# **Table of Contents**

Use	er Guide	1.1
Co	pyright	1.2
Intr	roduction	1.3
	Installation	1.3.1
	System Requirements	1.3.2
	Setup	1.3.3
	License	1.3.4
	Language	1.3.5
То	ol Reference	1.4
	Project Tools	1.4.1
	Add Data	1.4.1.1
	Add and Merge Point Cloud Data	1.4.1.2
	Delete Data	1.4.1.3
	Export Data	1.4.1.4
	Open Project	1.4.1.5
	Save Project	1.4.1.6
	Exit	1.4.1.7
	Color Tools	1.4.2
	Display by Height	1.4.2.1
	Display by Intensity	1.4.2.2
	Display by Classification	1.4.2.3
	Display by RGB	1.4.2.4
	Display by Return	1.4.2.5
	Display by Time	1.4.2.6
	Display by Blend	1.4.2.7
	Display by Tree ID	1.4.2.8
	Display by Mix	1.4.2.9
	Display by Danger Tree	1.4.2.10
	Display by EDL	1.4.2.11
	Viewing Tools	1.4.3
	Top View	1.4.3.1
	Bottom View	1.4.3.2
	Left View	1.4.3.3
	Right View	1.4.3.4
	Front View	1.4.3.5

Back View	1.4.3.6
Front Isometric View	1.4.3.7
Back Isometric View	1.4.3.8
Set Projection Mode	1.4.3.9
Pick Rotation Center	1.4.3.10
Operation Tools	1.4.4
Full Extent	1.4.4.1
Setting Tools	1.4.5
Configure Point Size	1.4.5.1
2D View	1.4.5.2
3D View	1.4.5.3
Capture Image	1.4.5.4
Cross Selection	1.4.5.5
Window Linkage	1.4.5.6
Rolling Screen	1.4.5.7
Configure Point Size and Type	1.4.5.8
Display Options	1.4.5.9
Camera Setting	1.4.5.10
Manipulator Setting	1.4.5.11
Shortcut Key Setting	1.4.5.12
Camera Roam	1.4.5.13
Configuration File Operation	1.4.5.14
Measure Tools	1.4.6
Pick Point	1.4.6.1
Multi Pick Point	1.4.6.2
Length Measurement	1.4.6.3
Area Measurement	1.4.6.4
Angle Measurement	1.4.6.5
Height Measurement	1.4.6.6
Volume Measurement	1.4.6.7
Density Measurement	1.4.6.8
Model Tools	1.4.7
Show Model	1.4.7.1
Show Triangle	1.4.7.2
Show Point	1.4.7.3
Profile Tools	1.4.8
Auto Hide	1.4.8.1
Profile	1.4.8.2
Auto Save Settings	1.4.8.3

Viewer Direction	1.4.8.4
Measure Tool	1.4.8.5
Automatic Profile	1.4.8.6
Manual Classify	1.4.8.7
Select Tools	1.4.9
Polygon Selection	1.4.9.1
Rectangle Selection	1.4.9.2
Sphere Selection	1.4.9.3
Subtract Selection	1.4.9.4
In Cut	1.4.9.5
Out Cut	1.4.9.6
Save Cut Result	1.4.9.7
Cancel Selection	1.4.9.8
Project Management Window	1.4.10
Layer Management	1.4.10.1
Point Cloud	1.4.10.1.1
Raster	1.4.10.1.2
Vector	1.4.10.1.3
Table	1.4.10.1.4
Model	1.4.10.1.5
Window Management	1.4.10.2
Viewers	1.4.11
New Window	1.4.11.1
Close	1.4.11.2
Close All	1.4.11.3
Tile Windows	1.4.11.4
Cascade Windows	1.4.11.5
Display Tools	1.4.12
Render to File	1.4.12.1
Save to Video	1.4.12.2
Language	1.4.12.3
Show Legend	1.4.12.4
Show Coordinate Axis	1.4.12.5
Shaders	1.4.12.6
EDL	1.4.12.6.1
Glass	1.4.12.6.2
Class Setting Options	1.4.12.7
Strip Alignment	1.4.13

Strip Alignment	1.4.13.1
Control Point Report	1.4.13.2
Adjust Elevation	1.4.13.3
Strip Quality Analysis	1.4.13.4
Elevation Difference Inspection Quality Report	1.4.13.5
Overlap Analysis	1.4.13.6
Density Analysis	1.4.13.7
Data Management	1.5
Point Cloud Tools	1.5.1
Outlier Removal	1.5.1.1
Noise Filter	1.5.1.2
Normalization	1.5.1.3
Normalization by Ground Class	1.5.1.4
Tile	1.5.1.5
Merge	1.5.1.6
Boundary	1.5.1.7
Subsampling	1.5.1.8
PCV	1.5.1.9
Define Projection	1.5.1.10
Reproject	1.5.1.11
Extract Color from Image	1.5.1.12
Subdivision	1.5.1.13
Transformation	1.5.1.14
Raster Tools	1.5.2
Band Calculator	1.5.2.1
Raster Mosaic	1.5.2.2
Raster Subdivision	1.5.2.3
Clip	1.5.3
Clip by Circle	1.5.3.1
Clip by Rectangle	1.5.3.2
Clip by Polygon	1.5.3.3
Conversion	1.5.4
Convert to LiData	1.5.4.1
Convert LiData to LiData	1.5.4.2
Convert to Las	1.5.4.3
Convert to ASCII	1.5.4.4
Convert to Raster	1.5.4.5
Convert to Shape	1.5.4.6
Convert to DXF	1.5.4.7

Convert Image to LiModel	1.5.4.8
Convert to Texture LiModel	1.5.4.9
Convert LiModel to Image	1.5.4.10
Extract	1.5.5
Extract by Class	1.5.5.1
Extract by Elevation	1.5.5.2
Extract by Intensity	1.5.5.3
Extract by Return	1.5.5.4
Extract by Time	1.5.5.5
Extract by Serial Time	1.5.5.6
Classify	1.5.6
Classify by Attribute	1.5.6.1
Classify Ground	1.5.6.2
Classify Low Points	1.5.6.3
Classify by Below Surface	1.5.6.4
Classify Isolated Points	1.5.6.5
Classify Air Points	1.5.6.6
Classify by Height Above Ground	1.5.6.7
Classify by Min Elevation	1.5.6.8
Classify Closeby Points	1.5.6.9
Class Conversion	1.5.6.10
Classify Buildings	1.5.6.11
Classify Model Key Points	1.5.6.12
Rectify Tools	1.5.7
PowerLine	1.6
Distribution Network Inspection	1.6.1
Project Configuration	1.6.1.1
Mark Tower	1.6.1.2
Tower List	1.6.1.2.1
Mark Distribution Network Tower	1.6.1.2.2
Tower Tools	1.6.1.2.3
Clip/Classify	1.6.1.3
Classify Tools	1.6.1.4
Profile Classification	1.6.1.5
Batch Processing	1.6.1.6
Generate Image	1.6.1.6.1
Generate Report	1.6.1.6.2
Clear	1.6.1.7

1.6.1.8
1.6.1.9
1.6.1.9.1
1.6.1.10
1.6.1.11
1.6.1.12
1.6.2
1.6.2.1
1.6.2.2
1.6.2.3
1.6.2.3.1
1.6.2.3.2
1.6.2.3.3
1.6.2.3.4
1.6.2.4
1.6.2.5
1.6.2.6
1.6.2.7
1.6.2.8
1.6.2.9
1.6.2.10
1.6.2.11
1.6.2.12
1.6.2.13
1.6.2.14
1.6.2.15
1.6.2.16
1.6.2.17
1.6.3
1.6.3.1
1.6.3.2
1.6.3.3
1.6.3.3.1
1.6.3.3.2
1.6.3.3.3
1.6.3.3.4
1.6.3.4
1.6.3.5
1.6.3.6

Vector Editing	1.6.3.7
File	1.6.3.7.1
Editor	1.6.3.7.2
Shortcut Settings	1.6.3.7.3
Layer Settings	1.6.3.7.4
Insulator Vectorization	1.6.3.7.5
Power Line Vectorization	1.6.3.7.6
Shield Line Vectorization	1.6.3.7.7
Drainage Thread Vectorization	1.6.3.7.8
Tower Vectorization	1.6.3.7.9
Simple Tower Model	1.6.3.7.10
Danger Points	1.6.3.8
Scissors Crossing	1.6.3.9
Tree Growth	1.6.3.10
Tree Fall	1.6.3.11
Clear	1.6.3.12
Image	1.6.3.13
Report	1.6.3.14
Multiple Directory Report	1.6.3.15
Simulation Condition	1.6.4
Project Configuration	1.6.4.1
Mark Tower	1.6.4.2
Information	1.6.4.3
Line Name	1.6.4.3.1
Power Line Type	1.6.4.3.2
Collection Time	1.6.4.3.3
Working Condition Parameter	1.6.4.3.4
Clip/Classify	1.6.4.4
Classify Tools	1.6.4.5
Profile Tools	1.6.4.6
Vector Editing	1.6.4.7
File	1.6.4.7.1
Editor	1.6.4.7.2
Shortcut Settings	1.6.4.7.3
Layer Settings	1.6.4.7.4
Insulator Vectorization	1.6.4.7.5
Power Line Vectorization	1.6.4.7.6
Shield Line Vectorization	1.6.4.7.7

Drainage Thread Vectorization	1.6.4.7.8
Tower Vectorization	1.6.4.7.9
Simple Tower Model	1.6.4.7.10
Danger Points	1.6.4.8
Scissors Crossing	1.6.4.9
Batch Processing	1.6.4.10
Simulation	1.6.4.11
Tree Growth	1.6.4.12
Tree Fall	1.6.4.13
Current Carrying Capacity	1.6.4.14
Allowable Stress	1.6.4.15
Scissors Crossing Double Line Simulation Analysis	1.6.4.16
Clear	1.6.4.17
Image	1.6.4.18
Report	1.6.4.19
Multiple Directory Report	1.6.4.20
Completion Acceptance	1.6.5
Project Configuration	1.6.5.1
Mark Tower	1.6.5.2
Clip/Classify	1.6.5.3
Classify Tools	1.6.5.4
Profile Tools	1.6.5.5
Vector Editing	1.6.5.6
File	1.6.5.6.1
Editor	1.6.5.6.2
Shortcut Settings	1.6.5.6.3
Layer Settings	1.6.5.6.4
Insulator Vectorization	1.6.5.6.5
Power Line Vectorization	1.6.5.6.6
Shield Line Vectorization	1.6.5.6.7
Drainage Thread Vectorization	1.6.5.6.8
Tower Vectorization	1.6.5.6.9
Simple Tower Model	1.6.5.6.10
Sag	1.6.5.7
Phase Spacing	1.6.5.8
Drainage Thread	1.6.5.9
Spacer	1.6.5.10
Rotation Angle	1.6.5.11
Insulator	1.6.5.12

Power Line And Shield Line Distance	1.6.5.13
Protect Angle	1.6.5.14
Anchor Bolt	1.6.5.15
Lighting Protector Inclination	1.6.5.16
Earth Electrode Line	1.6.5.17
Danger Point Sag	1.6.5.18
Wind Turbine Tower Inclination	1.6.5.19
Merge Report	1.6.5.20
Fine Inspection	1.6.6
Fine Inspection Menu	1.6.6.1
File Menu	1.6.6.2
Configuration	1.6.6.3
Trajectory Menu	1.6.6.4
Edit Waypoint	1.6.6.5
Tool Menu	1.6.6.6
Setting	1.6.6.7
Defect Recognition	1.6.6.8
Measurement	1.6.7
Tower Inclination	1.6.7.1
Cross Arms Height Difference	1.6.7.2
Tower Nominal Height	1.6.7.3
Minimum Distance	1.6.7.4
Minimum Crossing Distance	1.6.7.5
Phase Distance	1.6.7.6
Measure Sag	1.6.7.7
Sag	1.6.7.8
Rotation Angle	1.6.7.9
Deflection	1.6.7.10
Protect Angle	1.6.7.11
Tower Diaphragm	1.6.7.12
Curve Length	1.6.7.13
Goto	1.6.7.14
Tool Box	1.6.8
Strip Clip	1.6.8.1
Individual Tree Segmentation	1.6.8.2
Convert LiData To Las	1.6.8.3
Merge Point Cloud and Vector Data	1.6.8.4
Export Mixed Color Point Cloud	1.6.8.5

Classify Circuit by Tower Info	1.6.8.6
Automatic Shield Line Classification	1.6.8.7
Classify Noise by Vector Line	1.6.8.8
Copy And Adjust Point Cloud Position	1.6.8.9
Interactive Patch Line	1.6.8.10
Classify By Category And Restatistics	1.6.8.11
Smooth/Compress Point Cloud Data	1.6.8.12
Export Danger Points	1.6.8.13
Extract Danger Point Clouds	1.6.8.14
Extract Danger Trees	1.6.8.15
Tower Account	1.6.8.16
Section Map	1.6.8.17
Section Report	1.6.8.18
Merge Tower KML Files	1.6.8.19
Batch Rename Section Data Files	1.6.8.20
Open Working Directory	1.6.8.21
Detection Result List	1.6.9
Clearance Danger Points List	1.6.9.1
Scissors Crossing Analysis List	1.6.9.2
Tree Growth Analysis List	1.6.9.3
Tree Growth Warning Analysis List	1.6.9.4
Tree Fall Analysis List	1.6.9.5
Allowable Stress Analysis List	1.6.9.6
Drainage Thread Clearance Analysis List	1.6.9.7
Phase Spacing Analysis List	1.6.9.8
Sag Analysis List	1.6.9.9
Power Line And Shield Line Distance Analysis List	1.6.9.10
Nearest Distance Analysis List	1.6.9.11
Tutorials	1.7
Realtime Working Analysis	1.7.1
Early Warning Analysis	1.7.2
Appendix	1.8
Key Terms	1.8.1
File Formats	1.8.2
LiData	1.8.2.1
LAS	1.8.2.2
LiModel	1.8.2.3
LiTin	1.8.2.4
Clipping Point Cloud File Format	1.8.3

Clip by Circle File Format	1.8.3.1
Clip by Rectangle File Format	1.8.3.2
Extract by Time File Format	1.8.4
Homologous Points File Format	1.8.5
POS File	1.8.6
OUT File	1.8.7
Control Point File Format	1.8.8
Notes Elevation Points File	1.8.9
Sample Data File	1.8.10
Seed Points File	1.8.11
Tower File	1.8.12
Simulation File	1.8.13
Individual Tree Segmentation Result File	1.8.14
Line Type File	1.8.15
Line Time File	1.8.16
Working Condition Parameter File	1.8.17
Shortcut Keys	1.8.18
Menu Shortcut Keys	1.8.18.1
Viewer Shortcut Keys	1.8.18.2
Point Editing Shortcut Keys in Profile Window	1.8.18.3
High-Performance Graphics Mode Adjustment	1.8.19
FAQ	1.9
Installation and License Activation FAQ	1.9.1
Platform FAQ	1.9.2
Power Line FAQ	1.9.3
Changelog	1.10
End User License Agreement	1.11



# LiPowerline User Guide

Point Cloud Processing Software for -Power Line Inspection & Analysis





www.greenvalleyintl.com

# Copyright

**GreenValley International** 

LiPowerline V8.0

User Guide

#### Imprint and Version

**Document Version 1.0** 

Copyright © GreenValley International, Ltd. All rights reserved. This document may be copied and printed only in accordance with the terms of the Frame License Agreement for End Users of the related LiPowerline software.

Published by:

GreenValley International, Ltd.

Web: https://greenvalleyintl.com

#### Dear User,

Thank you for using LiPowerline software. We are pleased to be of service to you with LiDAR point cloud manipulation solutions. At GreenValley International, we constantly strive to improve our products. We therefore appreciate all comments and suggestions for improvements concerning our software, training, and documentation. Feel free to contact us via info@greenvalleyintl.com. Thank you.

#### Legal Disclaimer

GreenValley® is a registered trademark of GreenValley International, Ltd. Other trade names, company names and brand names mentioned in this document may be the trademark property of their holders.

Copyright

© 2024 GreenValley International, Ltd.

Date of printing: July 31, 2024

### Introduction

LiPowerline offers a complete and intuitive solution for power line inspection and analysis from LiDAR point clouds. It includes a powerful toolset for automatically classifying power lines, towers and vegetation and effectively detecting a range of user-defined danger points such as vegetation overgrowth and tree fall.

LiPowerline is able to segment individual sections of the corridor based on the location of each power tower and process all segments simultaneously.

After segmenting the corridor, LiPowerline utilizes our proprietary machine learning algorithms to automatically classify power lines and towers. The conditional classification algorithm then allows for the ground point, building and noise classification. Users are also given the option to manually edit the automatic classification results.

LiPowerline also has the ability to vectorize insulators and power lines, the results of which, can then be used to simulate and predict how environmental variabilities, such as strong wind, ice coverage and high temperatures, may affect the safety of electricity transmission.

Performing individual tree segmentation will allow users to simulate tree future growth and extract both identified and potential danger points.

Crucial risk and analysis information is then automatically generated as an assessment report, allowing for a precise understanding of the asset.

Specifically, LiPowerline has the following modules:

- **Data Management**: The module provides management tools for point cloud and raster data, which include format conversion, point cloud de-noising, normalization, raster band calculation and so on.
- **Statistics**: Based on the number, density and elevation of LiDAR points, statistics can be calculated for data quality evaluation.
- **Classify**: The module provides various classification methods for point cloud classification including ground classification, ground key point classification, interactive classification, machine-learning-based classification (for building, vegetation, and custom classes) etc.
- **Power Line**: The module supports automatic point classification(tower, conductor, shield line, insulator, drainage thread, scissors crossing line, ground point, vegetation, buildings, roads and water), real-time analysis of the powerline corridor condition and generate user-defined reports. Support simulation analysis under conditions such as high temperature, icing, and strong winds. Provide various tower and conductor measurement and analysis tools, such as tower tilt, sag analysis, etc. In addition, it supports the generation of tower fine inspection, wire inspection, and channel inspection routes, and checks the flight safety of the routes.

### **Get Started**

Please refer to Installation and License to install the software. The usage is described in Tutorials.

### Installation

Download the latest version of LiPowerline from the GreenValley International official website before installation.

### **System Requirements**

- RAM: at least 8G or more.
- CPU: Intel® Core™ i5/i7; Dual-core processor.
- Display Adapter: NVIDIA graphics above GTX 970, video memory no less than 4GB.
- **Operating Systems**: Microsoft Windows 7 (64-bit), Microsoft Windows 8 (64-bit), Microsoft Windows 10 (64-bit), Microsoft Windows 11 (64-bit), Microsoft Windows Server 2012 and higher.

Note: Please enable high-performance graphics mode for running the software. On Windows 8 and Windows 10 if the software is installed on the system disk, you need to set it up to run as an administrator.

#### Setup

- 1. Run the LiPowerline Setup Wizard.
- 2. Click Next button in the Welcome Interface.
- 3. Click / Agree button to continue if you accept the License Agreement.
- 4. Choose the installation path (or use default path), then click Install button.
- 5. Click Finish button after installation.

#### License Manager

There are two licensing approaches to activate LiPowerline, by license dongle or license code. For license dongle, users must not format, delete, or copy the license dongle.

1) License dongle

Properly insert a license dongle to USB port to activate LiPowerline.

2) License code

License code would be generated based on activation information given by LiPowerline users. After purchasing a license code, please follow the following steps to activate LiPowerline.

1.Run the software.

2.Click Help > Activate License, the License Manager window will pop up.

3.Under General Information tab, fill in your name and company name, select the modules you want to activate, and then click *Copy*.

4.Email the copied information to info@greenvalleyintl.com.

5. There are two licensing modes: single use licensing and concurrent use licensing. After receiving the activation key, activate or revoke the license using online or offline mode.

- Single Use Licensing
  - Activation/Update

Online Activation/Update: When connecting to the internet, under the "Single Use Licensing" tab, enter the authorization key, select "Online", and click "Activate" to activate or update. Activation information, such as expiration date, will displayed below. Under "General Information" page, you may also check the expiration date for each individual module. If you need to set up proxy to connect to the internet, click is to use proxy, and set up the address, port, user name, and password.

Ose r	roxy					
ddress:	XXX. XXX. XXX. XXX		Port:	xxxx		
lser:	xxxxxx		Password	*****		
	Key	Exp	iration Date		Status	
	CE5H******RFLE	2018-1	1-30 11:21:	07		

Offline activation: Step 1: Select "Offline" under the "Single Use Licensing" tab; Step 2: Click "Generate Request File" button to generate the request file (.req); Step 3: Use a computer that can connect to the internet to browse to https://user.bitanswer.cn, enter the authorization key to log in, click "Update", upload the request file (.req), and download the generated upgrade file (.upd); Step 4: go back to the License Manager interface, click "Apply Promote File" and select the downloaded .upd file.

🔘 0n	line 🔨	Offline
Step1: Generate Re	quest File or	Generate Revoke File
an an		(1.1.)
CE5H*****RFLE	Expiration Date 2018-11-30 11:21:07	Status

Revoke

To unbind an activation key from a computer, user could revoke the activation key online or offline. After the authorization key is revoked, it can be reused on the same computer or a different one.

Online Revoke: In "Single Use Licensing" tab, enter the authorization key, select "Online", and click "Revoke" to revoke the key. If you need to set up proxy to connect to the internet, click rouse proxy and to set up the address, port, user name, and password.

ay)					
🕜 llea	Online		Off	line	
Address	·····	Port:	xxxx		
Vser:	*****	Password	Password xxxxxxx		
	Key	Expiration Date		Status	
L	CE5H******RFLE	2018-11-30 11:21	07		

Offline Revoke: Step 1: Select "Offline" under the "Single Use Licensing" tab; Step 2: Click "Generate Revoke File" button to generate the request file (.req); Step 3: Use a computer that can connect to the internet to browse to https://user.bitanswer.cn, enter the authorization key to log in, click "Update", upload the request file (.req), and download the generated upgrade file (.upd); Step 4: go back to the License Manager interface, click "Apply Promote File" and select the downloaded .upd file.

Offline Generate Revoke File offline activation fil	or	🔘 Online
Generate Revoke File	or	
offline activation fil		Step1: Generate Request
Status	Expiration Date	Key
	2018-11-30 11:21:07	CE5H*****RFLE
Status	Expiration Date 2018-11-30 11:21:07	Key CE5H******RFLE

• Delete

To delete authorization information from the computer, right-click on the authorization key and select "Delete Key". After being deleted, the same activation key can only be used on the same computer.

neral information V Single Use Licensing V Concurrent Use Licensing V         Online         Online         Step1:         Generate Request File         or         Generate Revoke         Step2:         Please go to https://user.bitanser.cn to generate offline activatio         Step3:         Apply Promote File         Key         Expiration Date	File n file
<ul> <li>Online</li> <li>Online</li> <li>Offline</li> <li>Step1: Generate Request File</li> <li>or</li> <li>Generate Revoka</li> <li>Step2: Please go to https://user.bitanser.cn to generate offline activation</li> <li>Step3: Apply Promote File</li> <li>Key</li> <li>Expiration Date</li> <li>Step3:</li> </ul>	e File n file
Step1: Generate Request File or Generate Revok Step2: Please go to https://user.bitanser.cn to generate offline activatio Step3: Apply Promote File Key Expiration Date St	a File n file
Step2: Please go to https://user.bitanser.cn to generate offline activatio Step3: Apply Promote File Key Expiration Date St	n file
Step3: Apply Promote File Key Expiration Date St	
Key Expiration Date St	
Key Expiration Date St	
	atus
CE5H*****RFLE 2018-11-30 11:21:07	
Delete Key	
2	

• Concurrent Use Licensing

Install enterprise activation tool on the server to activate the key online or offline. Other users can use the activation windows to input the server's IP address to activate the software. The default port is 8273. Click "Apply".

General In	formation V Single U	L1DAR360 Suite	
Server TP.			
Port:	8273		
		Apply Logout	

6.Click the help button role on the License Manager interface to view the license manager user guide.

Note: If any of the software instance (i.e. LiDAR360, LiMapper, LiGeoreference, LiPowerline) is being opened while updating the license in License Manager, please restart the software to make the license be effective.

Note: If an user would like to move a key from one computer to another, he/she should revoke first, then activate on the other. If the license code has been deleted, the user should reactivate on the same computer first, then revoke and activate this key on the other computer.

Note: Please contact info@greenvalleyintl.com for inquiry and purchase.

#### Languages

Currently, the supported languages are English. You can switch the menu language in the following way:

- 1. Click *Display > Language > English* in the menu bar.
- 2. Language change needs a restart to be effective. Click Yes in the pop-up dialog to restart the software immediately, or click *Cancel* and restart later.

### **Tool Reference**

This chapter describes the usage of menu bar, toolbar, project management windows and toolbox of LiPowerline in detail.

- Project Tools
- Color Tools
- Viewing Tools
- Operation Tools
- Setting Tools
- Measure Tools
- Model Tools
- Profile Tools
- Select Tools
- Rectify Tools
- Project Management Window
- Viewers
- Display
- Data Management
- Statistics
- Classify
- Power Line

# **Project Tools**

- Add Data
- Add and Merge Point Cloud Data
- Delete Data
- Export Data
- Open Project
- Save Project
- Exit

### Add Data

**Brief**: One of the most useful features of LiPowerline is its ability to interface with data in many file formats. You can import point clouds (LAS/LAZ, TXT, PLY, ASC, NEU, XYZ, PTS, CSV etc.), tables, images (JPG, TIF), models (OSG, LiModel, LiTin) or vectors into LiPowerline. It allows you to visualize, animate and edit your point cloud as well. Point cloud data will be converted into LiData file at the first time being added. LiData file is the LiPowerline native file format for point cloud and optimized for viewing.

#### Import LAS/LAZ File

The LAS file is intended to contain LiDAR point data records. The data will generally be put into this format from software (e.g. provided by LiDAR hardware vendors) which combines GPS, IMU, and laser pulse range data to produce X, Y, and Z point data. The intention of the data format is to provide an open format that allows different LiDAR hardware and software tools to output data in a common format.

- 1. Click File > Data > Add Data to view the Open Data window.
- 2. Choose the LAS file you want to import and click *Open* for the Open LAS File window where you can do some initial settings as shown in the figures below:

ider Attrib	ute Option	Coordi	inate Option				
Version:			1.0				
Source ID:			0				
System ID:							
Generating	Software:		TerraScan				
File Creati	on Day/Yea	r:	0/0				
Header Byte	Size:		227				
Data Offset	:		311				
Number Var.	Length Re	cords:	1				
Point Data 1	Format:		1				
Number of P	oint Recor	ds:	2745406				
Compressed:			False				
Number of P	oints by R	eturn:	0 0 0 0 0				
Scale Facto	r X Y Z:		0.010000 0.	010000 0.0	10000		
Offset X Y	Ζ:		0.000000 0.	000000 0.0	00000		
Min X Y Z:			344999.9900	100 4050500	. 000000	2250.320	1000
Max X Y Z:			345499.9900	100 4051000	.000000	2494.100	1000

- 3. Click tab *Header* to check general LAS file header information such as Version, Source ID, System ID, Generating Software, File Creation Day/Year, Header Byte Size, Data Offset, Number of Point Records etc.
- 4. Click tab *Attribute Option* to set Crop Option and decide which point attributes you want to import for each point record. LiPowerline imports all the point attributes by default.

Crop ( Cebe c	Option	Points		
Attril	oute	V I I I I I I I		
X 🔟		💟 Ү	[ <b>√</b> ] Z	
<b>v</b>	Intensi ty		📝 GPS time	📝 Scan angle rank
/	Classification		📝 Point source ID	📝 Edge of flight line
7	Return number		👿 Scan direction flag	👿 User data
v [	RGB		📝 Number of returns	
Sel	lect All		🔘 Unselect All	

5. Click tab Coordinate Option to set the coordinate system for your point records.

ilter	Add C	oordinate System 🔻
ecently used coordinate refe	rence systems	() 
Coordinate Reference System	Authority ID	
North_Pole_Azimuthal_Equidistant	EPSG:102016	1.4
WGS 84	EPSG:4326	
WGS 84 / UTM zone 32N	EPSG:32632	E
WGS 84 / UTM zone 48N	EPSG:32648	
WGS 84 / UTM zone 47N	EPSG:32647	1
WGS 84 / UTM zone 50N	EPSG:32650	
1100 0 1 1 1 T 1 1 101 1		
oordinate reference systems	of the world	ide deprecated CRSs
oordinate reference systems	of the world Authority ID	ide deprecated CRSs
oordinate reference systems Coordinate Reference System Voirol 1879	of the world Authority ID EPSG:4671	ide deprecated CRSs
oordinate reference systems Coordinate Reference System Voirol 1879 Voirol 1879 (Paris)	of the world Authority ID EPSG:4671 EPSG:4821	ide deprecated CRSs
oordinate reference systems Coordinate Reference System Voirol 1879 Voirol 1879 (Paris) WGS 66	of the world Authority ID EPSG:4671 EPSG:4821 EPSG:4760	ide deprecated CRSs
oordinate reference systems Coordinate Reference System Voirol 1879 Voirol 1879 (Paris) WGS 66 WGS 72	of the world IN K Authority ID EPSG:4671 EPSG:4821 EPSG:4760 EPSG:4322	ide deprecated CRSs
oordinate reference systems Coordinate Reference System Voirol 1879 Voirol 1879 (Paris) WGS 66 WGS 72 WGS 72BE	of the world IN Authority ID EPSG:4671 EPSG:4821 EPSG:4821 EPSG:4322 EPSG:4322 EPSG:4324	ide deprecated CRSs
oordinate reference systems Coordinate Reference System Voirol 1879 Voirol 1879 Voirol 1879 (Paris) WGS 66 WGS 72 WGS 72 WGS 72BE WGS 84	of the world IN Authority ID EPSG:4671 EPSG:4671 EPSG:4821 EPSG:4322 EPSG:4322 EPSG:4324 EPSG:4326	ide deprecated CRSs
oordinate reference systems     Coordinate Reference System     Voirol 1879     Voirol 1879 (Paris)     WGS 66     WGS 72     WGS 72BE     WGS 84      ✓	of the world IN K Authority ID EPSG:4671 EPSG:4821 EPSG:4322 EPSG:4324 EPSG:4326 III	ide deprecated CRSs
ordinate reference systems     Coordinate Reference System     Voirol 1879     Voirol 1879 (Paris)     WGS 66     WGS 72     WGS 72BE     WGS 84     ✓	of the world IN K Authority ID EPSG:4671 EPSG:4821 EPSG:4322 EPSG:4324 EPSG:4326 III	ide deprecated CRSs
oordinate reference systems Coordinate Reference System Voirol 1879 Voirol 1879 (Paris) WGS 66 WGS 72 WGS 72BE WGS 84	of the world ID EPSG:4671 EPSG:4671 EPSG:4821 EPSG:4322 EPSG:4324 EPSG:4326 III	ide deprecated CR

You can search the coordinate system much more quickly by using regular expressions. For example, the WGS 84 coordinate system will be displayed instantly when you input EPSG code of WGS 84 system as shown in the figure below:

leader	Attribute Option	Coordinate Option		
llter	4326			Add Coordinate System 🔻
lecent]	ly used coordinate	reference systems		
Coordin	nate Reference System		Authority ID	
WGS 84			EPSG:4326	
< Coordin	nate reference sys	m tems of the world		Hide deprecated CRSs
Coordin	nate Reference System		Authority ID	
▲ Geo	graphic Coordinate Sy	/stems		
1	WGS 84		EPSG:4326	
<	<b>-4 []RS</b> - WGS 84	III		
GEOGCS [	"WGS 84", DATUM["WGS_ , 298.257223563, AUTHO	1984", SPHEROID["WGS 84 RITY["EPSG", "7030"]], 1	1", :0¥GS84[0, 0, 0, 0	, 0, 0, 0], AUTHORITY["EPSG

You can also import coordinate system form WKT or PRJ by clicking drop-down menu *Add Coordinate System*. Recently used coordinate reference systems holds a history list.

6. Click *Apply* or *Apply All* when you finish your configuration. *Apply* implies that you want this configuration for current point cloud data only. *Apply All* means all the point cloud data share the same configuration during the LiPowerline's running and it won't show this configuration window again even you add new data.

#### **Import TXT File**

A point cloud is a set of vertices in a three-dimensional coordinate system usually defined by X, Y, and Z coordinates and other attributes such as color and normal. These attributes can be simply arranged in one line for each point record and one single TXT file for one-point set.

- 1. Click *File > Data > Add Data* to view the Open Data window.
- 2. Choose the TXT file you want to import and click *Open* for the Open Ascii File window where you can do some initial settings as shown in the figure below:

	e first iew ii	nes or this	TILE. Ches	ose each column	attrioutes							-
1	2	3		5	6	7	В	9	10	11	12	1
x -	r -	Z -	Ignore -	Ignore 🔻	Ignore	Ignore -	Ignore 🔻	Ignore 🔻	I gnor e 🔹	Ignore -	I gnor e 🔫	1
	Y	z	intensity	classification	GPSTime	scanAngleRank	returnNumber	userData	edgeFlightLine	scanDirection	numOfReturn	
22500.680	4102000,490	2510.230	178	1	527243.125	9	1	32	0	0	2	
22502.350	4102001.120	2507.620	136	1	527243.1875	9	1	32	0	0	z	
2500.780	4102001.240	2490.490	169	2	527540.875	5	2	32	0	1	2	
22501.570	4102000.620	2507.480	156	1	527540.875	4	1	32	0	0	2	
2501.230	4102000.190	2510.870	182	1	527706	-3	2	32	0	1	2	
22502.410	4102000.610	2513.680	156	1	527706	-3	2	32	0	1	4	
22501.450	4102003.540	2490.990	135	1	527243.1875	9	3	32	0	1	3	
22500.380	4102004.720	2505.990	158	1	527243.1875	9	2	32	0	0	4	
2501.450	4102003.800	2512.140	136	1	527243.1875	9	1	32	0	1	3	

- 3. LiPowerline can automatically detect the delimiters but you can also specify delimiter manually.
- 4. There are indeed cells that are colored red in the import window if TXT file has a header. Just skip them by setting *Skip line* value to 1.

1	Z	3	4	5	6	т	8	9	10	31	12
x 🔻	Y .	I z •	Intensity .	Ignore •	Ignora -	Ignora -	Ignore -				
322500.680	4102000.490	2510.230	178	1	527243.125	9	1	32	0	0	2
322502.350	4102001.120	2507.620	136	1	527243.1875	9	1	32	0	0	2
322500.780	4102001.240	2490,490	169	2	527540.875	5	2	32	0	1	2
322501.570	4102000.620	2507.480	156	1	527540.875	4	1	32	0	0	2
322501.230	4102000.190	2510.870	182	1	527706	-3	2	32	0	1	2
322502.410	41.02000.610	2513,680	156	1	527705	-3	2	32	0	1	4
322501.450	41.02003.540	2490.990	135	1	527243.1875	9	3	32	0	1	3
322500.380	4102004.720	2505.990	158	1	527243.1875	9	2	32	0	0	4
322501.450	4102003.800	2512.140	136	1	527243.1875	9	1	32	0	1	3

5. Use the drop-downs to give the proper form of your point records.

#### Import CSV File

The so-called CSV (Comma Separated Values) format is the most common import and export format for spreadsheets and databases. CSV format was used for many years prior to attempts to describe the format in a standardized way in RFC 4180. The lack of a well-defined standard means that subtle differences often exist in the data produced and consumed by different applications. These differences can make it troublesome to process CSV files from multiple sources. Still, while the delimiters and quoting characters vary, the overall format is similar enough that it is possible to write a single module which can efficiently manipulate such data.

- 1. Click *File > Data > Add Data* to view the Open Data window.
- 2. Choose the CSV file you want to import and click *Open* for the Open ASCII File window where you can do some initial settings as shown in the figures below:

Forest Sample Data/Fo	orest_Outliers Removal_CHM Segmentation.cs
Open As	
🧿 As Table	🔘 As PointCloud
Show Lable Treel	

CSV file can be opened as table or point cloud.

3. *Open as Table* is recommended if the CSV file is the resultant product of the Segmentation function. The CSV table contains the ID of each tree, the x, y coordinate locations, the tree height, the crown diameter, and the crown area properties. The data type could be *Point* or *Circle*. If *Point* type was selected, you should specify the X,Y,Z columns additionally.



If Circle type was selected, you should specify the center and radius.



Click Show Label radio button to show/hide label for each point or circle.

4. The Import TXT File section has more detailed descriptions if you Open as Point Cloud.

#### **Import PLY File**

The polygon (PLY) file format, also known as the Stanford triangle format stores three-dimensional data from 3-D scanners. It is a format for storing graphical objects that are described as a collection of polygons. A PLY file consists of a header, followed by a list of vertices and then, a list of polygons. The header specifies how many vertices and polygons are in the file. It also states what properties are associated with each vertex, such as (x, y, z) coordinates, normals, and color. The file format has two sub-formats: an ASCII representation and a binary version for compact storage and for rapid saving and loading. The header of both ASCII and binary files is ASCII text.

- 1. Click File > Data > Add Data to view the Open Data window.
- 2. Choose the PLY file you want to import and click *Open* for the Open PLY File window where you can do some initial settings as shown in the figure below:

Open	PLY File		×
Type			
Elements	0	Properties	0
Point X	x		•
Point Y	у		•
Point Z	z		•]
Red	None		•
Green	None		•
Blue	None		•
		Apply Apply all C	ancel

- 3. Specify properties that associated with each vertex's coordinates(x,y,z).
- 4. Specify properties that associated with each vertex's color (r,g,b) if they have any. Otherwise, simply choose *None*.
- 5. Click Apply when you complete your configuration.

#### **Import Raster File**

A raster data structure is based on a (usually rectangular, square-based) tessellation of the 2D plane into cells. In its simplest form, a raster consists of a matrix of cells (pixels) organized into rows and columns (grid) where each cell contains a value representing information. The geographic location of each cell is implied by its position in the cell matrix. Accordingly, other than an origin point, e.g. bottom left corner, no geographic coordinates are stored. Due to the nature of the data storage technique data analysis is usually easy to program and quick to perform.

- 1. Click *File > Data > Add Data* to view the Open Data window.
- 2. Choose the Raster file and click Open.

#### **Import Vector File**

Vector data can be represented at its original resolution and form without generalization. Graphic output is usually more aesthetically pleasing (traditional cartographic representation). Since most data is in vector form and no data conversion is required. Accurate geographic location of data is maintained.

- 1. Click *File > Data > Add Data* to view the Open Data window.
- 2. Choose the Vector file and click Open.

#### **Import Model File**

LiModel file is the native file format where LiPowerline stores triangulated regular network models generated by DEM or DSM. LiTin file is generated by the irregular 2.5D triangulation model based on the point cloud.

- 1. Click *File > Data > Add Data* to view the Open Data window.
- 2. Choose the Model file and click Open.

Note: You can drag file(s) into LiPowerline directly. If you can't, click here for more help.

### Add and Merge Point Cloud Data

**Brief**: Merge two or more point clouds in LAS/LAZ or LiData format to one single point cloud in LiData format.

#### Steps

1. Click tool botton  $-\frac{1}{M}$  to open the Add and Merge Data window.

		D:/airborne lidar data/6.las	
0	2	D:/airborne lidar data//.las D:/airborne lidar data/8.las	
	1		

Bounding boxes of point clouds are displayed in the left area. Bounding box of the selected point cloud is highlighted in red.

- 2. Select LAS or LiData as your data type.
- 3. Click to add LAS/LiData file(s).
- 4. Click to remove LAS/LiData file(s).
- 5. Click *f* to remove all file(s).

### **Delete Data**

Brief: Remove data.

### Steps

1. Select the data item you want to remove in the tree widget to active the Remove button  $\times$ .

### 2. Click 🗙 .

Note: In some cases, it is not allowed to remove data from LiPowerline when it is busy running some critical functions.

### **Export Data**

**Brief**: As described in Import section, you can easily move data into and out of LiPowerline. You can currently export point clouds from LiData to many other formats (LAS/LAZ, TXT, PLY, ASC, NEU, XYZ, PTS, CSV etc.).

#### Steps

- 1. Select the point cloud data you want to export in the tree widget on the left.
- 2. Move the mouse to that item and right click.
- 3. Click *Export* to show the Export Point Cloud window.
- 4. Input file path and name:

				0++
🐔 OneDrive 🔦	Name	Date	Туре	Size
	🌗 doc	2017/12/3 16:03	Filefolder	
Desktop	🍺 nearest	2017/12/3 16:03	Filefolder	
Libranes	🍺 cache	2017/12/3 16:03	File folder	
B tg	ALSForest.las	2014/3/3 21:31	Las File (Jas)	75,070
<ul> <li>1_TLS Forest Sample Dat</li> <li>1102</li> <li>1109</li> <li>ALS Forest Sample Data</li> </ul>				
Gircle -	<i>i</i> [	m		
→ 1109 → ALS Forest Sample Data → Circle +	۲	m.		

5. Set file type:

Organize 🔻 New folde	r			800 - (
🐔 OneDrive	<ul> <li>Name</li> </ul>	Date	Туре	Size
	🔲 🌗 doc	2017/12/3 16:03	Filefolder	
Desktop	🍺 nearest	2017/12/3 16:03	Filefolder	
Libranes	🍑 cache	2017/12/3 16:03	Filefolder	
B tg	ALSForest.las	2014/3/3 21:31	Las File (.las)	75,070
<ul> <li>1_SampleData</li> <li>1_TLS Forest Sample</li> <li>1102</li> <li>1109</li> <li>ALS Forest Sample</li> </ul>	ple Dat			
<ul> <li>1_SampleData</li> <li>1_TLS Forest Sample</li> <li>1102</li> <li>1109</li> <li>ALS Forest Semple</li> <li>Circle</li> </ul>	e Data - I (	m		
I_SampleData I_TLS Forest SampleData I_TLS Forest Sample II09 ALS Forest Sample Circle File name: ALSFor	e Data 	.m.		
I_SampleData I_TLS Forest SampleData I_TLS Forest SampleData II02 II09 IALS Forest SampleData Circle File name: ALSFor Save as type: LAS clc	e Data +	m		
I_SampleData     I_ILS Forest Samp     In02     In09     ALS Forest Sample     Circle     File name: ALSFor     Save as type     LAS ck     LAS ck	ple Data = Deta = ( rest.les sud(".les *.lez) sud(".les *.lez)	. W		

6. Click Save .

### **Open Project**

**Brief**: Open a LiPowerline project file(\*.LiProj).

#### Steps

1. Click File > Open Project to show Open Project window:



2. Select a LiPowerline project file and click Open.

### **Save Project**

Brief: Save project.

#### Steps

1. Click the Save Project button 💾 on the tool bar,and then click Save.

rganize 🕶 New folder				-	
Desktop Libraries Libraries Libraries Computer Libraries Librarie	Neme Jodoc Jonearest Jocache	Date 2017/12/3 16:03 2017/12/3 16:03 2017/12/3 16:03	Type File folder File folder File folder	Size	
cache     doc     File name: Untilied-LDAR		·W			
Save as type: PROJ File(*.LiPr	D				

- 2. If this is the first time that you are saving the project, type a name for it in the file name box, and then click *Save*.
- 3. You can save a project in the following file format: \*.LiPrj.

### Exit

Brief: Exit the software.

### Steps

- 1. (Optional) Click *File > Exit* to quit.
- 2. (Optional) Use the hotkey Alt+F4 to quit.
# **Color Tools**

With tools in this section, LiPowerline allows you to visualize vast amounts of point cloud using the best data representations for your analysis. You can change the coloration of the point cloud displaying by class or intensity, GPS time, return of number, etc. You can also enhance the render effect using visualization tools such as EDL, PCV and Glass which are intuitive and helpful for quality check.

- Display by Height
- Display by Intensity
- Display by Class
- Display by RGB
- Display by Return
- Display by Time
- Display by Blend
- Display by Tree ID
- Display by Mix
- Display by Danger Tree
- Display by EDL

# **Display by Height**

E Brief: This tool is used for displaying point cloud data. The elevation values of point cloud data are mapped to several uniformly varying color intervals, so as to display the variation of elevation values more intuitively.

### Steps

- 1. Click the window that loads point cloud data with the left mouse button and set it as the active window.
- 2. Click the button **E** on the toolbar to pop up the dialog "Display by Elevation", as shown below.



3. Select the appropriate color bar in the combo box and click the "OK" button. The color indicator of the window will generate the corresponding color bar according to the elevation range of the point cloud data. At the same time, the data is displayed by elevation in the scene. The visual effects are better with EDL mode, as shown below.



Note: This tool only works with point cloud data.

# **Display by Intensity**

**Brief**: This tool is used for displaying point cloud data. The intensity values of point cloud data are mapped to several uniformly varying color intervals, so as to display the variation of intensity values more intuitively.

### Steps

- 1. Click the window that loads point cloud data with the left mouse button and set it as the active window.
- 2. Click *Tool* > *Colorbar* > **I** *Display by Intensity*. The color indicator of the window will generate the corresponding gray color bar according to the intensity range of the point cloud data. At the same time, the data is displayed by intensity in the scene. The visual effects are better with EDL mode, as shown below.



Note: This tool only works with point cloud data.

## **Display by Class**

**Brief**: This tool is used for displaying point cloud data. The classes of point cloud data are mapped to discrete color values, so as to distinguish different classes of point cloud data more intuitively.

#### Steps

- 1. Click the window that loads point cloud data with the left mouse button and set it as the active window.
- 2. Click the button C on the toolbar to pop up the dialog "Display by Class", as shown below.

Class ID	Description	Color	^
2	Ground		
4	Medium Vegeta		
6	Building		
7	Noise		
16	Conductor		
17	Structure		
20	Shield Wire		
23	Other Line		
	2 4 6 7 16 17 20 23	2Ground4Medium Vegeta***6Building7Noise16Conductor17Structure20Shield Wire23Other Line	2Ground4Medium Vegeta***6Building7Noise16Conductor17Structure20Shield Wire23Other Line

3. Select the appropriate color for each class and click the "OK" button. The color indicator of the window will generate the corresponding color bar according to the class attribute of the point cloud data. At the same time, the data is displayed by classification in the scene. The visual effects are better with EDL mode, as shown below.



Note: This tool only works with point cloud data.

# **Display by RGB**

**Brief**: Capable of displaying point cloud data, rendering the point cloud using its inherent RGB color attributes.

### Steps

- 1. Click the window that loads point cloud data with the left mouse button and set it as the active window.
- 2. Click the button Solution on the toolbar. The data is displayed according to its own RGB values in the scene, as shown below.



Note: This tool only works with point cloud data contains RGB attributes.

# **Display by Return**

R Brief: This tool is used for displaying point cloud data. The return numbers of point cloud data are mapped to discrete color values, so as to distinguish different return numbers of point cloud data more intuitively.

### Steps

- 1. Click the window that loads point cloud data with the left mouse button and set it as the active window.
- 2. Click *Tool* > *Colorbar* > **R** *Display by Return* to pop up the dialog "Display by Return", as shown below.

Display	Return Number	Color
	1	
	2	
	3	
	4	

3. Select the appropriate color bar for each return number and click the "OK" button. The color indicator of the window will generate the corresponding color bar according to the return number attribute of the point cloud data. At the same time, the data is displayed by return number in the scene. The visual effects are better with EDL mode, as shown below.



Note: This tool only works with point cloud data.

# **Display by Time**

**Brief**: This tool is used for displaying point cloud data. The GPS time values of point cloud data are mapped to several uniformly varying color intervals, so as to display the variation of GPS time values more intuitively.

### Steps

- 1. Click the window that loads point cloud data with the left mouse button and set it as the active window.
- 2. Click *Tool* > *Colorbar* > T *Display by Time* to pop up the dialog "Display by Time", as shown below.



3. Select the appropriate color bar in the combo box and click the "OK" button. The color indicator of the window will generate the corresponding color bar according to the GPS time range of the point cloud data. At the same time, the data is displayed by time in the scene. The visual effects are better with EDL mode, as shown below.





# **Display by Blend**

**Brief**: This tool is used for displaying point cloud data. Consider the elevation attribute and intensity attribute, the point cloud data is mapped to several uniformly varying color intervals, so as to reflect the comprehensive variation of elevation/intensity more intuitively, and display the feature class and boundary more explicitly.

### Steps

- 1. Click the window that loads point cloud data with the left mouse button and set it as the active window.
- 2. (Optional) Process the point cloud data by PCV.
- 3. Click *Tool* > *Colorbar* > B *Display by Blend* to pop up the dialog "Display by Blend", as shown below.



4. Select the appropriate color bar in the combo box and click the "OK" button. The color indicator of the window will generate the corresponding color bar according to the elevation range of the point cloud data. At the same time, the data is displayed in the scene according to the elevation values and intensity values. The visual effects are better with EDL mode, as shown below.





Note: This tool only works with point cloud data. The visual effects will be better after PCV process for the point cloud data.

## **Display by Tree ID**

**Brief**: This tool is used for displaying point cloud data after point cloud segmentation. The tree ID's of point cloud data are mapped to discrete color values, so as to distinguish different trees of more intuitively.

### Steps

- 1. Click the window that loads point cloud data with the left mouse button and set it as the active window.
- 2. Click the button ID on the toolbar. If the point cloud data contains tree ID attribute, then the data will be displayed by tree ID in the scene. The visual effects are better with EDL mode, as shown below.



Note: This tool only works with point cloud data after individual tree segmentation.

# **Display by Mix**

**Brief**: This tool is used for displaying point cloud data. Different attributes of point cloud data are mapped to several uniformly varying color intervals, at the same time different ways of attribute filtering are supported, so as to display the variation of a certain attribute of the filtered point cloud data more intuitively.

### Steps

- 1. Click the window that loads point cloud data with the left mouse button and set it as the active window.
- 2. Click *Tool > Colorbar > M Display by Mix* to pop up the dialog "Display by Mix", as shown below.

ргау бу Ле	ight 🔹					
orBar ilter by Cl	assification			Filter by Return Nu	mber	
isplay	lass Numbe	Class Name	^	Display	Return Num	ber
	2	Ground			1	
<u> </u>	4	Medium V…				
	5	High Vege…				
	16	Reserved16				
	17	Reserved17				
2	10	Percented 19	¥			

- 3. Select the attribute for display.
- 4. Select the appropriate color bar in the drop-down box.
- 5. Check the classes and return numbers for filtering.
- 6. Click the "OK" button. Then the color indicator of the window will generate the corresponding color bar according to the selected attribute range the point cloud data. The data will be filtered by the specified attributes first and then be displayed by the specified attributes in the scene. The visual effects are better with EDL mode, as shown below.



#### **Settings**

- **Display By**: The selected attribute will be mapped to specified color range.
  - Height(Default): The elevation attribute of the point cloud data.
  - Intensity: The intensity attribute of the point cloud data.
  - Time: The GPS Time attribute of the point cloud data.
- ColorBar: The color bar supports several uniformly varying color intervals for color mapping.
- Filter by Classification: List all the classes users can choose to filter the point cloud data.
- Filter by Return Number: List all the return numbers users can choose to filter the point cloud data.

Note: This tool only works with point cloud data.

# **Display by Danger Tree**

### Summary

4 Used to display the dangerous tree in the segmented point cloud. By mapping the Tree ID of the

dangerous tree and the attribute of clearance distance to different color values, intuitively distinguish the different dangerous in different colors.

### Steps

- 1. Click the window that loads the point cloud data with the left mouse button and set it as the active window.
- 2. Click > in toolbar at the left side of the software UI. In the popup menu, click the software UI. In the popup menu, click the software util be displayed contains the information of Tree ID and the clearance distance, the dangerous trees will be displayed by tree ID. The visual effects are better with EDL model, as shown below.



Note: This tool only works on point cloud data that has undergone single-tree segmentation and clearance danger point detection.

# **Display by EDL**

EDL **Brief**: This tool is used to display the point cloud data and enhance the visual effects of the contour features using the Eye Dome Lighting (EDL) mode. EDL is a shading technique that works with other display mode (e.g. display by height, display by intensity) to improve the depth perception in 3D point cloud visualization.

### Steps

- 1. Click the window that loads point cloud data with the left mouse button and set it as the active window.
- 2. Click the button EDL on the toolbar. The visual effects of the point cloud data in the scene will be improved with EDL mode. The following picture shows the comparison before and after using EDL display mode.



Note: This tool only works with point cloud data.

## **Viewing Tools**

Set current active window to some view.

- Top View
- Bottom View
- Left View
- Right View
- Front View
- Back View
- Front Isometric View
- Back Isometric View
- Set Projection Mode
- Pick Rotation Center

## **Top View**

**Brief**: Set camera to top view. View data from +z to -z direction. View plane: x-y plane.

### Steps

1. After clicking this button , current active window will be shown:



## **Bottom View**

**Brief**: Set camera to bottom view. View data from -z to +z direction. View plane: x-y plane.

### Steps

1. After clicking this button , current active window will be shown:



### **Left View**

**Brief**: Set camera to left view. View data from -x to +x direction. View plane: y-z plane.

### Steps



## **Right View**

**Brief**: Set camera to right view. View data from +x to -x direction. View plane: y-z plane.

### Steps



## **Front View**

**Brief**: Set camera to front view. View data from -y to +y direction. View plane: x-z plane.

### Steps



### **Back View**

**Brief**: Set camera to back view. View data from +y to -y direction. View plane is x-z plane.

### Steps

1. After clicking this button , current active window will be shown:



## **Front Isometric View**

**Brief**: Set camera position to front 45 degrees of X-Y plane.

### Steps

1. After clicking this button , current active window will be shown:

FRONT



## **Back Isometric View**

**Brief**: Set camera position to back 45 degrees of X-Y plane.

### Steps

1. After clicking this button , current active window will be shown:

BACK



# **Set Projection Mode**



Brief: Select projection mode(orthographic/perspective).

### Steps



1. After clicking this button , the option of projection mode is popped up. If Orthogonal Projection is selected, current active window will be set in orthogonal projection. If Perspective Projection is selected, current active window will be set in perspective projection.

X	T	Orthogonal Projection
0	T	Perspective Projection

### Settings

- Shortcut Key: F3
- Note: This tool is only for viewer in 3D mode.

## **Pick up Rotation Center**

#### Summary

Pick up rotation center in 3D viewer.

### Steps

Click button on left toolbar, move mouse on the viewer currently activated. And the mouse cursor changes into -<sup>1</sup><sub>1</sub>-, pick up a point and this point will become new rotation center. Then the cursor will restore as arrow shape. Press "Shift" to reset rotation center.



Note: This function is only available in 3D viewer.If users want to cancel current rotation center, please click Top View, Bottom View, Left View, Right View, Front View, Back View or Global View.

# **Operation Tools**

The operation toolbar contains tools to control view operations.

- Full Extent
- Zoom In
- Zoom Out
- Pan
- Go To

## **Full Extent**

**Brief**: This tool is applicable to all data types supported by LiPowerline. It makes all the data cover the entire window in top view and provides full view of all the data.

### Steps

- 1. Click the window that contains data with the left mouse button and set it as the active window.
- 2. Click the button so on the toolbar. All the data in the active window will be scaled automatically to cover the entire window, as shown below.



Note: When there are multiple windows, this tool only works on the active window.

# **Setting Tools**

Basic settings for viewers.

- Configure Point Size
- 2D View
- 3D View
- Capture Image
- Cross Selection
- Window Linkage
- Rolling Screen
- Display Options
- Camera Setting
- Manipulator Setting
- Shortcut Key Settings
- Camera Roam
- Configuration File Operation

# **Configure Point Size**

**Brief**: Configure point size and type.

### Steps

Configure Po	int Size	×
🗌 Circular Poin	ts	
💿 Fixed Size: 🕯	2 🔿 Point Autos	ize
. 4 <b>. 1</b> .		
		שו

2. Configure point size and type.

### Settings

- **Circular Points**: Determine point type. If checked, point will be rendered as circle, otherwise, point will be rendered as square.
- **Fixed Size**: If checked, point size would be fixed. User can adjust point size using the slider below (range 0-50 pixels).
- **Point Autosize**: If checked, point size is auto changing based on the depth of the viewer.

Note: This function is global. If user wants to configure a single point cloud, just right-click it, select Configure Point Size and Type from the context menu.

## 2D View

2D Brief: Switch current active window to 2D mode.

### Steps

1. After clicking this button, current active window will switch to 2D mode, as shown below:



Note: If current active window contains raster data, it can only be set to 2D mode. After removing raster data, it can be set to 3D mode.

## **3D View**

3D Brief: Switch current active window to 3D mode

### Steps

1. After clicking this button, current active window will switch to 3D mode, as shown below:



Note: If current active window contains raster data, it can only be set to 2D mode. After removing raster data, it can be set to 3D mode.

## **Capture Image**

**Brief**: Save the view in current window as a JPG file.

### Steps

1. Click this button, open save file dialog, default file name is window name, click "OK" to save file.



## **Cross Selection**

**Brief**: Cross select partial point cloud using ROI. This function can be used for flood analysis and other applications.

### Steps

1. Click *Tool* > 式 Cross Selection to open the dialog shown below:

V Show ROI		-	
ROI			
Xmin 322500.00	👙 Xmax	322999, 99	
Ymin 4102000.00	) 🔶 Ymax	4102499.99	
Zmin 2488.76	🚖 Zmax	2676.52	*
Shift ROI			
+X	+¥	+z	
-x	-¥	z	
		118	

- 2. Click button 🦛 to reset ROI.
- 3. Click button is to export point cloud inside the ROI to a new LiData File.
- 4. Click button  $\times$  to exit cross selection.
- The whole display effect is shown below. Drag the blue, green ,or red rectangular interactor in the viewer to adjust the size of the ROI. Drag the blue, green ,or red spherical interactor to adjust the orientation of the ROI.



### Settings

- **Prerequisite**: Current viewer contains point cloud.
- Show ROI: Show or hide ROI.
- **ROI**: Adjust the minimum and maximum X, Y, Z of the ROI.
- Shift ROI: +X, +Y, +Z means to move the ROI to the X, Y, Z positive direction for a default distance. -X, -Y, -Z means to move the ROI to the X, Y, Z negative direction for a default distance.

Note: This function is for all point clouds in the current viewer.

## Window Linkage

**e**-1

Brief: Enable windows linkage of multiple viewers.

#### Steps

1. Click *Tool* > Window Linkage to open the dialog shown below:

indows List	Linkaged Windows	
Viewer-0 Viewer-1 Viewer-2	>>>	
	All>>	
		E Cross I

- 3. If "Cross Line" is checked, cross line will be displayed in the linkage windows. The following figure shows if the cross line is checked:


Note: If the current window contains raster data, it will be displayed in 2D. If the linkage windows contain 3D window and 2D window, the windows will be displayed in 2D mode.

# **Rolling Screen**



Brief: Enable rolling screen for current viewer.

#### Steps

1. Click *Tool* > *Rolling Screen* to open the dialog shown below:

mrent Files		Rolling Screen Files	
D:/aa/LiForest_DEM_Convert Image to LiModel.Lif	>>>>	D:/aa/LiForest1.LiData	
	A11 >> ]		
	]		
۰ m +			

- 2. Current files list contains files in current viewer. Double-click a file that needs to be added to rolling screen, or select files and then click >>>>, or click button All>>> to add all files to rolling screen files. The rolling screen files list contains files in rolling screen, double-click a file to remove, or select files and then click button
- 3. Click "OK". In the viewer, press the "Shift" button on the keyboard then drag. The window is shown below:



### Settings

• Prerequisite: An active viewer.

Note: This function cannot be apply to the profile window. Click this button again to exit.

# **Display Options**

**Brief**: Configure background color, label properties and lights.

## Steps

1. Click this button to open the dialog shown as below:

		×
Colors		
Background		
Labels		
Light		
Default All		0K

2. Click "Colors" page to set background color:

				4
Hue:	240	Red:	0	
Hue: Sat:	240 255	Red: Green:	0	
Hue: Sat: Val:	240 255 255	Red: Green: Blue:	0 0 255	

Click "Labels" page to set label color and size:

Bisplay Options		6
Colors		
Labels		
Label background color	Labels font size 2	20 🤹
Marker color	Labels marker size	10 🚖
Light		

After creating any tag, user can move it by dragging. Push "Delete" key on the keyboard to delete selected tags.



4. Click "Light" page to set the direction of light. Light settings only effect on model files (LiModel, LiTin, OSGB, etc.).

🚭Display Options	(
Colors	
Labels	
Light	
Azimuth:	
Altitude:	45.00°
	💟 Light On
Default 411	OR
	UN

5. Click "Default All" to restore all settings to default values.

# **Camera Setting**

**Brief**: Camera settings for current active 3D window.

## Steps

1. After clicking this button, the dialog shown below would pop up:

			-117.9°	4
			35.0°	1
	-0		-12.5°	
Rotation Cente 588.722046	er 🙆	Camera/1 809.11664	Eye Center	*
304. 345123	-	~702.59639	95	4 7
469.308990		845.83405		4 ¥

- 2. Adjust camera rotation using sliders.
- 3. Click  $\bigcirc$  to pick a point as rotation center.



### Settings

- **Prerequisite**: Current active window must be in 3D mode.
- **Current mode**: Show projection type of current active window, including perspective projection and orthogonal projection.
- X: Camera rotation around X axis.
- Y: Camera rotation around Y axis.
- Z: Camera rotation around Z axis.
- Rotation Center: Rotation center, which could be picked from viewer.
- Camera/Eye Center: Non-editable, computed using rotation.
- Field of view: Field of view, default 30 degree.
- **Distance**: Distance to viewpoint. Non-editable.

# **Manipulator Setting**

**Brief**: Set the mouse sensitivity.

### Step

1. Click the > button on the left toolbar of the software interface, and then click the 🕑 button in the pop-up menu to open the following interface:



### **Parameter Settings**

• Select Sensitivity: The sensitivity is divided into levels 1, 2, and 3, with higher levels indicating higher sensitivity. The default level is 1.

## **Shortcut Key Settings**

**Brief**:Set shortcut keys for common functions. Select the function for which you want to set the shortcut key and click the keyboard to set the shortcut key.

	Operation Name	Shortcut	
1	Import Data	Ctrl+Shift+O	
2	New Window	CTRL+F3	
3	Close Window	CTRL+F4	
4	Exit LiPowerline	Alt+F4	
5	Full Screen	F11	
6	Orthogonal/Perspective Projection	F3	

- Clear Current: Clear the shortcut key Settings for the currently selected function.
- Clear All: Clear shortcut key Settings for all functions.
- Default: Restore default shortcut key Settings.

Note: Some shortcut keys are already used for specific operations, please set other keys.

# Camera Roam

**Brief**: This function can control the scene camera to navigate through a roam path. Two types of roam path are supported including roam path based on viewport and roam path based on POS file. This function can also generate immersive video if cooperated with Save to Video function.

## Steps

1. Click *Disply > Camera Roam* to open Camera Roam Set dialog as bellow.

Viewer-O				
Speed: 1.000 🗘				
🖉 Roam by Viewports ———				
			T	5.0.
			1	-
			1	
			1	14
				1
			1	
Roam by Pos Path				
Show Path	Path Wie	lth: 0	÷	
Restore Original State	Top	View Roa	n -	
			133	
Pos Path:				

- 2. Choose mode as desired(Select "Roam by Viewports" or "Roam by Pos Path").
  - 2.1 Roam by Viewports
    - Add Key Frame: Click this button to add current viewport as a key frame.
    - Delete Key Frame: Click this button to delete a key frame.
    - Load Key Frames from File: Click this button to import a key frame file.
    - Save Key Frames to File: Click this button to export all key frames to file.
    - XDelete All Key Frames: Click this button to delete all key frames.

- Select a key frame in the list: Scene camera will be adjusted to this key frame.
- 2.2 Roam by POS File
  - Check or uncheck "Show Path" as desired.
  - Set the Path Width, which will be activated when "Show Path" is checked.
  - Click "Restore Original State" to return to the first control point.
  - Select "Top View Roam" or "Front View Roam" as desired.
  - Click Settings to open the following dialog.

ile Name:			(SH-40
Work Path Set			
X Offset	651944.75	A V	
¥ Offset	2977078.97	*	
Z Offset	82.91	* *	
Time Step	1.00	*	
Yaw	0.00°	* *	(Tips: Camera Default State)
Pitch	0.00°	*	-z: View Dir Yaw (+z) +x: Right Dir Pitch (+x)
Roll	0.00°	* *	+y: Up Dir Roll (+y)

- Select a POS File: txt format only, each line of the file represents a key frame. The first three columns are assumed to be XYZ. Column delimiters include comma, semicolon and space.
- Set parameters: Including offset, time step, yaw, pitch, roll.
- Click "Ok" to end the roam path setting.
- 3. Click "Start Roam" to begin roam through current path. After finished, the following dialog will show.



- 4. Click "Ok" to end the camera roam.
- 5. Click "Cancel" to exit this function.

### Settings

• Input: Viewport of current window or POS file.

- Settings of Roam by POS file:
  - Path Width: Non negative integer only, defines the line width of POS trajectory in the viewer.
  - **X/Y/Z Offset**: The default value will be the offset of scene coordinate to the world coordinate system, as POS data is in the world coordinate system.
  - **Time Step**: real number larger than 0.01 only, defines the time interval between key frames. The smaller this value is, the slower the roaming speed is.
  - Yaw/Pitch/Roll: Local roam coordinate is defined that the origin is key frame center, the Y axis points to the motion direction, the X axis is defined based on Y axis and world coordinate Z axis using right-hand coordinate system principle, the Z axis is defined based on X axis and Y axis using right-hand coordinate system principle. By default, the roam camera is towards -Z, the right of camera is +X, the upper of camera is +Y. Yaw means spinning around +Z. Pitch means spinning around +X. Roll means spinning around +Y.

# **Configuration File Operation**

100

Brief: View and change the camera settings of the currently active 3D view.

#### Step

1. Click the > button on the left toolbar of the software interface, and then click the button in the pop-up menu to open the following interface:



### **Parameter Settings**

- Save Configuration File As: Save all configuration files to another folder.
- Import Configuration Files: Import configuration files from the selected folder.
- Delete Configuration Files: Delete configuration files.

# **Measure Tools**

The measure tools are used to measure geometric information about the data.

- Pick Point
- Multi Pick Point
- Length Measurement
- Area Measurement
- Angle Measurement
- Height Measurement
- Volume Measurement
- Density Measurement

## **Pick Point**

**Brief**: This tool is applicable to point cloud data, raster data and model data. For point cloud data, the attributes that can be queried contain position, intensity, return number, classification and GPS time. For raster data, the attributes that can be queried contain position, stretched RGB value and pixel value.

### Usage

Click Point Cloud > Measurement > Point

### Steps

 Click a valid point in the scene and a label that displays the point attributes will pop up. If the point belongs to point cloud data, then the label will show the position, intensity, return number, classification and GPS time, as is shown below. If the point belongs to raster data, then the label will show the position, stretched RGB value and pixel value.



Click the right mouse button, two context menus will pop up. The menu "Clear Measure" is used to clear the selection result. The menu "Quit Measure" is used to exit the pick point function.

Note: This tool only works with point cloud data, raster data and model data. It's available in the profile window too.

## **Multi Pick Point**

**Brief**: This tool is applicable to point cloud data, raster data and model data. For point cloud data, the attributes that can be queried contain position, intensity, return number, classification and GPS time. For raster data, the attributes that can be queried contain position, stretched RGB value and pixel value. Different from the pick point tool, this tool allows querying multiple points at the same time, and the selection set can be exported in \*.txt format.

### Usage

Click Point Cloud > Measurement > Points

### Steps

 Left-click the points in the scene and the selection results are marked by labels. At the same time, a table that contains the attributes of the selection points will pop up, shown as follows. The attributes of point cloud data shown in the table contain index, position (XYZ), classification, return number, GPS time and intensity. The attributes of raster data shown in the table contain index, position (XY) and band value. The total number of the points is updated real-time above the table.

	Index	X	Y	Z	assificati	Return	Time	Intensity
0	Point #1	66683	27149	464.99	5	1	20201	157.00
1	Point #2	66686	27149	476.08	5	1	20201	157.00
2	Point #3	66686	27149	450.12	5	1	20201	157.00

- 2. The "marker size" is used to set the point size of the marker in the scene. The "start index" is used to set the start index of the selected points.
- 3. Double-click a row of the table, the scene will go to the position of the corresponding point automatically.
- 4. Select a row of the table by left-clicking and click the button  $\times$  to delete the point.
- 5. The selection set can be exported as \*.txt format. Click the drop-down menu 📑 to pop up "Select Format" dialog, as shown below. If the selected points belong to raster data, then the menu "Save 2D points" is available. If the selected points belong to 3D data, then the menu "Save 3D points" is available. If the selected points contain 2D data and 3D data, then the menu "Save all points" is available.

🗸 X	У У	🗹 Z	
🗸 Classification	🗹 Return	🗹 Time	
🗹 Intensity	🗹 Index	🔄 Band	value
🗌 Latitude	📃 Longi tude		
			e F
Projection Coordin	ate System(Optional	.): []	
Projection Coordin Output Path: kfile	ate System(Optional :/data/test/picking	.): _list. txt ]	***

- 6. Click to pop up the export dialog. Input the output path, and check the attributes that need to be exported. Click "OK" to complete the export. Click "Cancel" to cancel the export.
- 7. If the selected points have not been saved before quitting this tool, a message box will pop up as follows. Click "Save" to save the points. Click "Discard" to cancel the selections.



#### Settings

- X: X component of the coordinate.
- Y: Y component of the coordinate.
- **Z**: Z component of the coordinate.
- Classification: The class attribute of point cloud data.
- Return: The return number attribute of point cloud data.
- **Time**: The GPS time attribute of point cloud data.
- Intensity: The intensity attribute of point cloud data.
- Index: The index of select point.
- BandValue: The band value of raster data.
- Output Path: The path of the output file.

Note: This tool only works with point cloud data, raster data and model data. If the center of rotation needs to be changed, hold down the the Ctrl key and select the center of rotation with the left mouse button. This tool is available in the profile window too.

# Length Measurement

**Brief**: This tool is applicable to point cloud data, raster data and model data, which calculates the distance between two consecutive points.

#### Usage

Click Point Cloud > Measurement > Length

#### Steps

1. Left-click at least two points in the scene and the corresponding polyline will be rendered real-time. The measurement result is displayed in a label as follows. Double-clicking the last point will stop the measurement process, and the distance value will continue to be displayed in the label.



Click the right mouse button, three context menus will pop up. The menu "Back One Point" is used to go back to the previous step. The menu "Clear Measure" is used to clear the measurement result. The menu "Quit Measure" is used to exit the measure tool.

Note: This tool only works with point cloud data, raster data and model data. The "Back One Point" is only available before the measurement is stopped. This tool is available in the profile window, too.

## Area Measurement

**Brief**: This tool is applicable to all data types supported by LiPowerline, which calculates the projected area within the polygon region. Current window will switch to Orthogonal Projection automatically for 3D data.

### Usage

Click Point Cloud > Measurement > Area

### Steps

 Left-click at least three points in the scene and the corresponding polygon area will be rendered real-time. The measurement result is displayed in a label as follows. Double-clicking the last point will stop the measurement process, and the measurement result will continue to be displayed in the label.



Click the right mouse button, three context menus will pop up. The menu "Back One Point" is used to go back to the previous step. The menu "Clear Measure" is used to clear the measurement result. The menu "Quit Measure" is used to exit the measure tool.

Note: This tool only works under orthogonal projection. The "Back One Point" is only available before the measurement is stopped.

# **Angle Measurement**

Brief: This tool is applicable to point cloud data, raster data and model data, which calculates the angle of pitch between two points in 3D view and calculates the projection angle of three points on the horizontal plane in 2D view.

## Usage

Click Point Cloud > Measurement > Angle

## Steps

- 3D View:
  - 1. Select the reference point of angle measurement by left-clicking.
  - 2. Select the measurement point by double-clicking. The pitch angle between the reference point and the measurement point will be rendered in the scene and the measurement result is displayed in a label as follows.



- 2D View:
  - 1. Select the first point of angle measurement by left-clicking.
  - 2. Select the second point of angle measurement by left-clicking.
  - 3. Select the third point of angle measurement by double-clicking. The projection angle of the three points on the horizontal plane will be rendered in the scene and the measurement result is displayed in a label as follows.



Click the right mouse button, three context menus will pop up. The menu "Back One Point" is used to go back to the previous step. The menu "Clear Measure" is used to clear the measurement result. The menu "Quit Measure" is used to exit the measure tool.

Note: This tool only works with point cloud data, raster data and model data. The "Back One Point" is only available before the measurement is stopped. The tool is available in the profile window too.

# **Height Measurement**

**Brief**: This tool is applicable to point cloud data and model data, which calculates the relative height difference between two points.

#### Usage

Click Point Cloud > Measurement > Height

#### Steps

- 1. Select the reference point of height measurement by left-clicking.
- 2. Select the measurement point by double-clicking. The relative height difference between the reference point and the measurement point will be rendered in the scene and the measurement result is displayed in a label as follows.



Click the right mouse button, three context menus will pop up. The menu "Back One Point" is used to go back to the previous step. The menu "Clear Measure" is used to clear the measurement result. The menu "Quit Measure" is used to exit the measure tool.

Note: This tool only works with point cloud data and model data. The "Back One Point" is only available before the measurement is stopped. The tool is available in the profile window too.

# **Volume Measurement**

**Brief**: This tool is applicable to point cloud data and model data, which calculates filling, cutting and total amount relative to a reference height. It's commonly used in volume measurement of coal pile and hull.

#### Usage

Click Point Cloud > Measurement > Volume

#### Steps

 It is suggested to adjust the window to top view before the tool is used. Select at least three points to generate the reference plane for volume calculation by left-clicking. Select the last point by double-clicking. The border of the selected region will be rendered in red and the dialog "Volume Measure" will pop up.



- 2. Set the cell size.
- 3. Set the reference plane of volume measurement. The options include minimum value, mean value and custom value.
- 4. Click the "Compute" button to generate the measurement result. The corresponding volume will be rendered in the scene, as shown below.



5. Click the "Export" button to export the result in \*.pdf or \*.txt format.

## Settings

- Cell Size: It defines the smallest unit size for calculation. The smaller the value is, the more accurate the calculation is.
- Basic Height: It defines the reference plane to calculate filling and cutting.
  - Minimum (Default): Use the minimum height of the selected points as the height of the reference plane.
  - Mean: Fit the best plane according to the selected points.
  - **Custom**: This value is specified by the user.

Note: This tool only works with point cloud data and model data in 3D view.

# **Density Measurement**

**Brief**: Point density is an important metric to measure the quality of point cloud data. The average number of points per square meter can be counted with this tool.

#### Usage

Click Point Cloud > Measurement > Density

#### Steps

- 1. Active window is adjusted to orthogonal projection automatically when this tool is started. Then the dialog "Density" pops up.
- 2. If the option "Width" is checked, the width value can be manually input, and the height value will be set to the same as the width value, then the area value will be decided by "Width" and "Height". The measurement region can be selected by left-clicking.
- 3. If the option "Width" is unchecked, the width value and the height value will be decided by the size of the rectangle that is drawn interactively by left-clicking the upper left corner and the lower right corner. The area value will be decided by "Width" and "Height". The rectangle will be rendered in the scene and the measurement result is displayed in a label as follows.



#### **Settings**

- Width: It defines the width of the reference rectangle.
- Height: It defines the height of the reference rectangle.
- Area: It defines the area of the reference rectangle.

Note: This tool only works with point cloud data and model data under orthogonal projection.

# Model Display

Set the display mode of models in current active window.

- Show Model
- Show Triangle
- Show Point

## **Show Model**

**Brief**: Set model files in the current window to display in model type.

## Steps

1. Click this function, the models in the current active window will display in model, as shown in the figure below:



## Settings

• Shortcut key: Press the "W" key to switch the display mode between model, triangle and point.

Note: The model types for this function includes LiTIN, LiModel, IVE and other model types.

# **Show Triangle**

**Brief**: Switch display mode of models in current window to triangle mesh mode.

### Steps

1. Click this button, the models in current active window will display as triangle mesh, as shown in the figure below:



### Settings

• Shortcut key: Press the "W" key to switch the display mode between model, triangle and point.

Note: The model types for this function includes LiTIN, LiModel, IVE and other model types.

# **Show Point**

**Brief**: Switch display mode of models in current window to point mode.

### Steps

1. Click this button, the models in current active window will display as points, as shown in the figure below:



## Settings

• Shortcut key: Press the "W" key to switch the display mode between model, triangle and point.

Note: The model types for this function includes LiTIN, LiModel, IVE and other model types.

# **Profile Tools**

The profile window provides many tools for users to observe, measure, and even change data properties from specific angles, such as modifying the category of point cloud data.

### **2D Profile**



After enabling this function, the origin cloud display window will be fixed in top view mode and support users to arbitrarily delineate a rectangular area in the window. After determining the delineated area, a side view of the area will be displayed in an independent section window, where users can select the tools in the top toolbar to operate on point cloud data. Close the independent window to exit 2D section editing. The 2D section editing view is shown in the following figure.



### **3D Profile**

13D

After enabling this function, a toolbar will be displayed at the top of the origin cloud display window, and you can directly operate on point cloud data in the selection area of the window. Click on the far right corner of the top toolbar to exit 3D profile editing. The 3D section editing view is shown in the following figure.



## **Top Toolbar**

In the process of point cloud processing, due to the limitations of automatic algorithms, many functions cannot fully meet the requirements. In this case, the profile function can be used to manually edit point cloud data. The tools at the top of the profile window are as follows.

- Auto Hide
- Profile
- Auto Save
- Views
- Measure Tool
- Automatic Profile
- Manual Classify
  - Settings
  - Polygon Selection
  - Rectangle Selection
  - Circle Selection
  - Polyline Above Selection
  - Polyline Below Selection
  - Continous Brush
  - Save Results

Cancel

### **Profile and Angle/Height Measurement Tool**

Angle Measurement, Height Measurement and Pick Point are available in Profile window.

## **Profile and Strip Alignment**

When doing strip alignment, users need to check data misalignment among strips caused by Heading/Pitch/Roll angles.

For example, the picture below shows the data misalignment before doing strip alignment.



During the strip alignment process, users can check alignment effect by setting different parameters in profile window.



When users are happy with alignment effect in profile window, the point cloud can be transformed according to the current parameters and written directly to disk.

Besides, users can use measurement tools in profile window to help adjusting Heading/Pitch/Roll angles. Please refer to Strip Alignment for detailed information.

### **Profile and Powerline**

In powerline module, users need to classify point cloud into different classes, such as tower, conductor, dangerous point, vegetation etc. Limited by auto classification algorithm, manual editing is necessary for higher accuracy.

After clipping and classifying the powerline data, users can check and modify classification result in profile window.



# Auto Hide

Hide Profile Toolbar.

## Steps

- 1. **(Optional)**Click to hide profile toolbar automatically.
- 2. (Optional)Click I to fix toolbar.

Note: When Auto Hide function is prohibited, the toolbar will be floating on the top of profile window. In contrast, the toolbar will hide after a few seconds and appear again when cursor moves to the top. This function is especially suitable for small screen and tight space.

# Profile

### Summary

Under the 3D profile editing function, an area can be delineated and only the point cloud of that area can  $\sim$  be displayed in the window.

### Steps

- 1. Click / profile.
- 2. After clicking the left mouse button to confirm the endpoints in the section window (please confirm at least three endpoints), double-click the left mouse button to delineate the area, as the picture below.


# **Auto Save Settings**

#### Summary

The time interval can be set to automatically save the executed operations for point cloud classification. Note: All operations for point cloud classification are temporary and must be saved before they can take effect.

### Steps

1. Click Display the automatic save settings interface, as shown in the following figure.

Auto Save Settings	×
Auto Save Time Interval: 5.00 min	\$
Default	OK

2. Check "Auto Save" and set a time interval before clicking "OK". The default time interval is 5.00 minutes.

### View

#### Summary

Unlike general 3D viewer, the profile window does not support rotation by default. There are four views can be chosen: front view, back view, left view and right view.

#### Steps

- 1. By default, the profile window shows the front view of selection area. Users can click drop-down menu to change the view.
- 2. (Optional)Click to choose front view.
- 3. (Optional)Click to choose back view.
- 4. (Optional)Click to choose left view.
- 5. (Optional)Click to choose right view.

Note: If users are interested to view selection area from other view, they can click  $\bigoplus$  to activate rotation function in profile window. After activation, users can rotate the selection area by any random angle.

# **Measurement Tool**

#### Summary

Different from the general measurement, the default is the orthogonal projection in the profile window.
After clicking two points, users can easily calculate the horizontal and vertical distances in the current view. When rotation function in the profile window is not enabled, the frustum axis is always vertical to the Z axis and parallel to the horizontal plane. The vertical and horizontal distances under this condition can be very useful in some scenarios. For example, users can use this information for parameter estimation before strip alignment.

#### Steps

- 1. Left click to pick up the first end point.
- 2. Move mouse and double click to pick up another end point.

# **Automatic Profile**

#### Summary

Under the 2D profile editing function, the point cloud is automatically cut based on the starting and ending tower numbers.

#### **Steps**

1. Click Display the automatic segmentation profile interface, as shown in the following figure.

Automatic	Profi	Le	-	8	×
Buffer		🕜 👎			
Angle 5	2	2			
Start Ind	ex:	1			]
End Index	:	2			]
Segment B	iffer	15			Ï
	Prev (Ho	ous Tower t Key: <)	Next Tower (Hot Key: >)		
	Previ (Hot	ous Section Key: PgUp)	Next Section (Hot Key: FgDn)		

- 2. Set the start index, end index, and segment buffer of the tower.
- 3. (Optional) The previous section/next section can directly cut the entire tension section line.
- 4. (Optional) The previous tower/next tower will only be cut for the next section.
- Buffer 5. (Optional)

Fixed selection area width. Users can fix the width to move the position of the selection area. Click on the circular checkbox on the left to turn it solid. After setting the width value (in meters), click 1 to move the selection area forward with a fixed width, click 4 to move the selection area back with a fixed width.



Rotate the selection area. Users can rotate the selection area at a fixed 6. (Optional) angle. After setting the angle value (angle system, between -360~360), you can click 20 to rotate the selection area.

### **Manual Classification**

#### Summary

Most of the tools provided by the profile window are integrated on the toolbar. These tools can be used for manual classification.

#### Steps

1. Click *is to set From Class and To Class*.

0-Never Classified	1-UnClassified
🔄 2-Ground	3-Low Vegetation
4-Medium Vegetation	🔲 5-High Vegetation
6-Building	🗌 7-Noise
🜅 16-Conductor	🔲 17-Structure
🛅 18-Scissors Crossing Up	🗌 19-Scissors Crossing Down
20-Shield Wire	🔲 Select All

By default, the classes are arranged in the LAS white paper. Users can also select a class and click the button on the right side of the interface to adjust the order:  $\bigcirc$  Up  $\bigcirc$  Down  $\bigcirc$  Top  $\bigcirc$  Bottom Users can also double click the class and rename it(Not including specific classes 0-8).

1. Choose a suitable selection tool and classify manually:

Polygon: Suitable for random polygon or complex concave polygon. For example, a tree or a building. Use Parity Ruleto check if the feature is selected.

Rectangle: Suitable for features with simple shapes. Compared to polygon selection, the edges of a rectangular selection can only be parallel to the corresponding edges of the window.

Circle: Circle selection is convenient for some circumstances. For example, a circle pool.

- Above Polyline: Point clouds above the polyline will be selected.
- Below Polyline: Point clouds below the polyline will be selected.
- 2. (Optional)Press hot key Ctrl+Z to undo last operation. Or click 🔀 to clear all temporary operation.
- 3. After all class modifications are done, click  $H_{M}$  to save the modification.

Note: After the algorithm automatically classifies, manual inspection is required to ensure accuracy.

Note: All operations related to point cloud classification are temporary and must be saved before they can take effect.

# **Select Tools**

+×														LiPower	line						
Point Clou	ud linini	iuting Br	trock Insp	pection		ul Realt	ine Conditio	n Vertor S	ealtine Co	udi ti m	Similatio	m Condition	Congletion (	Superiore	Pine Inspects	ice Plugi					
Add Deta 1	Add and Merge Data	Celece Data	Open Project	Save Project	Point	Length	Height Roints	Angle	2D Profile	SD- 3D Profile	Class Order	Start/End	😤 Polygon 🔍 Rectangle 🌑 Sphere	Subtract	Cancel	Viewers	Render + Language + Display +	Windows	Recet	Import	Activate Help About
		Data				5.5	easurement		Profil	e Classifie	ration		Point Clos	d Cutting		Viewets	Display	Windows		Help	

Select and save point clouds in interest area.

- Polygon Selection
- Rectangle Selection
- Sphere Selection
- Subtract Selection
- In Cut
- Out Cut
- Save Cut Result
- Cancel Selection

# **Polygon Selection**

**Brief**: Select point cloud data in polygon area.

### Usage

Click Tool > Cut Point Cloud > Polygon Selection

#### Steps

- 1. Click the Polygon Selection button to activate this function (Click again if you want to deactivate it).
- 2. Add polygonal vertices by left click. At least 3 vertices are needed to form a closed loop.



- 3. (Optional) Delete added vertices in reverse order by right click, if some of them are unwanted.
- 4. Left double click to add the last vertex. The selected points in the polygon area are highlighted.



5. (Optional) Combine multiple selections.





6. **(Optional)** Remove unwanted points from the selected, if Subtract Selection is active. The removed points are no more highlighted.





Shortcut Key: Press Ctrl + Z to undo the selection operation.

Note: This function is only applicable to point cloud data.

# **Rectangle Selection**

**Brief**: Select point cloud data in rectangle area.

### Usage

Click Tool > Cut Point Cloud > Rectangle Selection

#### Steps

- 1. Click the Rectangle Selection button to activate this function (Click again if you want to deactivate it).
- 2. Add the first vertex by left click. Then move cursor to adjust rectangle size.



- 3. (Optional) Delete the first vertex by right click, if it's unwanted.
- 4. Left double click to add the second diagonal vertex. The selected points in the rectangle area are highlighted.



5. (Optional) Combine multiple selections.





6. (**Optional**) Remove unwanted points from the selected, if Subtract Selection is active. The removed points are no more highlighted.





Shortcut Key: Press Ctrl + Z to undo the selection operation.

Note: This function is only applicable to point cloud data.

### **Sphere Selection**

**Brief**: Select point cloud data in sphere.

### Usage

Click Tool > Cut Point Cloud > Sphere Selection

#### Steps

- 1. Click the Sphere Selection button to activate this function (Click again if you want to deactivate it).
- 2. Add the center point of sphere by left click. Then move cursor to adjust radius.



- 3. (Optional) Delete the center point by right click, if it's unwanted.
- 4. Left double click to confirm the radius. The selected points in the sphere are highlighted.



5. (Optional) Combine multiple selections.





6. **(Optional)** Remove unwanted points from the selected, if Subtract Selection is active. The removed points are no more highlighted.





Shortcut Key: Press Ctrl + Z to undo the selection operation.

Note: This function is only applicable to point cloud data.

### **Subtract Selection**

**Brief**: This function is effective on one of the geometric selection tools (Polygon Selection, Rectangle Selection or Sphere Selection). If *Subtract Selection* is **inactive**, more points can be added to the currently selected. If **active**, unwanted points can be removed from the currently selected.

#### Usage

Click Tool > Cut Point Cloud > Subtract Selection

#### Steps

- 1. Activate one of the geometric selection tools (Polygon Selection, Rectangle Selection or Sphere Selection) before using *Subtract Selection*. Then please activate/deactivate *Subtract Selection* by left click.
- 2. (Optional) If Subtract Selection is inactive, multiple selections can be combined.







3. (Optional) If Subtract Selection is active, unwanted points can be removed from the currently selected.





**Shortcut Key**: Press **Ctrl + Z** to undo the last operation. Note: This function is only applicable to point cloud data.

# In Cut

**Brief**: Cut point clouds after selection. The selected points are kept while the unselected are hidden.

### Usage

Click Tool > Cut Point Cloud > In Cut

#### Steps

1. Select points using Polygon Selection, Rectangle Selection or Sphere Selection. The selected points are highlighted.



2. Click the *In Cut* Button. The result is shown in the following figure.



3. (Optional) You can repeat this function several times to get the result you need.

**Shortcut Key**: Press **Ctrl + Z** to undo the cut operation. The corresponding selection is also cancelled.

Note: This function is only applicable to point cloud data.

# **Out Cut**

Brief: Cut point clouds after selection. The selected points are hidden while the unselected are kept.

### Usage

Click Tool > Cut Point Cloud > Out Cut

#### Steps

1. Select points using Polygon Selection, Rectangle Selection or Sphere Selection. The selected points are highlighted.



2. Click the Out Cut Button. The result is shown in the following figure.



3. (Optional) You can repeat this function several times to get the result you need.

**Shortcut Key**: Press **Ctrl + Z** to undo the cut operation. The corresponding selection is also cancelled. Note: This function is only applicable to point cloud data.

### **Save Cut Results**

**Brief**: Save results after cut operation as new point cloud files.

#### Usage

Click Tool > Cut Point Cloud > Save Cut Results

#### Steps

1. Click this button after successful cut operations(In Cut, Out Cut). An interface is shown as follows.

Image: Constraint of the system   380954.000_381045.344     Image: Constraint of the system   381150.400_381299.712     Image: Constraint of the system   381332.976_381496.560     Image: Constraint of the system   381598.920_381756.928	Z Select	File Name				
Image: Constraint of the second se		380954.000_381045.344.LiData				
381332.976_381496.560       381598.920_381756.928		381150.400_381299.712.LiData				
381598.920_381756.928		381332.976_381496.560.LiData				
		381598.920_381756.928.LiData				
Merge files		Merge files into o				

- 2. Select source point cloud files, from which new files are generated.
- 3. (Optional) Check/Uncheck the option "Merge files into one" according to demand.
- 4. Specify the output path. New file names are created based on the source file names and system time. An example of new file name is "SourceFileName\_CutResult\_SystemTime.LiData".
- 5. After data saving, a dialog will ask if you want to add the new files to current project.



6. Click Yes or No according to demand.

# **Cancel Selection**

**Brief**: Cancel all the selections and cut operations.

### Usage

Click Tool > Cut Point Cloud > Cancel Selection

#### Steps

1. Click this button after selections(Polygon Selection, Rectangle Selection, Sphere Selection) or cut operations(In Cut, Out Cut). All the selections and cut operations will be cancelled.

Note: This function is only applicable to point cloud data.

# **Project Management Window**

The data list in the project is managed by layers and windows separately.

- Layer Management
  - Point Cloud
  - Raster
  - Vector
  - Table
  - Model
- Window Management

Note: The data loaded into the project can be displayed in single/multiple window(s), or not displayed at all. Please drag data to a certain window for display.

# Layer Management

#### Brief

The **project layers** manage the data in the software by group, whose types include **Point Cloud**, **Raster**, **Vector**, **Table**, and **Model**.

- **Point Cloud**: Proprietary LiData File(\*.LiData), LAS File(\*.las,\*.laz), ASCII File(\*.txt,\*.asc,\*.neu,\*.xyz,\*.pts,\*.csv);
- Raster: Image File(\*.tif,\*.jpg);
- Vector: Vector File(\*.shp);
- Table: Table File(\*.csv);
- **Model**: Proprietary Model File(\*.LiModel), Proprietary TIN File(\*.LiTin), OSG Model File(\*.osgb,\*.ive,\*.desc,\*.obj);

In the **project layers** the user can remove data from the software, show/hide data in all windows by checking/unchecking the box before data node (or data type node). The data can be dragged from data node to different windows for display. The context menu (i.e. right-click menu) of data node, which differs depending on data types, is mainly used for data query, display, statistics, export, and removal, etc.

#### Click the fourthe button to show the project layers as follows:



#### **Context Menu**

Open the context menu by right clicking data type or data.

- Context menu of point cloud
- Context menu of raster
- Context menu of vector
- Context menu of table
- Context menu of model

Note: The context menu of layer management is effective on all windows, while the context menu of window management is only effective on specified window.

### **Point Cloud Context Menu**

#### Brief

The context menus are used to for data import, removal, query, display, statistics, export, etc.

### Data Type Context Menu

The user can open this menu by right clicking the point cloud data type.

- Import Data: The point cloud data formats supported by LiPowerline include LiData (\*.LiData), LAS (\*.las, \*.laz), ASCII (\*.txt, \*.asc, \*.neu, \*.xyz, \*.pts, \*.csv) and PLY (\*. ply). The LiData is the proprietary point cloud data format, on which the point cloud processing are based. Other imported formats of LAS, ASCII and PLY will be converted to LiData for subsequent processing. This function is the same as the tool Add Data.
- Remove All: Remove all the point cloud data from the project.

#### **Data Context Menu**

The user can open this menu by right clicking a point cloud data object.

• Info: View the basic information of point cloud data as shown below. Click the *Export* button to export the information as a \*.txt file.

	nate:							
X :	479000.000		Max X: 479999.990					
¥:	4619000.000		Max Y: 4619999.990					
. Z:	410. 410		Max Z: 588.430					
n Z	: 472.831		std Z: 16.435					
GP	PS Time: 0.000		Max GPS Time: 79871888.000					
In	tensity: 0.000		Max Intensity: 255.000					
n I	Intensity: 99.501		std Intensity: 60.632					
Di	mensions(X,Y,Z): (999.9	90,999.990,178.020)	Total Points Count: 401839	2				
1	rification Statistics	Raturn Number Statist	dan <sup>1</sup>					
las	ssification Statistics	Return Number Statist	ics					
las	sification Statistics Classification Name	Return Number Statist Value	ios Points Count	^				
1 as	classification Statistics Classification Name UnClassified	Return Number Statist Value 1	Points Count 371039	^				
1 as	classification Statistios Classification Name UnClassified Ground	Return Number Statist Value 1 2	i os Points Count 371039 1595090	Î				
1 as 1 2 3	Classification Statistics Classification Name UnClassified Ground Low Vegetation	Return Number Statist Value 1 2 3	i os Points Count 371039 1595090 344959	^				
1 as 1 2 4	Classification Statistics Classification Name UnClassified Ground Low Vegetation Medium Vegetation	Return Number Statist Value 1 2 3 4	i os Points Count 371039 1595090 344959 336781					
1 as 1 2 4	Classification Statistics Classification Name UnClassified Ground Low Vegetation Medium Vegetation Building	Return Number Statist Value 1 2 3 4 6	i os Points Count 371039 1595090 344959 336781 936785	Î				

• View Mode: Select the display mode of point cloud data between the following types.

• **Display by Height**: The interface is shown as follows. The value range of display can be stretched by minimum/maximum or standard deviation in order to improve the visual effects.



The curve can be saved in \*.pdf format. Click the button "Save Curve" to pop up the following interface. Set the width, height, resolution, output path of the curve and click "OK" button to save the curve to local disk.

Width	300	inch
Height	200	] inch
Resolutior	ι 300	] dpi

The visual effects are consistent with the tool **E** Display by Elevation.

• **Display by Intensity**: The interface is shown as follows. The value range of display can be stretched by minimum/maximum or standard deviation in order to improve the visual effects.



The curve can be saved in \*.pdf format. Click the button "Save Curve" to pop up the following interface. Set the width, height, resolution, output path of the curve and click "OK" button to save the curve to local disk.

l'aramete	rs	
Width	300	] inch
Height	200	] inch
Resoluti	on 300	] dpi
utput pat	h /1jw/data/Canvas.pdf	

The visual effects are consistent with the tool I Display by Intensity.

- **Display by Class**: This function is the same as the tool C Display by Class.
- **Display by RGB**: This function is the same as the tool **B** Display by RGB.
- Display by Return: This function is the same as the tool R Display by Return.
- **Display by Time**: This function is the same as the tool **T** Display by Time.
- **Display by TreeID**: This function is the same as the tool **ID** Display by TreeID.
- **Display by Selected**: Select user-defined color to display the point cloud data. The interface and the visual effects are shown below.



- **Display by Blend**: This function is the same as the tool **B** Display by Blend.
- **Display by Mix**: This function is the same as the tool M Display by Mix.
- Zoom to Layer: Calculate the bounding box of the current point cloud data. All the windows, in which the data object is loaded, will show full extent of the bounding box.
- **Restatistics**: Recalculate the *Mean Z*, *Std Z*, *Mean Intensity* and *Std Intensity* of point cloud data. This function is used to repair older versions of LiData which may contain incomplete information.
- Export: Export the point cloud data to LAS (\*.las, \*.laz), ASCII (\*.txt, \*.asc, \*.neu, \*.xyz, \*.pts, \*.csv) and PLY (\*.ply) format. This function is the same as the tool Export.
- PCV: Process the point cloud data with PCV to improve the visual effects.
- **Point Size**: The point size of each point cloud data object can be set separately or set uniformly according to the global settings. The shape of points can be set to circle or square. The interface is shown as follows.

F Spoint Size		×
Circular Points		
○ Specified set	🖲 Use global set	
	OK	

For global point size settings, see the usage of the tool Configure Point Size.

• **Remove**: Remove the selected point cloud data from the current project. This function is the same as the tool Kemove.

### Settings

- Display by Height:
  - Color Bar: The colorbar supports several uniformly varying color intervals for color mapping.
  - Stretch: The stretch methods of the histogram.
    - Minimum and Maximum (Default): Apply a linear stretch based on the minimum and maximum pixel values, with the minimum and maximum pixel values as the endpoints for the histogram. For example, the minimum and maximum pixel values of the image could be 2488 and 2656 respectively. The values can be stretched linearly between 0 and 255. Distributing pixel values over the entire histogram range, the brightness and contrast of the image are increased and features in the image are easier to distinguish.
    - Std deviation: Apply a linear stretch between the pixel values defined by the std deviation (n) value. For example, the minimum and maximum pixel values of the image could be 2488 and 2656 respectively. If the value of standard deviation (n) is defined as 2, then the values beyond 2 standard deviation become 0 or 255, the remaining values stretch between 0 and 255.
- Display by Intensity:
  - Stretch: The stretch methods of the histogram.
    - Minimum and Maximum (Default): Apply a linear stretch based on the minimum and maximum pixel values, with the minimum and maximum pixel values as the endpoints for the histogram. For example, the minimum and maximum pixel values of the image could be 2488 and 2656 respectively. The values can be stretched linearly between 0 and 255. Distributing pixel values over the entire histogram range, the brightness and contrast of the image are increased and features in the image are easier to distinguish.
    - Std deviation: Apply a linear stretch between the pixel values defined by the std deviation (n) value. For example, the minimum and maximum pixel values of the image could be 2488 and 2656 respectively. If the value of standard deviation (n) is defined as 2, then the values beyond 2 standard deviation become 0 or 255, the remaining values stretch between 0 and 255.
- Save Curve:
  - Width: The width of the saved curve.
  - Height: The height of the saved curve.
  - Resolution: The resolution of the saved curve.
  - Output path: The output path of the saved curve.
- Point Size:
- Circular Points (Optional): Set the shape of the point to circle or square.
- Specified set (Optional): Set the point size of the specified point cloud data separately.
- Use global set (Optional): Set the point size of the specified point cloud data with global settings.

## **Raster Context Menu**

#### Brief

The context menus are used to for data import, removal, query, display, etc.

### Data Type Context Menu

The user can open this menu by right clicking the raster data type.

- Import Data: The raster data formats supported by LiPowerline include TIF and JPG. The function is the same as the tool Add Data.
- Remove All: Remove all the raster data from the project.

### Data Context Menu

The user can open this menu by right clicking a raster data object.

• Info: View the basic information of raster data, including file path, description, X size, Y size, bands count, pixel size, invalid value of each band, projection, etc. The interface is shown below.

GC:/LiDAR360/data/Li	Forest_DBM. tif	3
Jescription:	GTiff	
Meta Infor:	GeoTIFF	
X Size:	260	
¥ Size:	260	
Bands Count:		
Origin:	322500.000005, 4102499. 93	
Pixel Size:	2,-2	
Band 1 No Data Value:	-9689	
Projection:	Kone	

• **Histogram**: View the histogram of the raster data, where the values of each band can be stretched separately. The raster data is displayed in gray color bar by default. Select an appropriate color bar in the combo box. Click the button "Apply", the raster data in the scene will be rendered according to the above settings, as shown below.



Select the stretch method and generate the corresponding histogram, as shown below.



The button "Default" is used to restore the default settings. The button "Recompute Histogram" is used to calculate all the pixel values of the raster data again. The sampling points are 250000 by default. When the pixel size of the raster data exceeds the value, the statistical results may be inaccurate, then this button is needed. The histogram can be saved in \*.pdf format. Click the button "Save Histogram" to pop up the following interface. Set the width, height, resolution, output path of the histogram and click "OK" button to save the result to local disk.

farameters		
Width	300	] inch
Height	200	] inch
Resolution	. 300	] дрі
utput path	/ljw/data/Canvas.pdf	

- Zoom to Layer: Calculate the bounding box of the current raster data. All the windows, in which the data object is loaded, will show full extent of the bounding box.
- Zoom to Native Resolution (100%): Display the raster data in 1:1 ratio according to the resolution of the raster data.
- **Remove**: Remove the selected raster data from the current project. This function is the same as the tool Remove.

#### Settings

- Histogram:
  - Stretch: The stretch methods of the histogram.
    - Minimum and Maximum (Default): Apply a linear stretch based on the minimum and maximum pixel values, with the minimum and maximum pixel values as the endpoints for the histogram. For example, the minimum and maximum pixel values of the image could be 2488 and 2656 respectively. The values can be stretched linearly between 0 and 255. Distributing pixel values over the entire histogram range, the brightness and contrast of the image are increased and features in the image are easier to distinguish.
    - Percent Clip: Apply a linear stretch between the pixel values defined by percent clip minimum and percent clip maximum. For example, the minimum and maximum pixel values of the image could be 2488 and 2656 respectively. Percent clip minimum and percent clip maximum values are 0.02 and 0.98, values less than 0.02 mean the values between 2488 and 2492, values more than 0.98 mean the values between 2652 and 2656, values between 2488 and 2492 become 0, values between 2652 and 2656 become 255, the remaining values are between 0 and 255.
    - Std deviation: Apply a linear stretch between the pixel values defined by the std deviation (n) value. For example, the minimum and maximum pixel values of the image could be 2488 and 2656 respectively. If the value of standard deviation (n) is defined as 2, then the values beyond 2 standard deviation become 0 or 255, the remaining values stretch between 0 and 255.
    - Histogram Equalization: Apply a non-linear stretch between the pixel values, redistribute the pixel values so that the pixel values in a certain range is approximately equal. This method works well when there are a lot of pixel values that are closely grouped together.

- Color Bar: The colorbar supports several uniformly varying color intervals for color mapping.
- BandList: Select a band from the band list to draw the histogram.
- Show all bands (Optional): Whether to show all bands.
- Save Curve:
  - Width: The width of the saved curve.
  - **Height**: The height of the saved curve.
  - Resolution: The resolution of the saved curve.
  - **Output path**: The output path of the saved curve.

## **Vector Context Menu**

#### Brief

The right button menu of vector data in the layer management tree mainly includes import and export vector data, it also contains information, show attribute table, zoom to layer, color by elevation, and display by selected for single vector data.

### Data Type Context Menu

• Import Data: The import data format is SHP (\*.shp), the same with the function  $\stackrel{l}{\leftarrow}$ , see Add Data. Import vector data generate by point cloud to contour, as shown below:



• Remove All: Remove all vector data from LiPowerline.

#### Data Context Menu

• Info: View the basic information of vector file, including file path, elements count and bounding box.

lement Number:	79			
eometry Type:	LineString			
ayer Extent:				
Min X:	322499.9375	Max X:	323000.0625	
Min Y:	4101999.75	Max Y:	4102500	

• Open Attribute Table: Displays the property sheet information of the vector data. The result is shown in the

#### figure:

	ID	Elevation	LineTune	LiesMidth	Color P	Color G	Color P	
	10	Elevation	LineType	Linevviduri	COIDER	Color G	COLOR B	
1	1	2490.00000000	basic	2	0	0	255	
2	2	2492.5000000	minor	1	255	255	0	1
3	3	2495.0000000	basic	2	0	0	255	
4	4	2497.5000000***	minor	1	255	255	0	
5	5	2500.0000000	major	3	255	0	0	
5	б	2502 5000000***	minor	1	255	255	D	
7	7	2505.0000000	basic	2	0	0	255	
8	8	2507.5000000	minor	1	255	255	0	
9	9	2510 00000000000000000000000000000000000	basic	2	0	0	255	
10	10	2512 5000000	minor	1	255	255	0	
11	11	2515.0000000	basic	2	0	0	255	
12	12	2517.5000000	minor	1	255	255	0	
13	13	2520.0000000***	basic	2	0	0	255	
14	14	2522.5000000	minor	1	255	255	0	
5	15	2525.0000000	major	3	255	0	0	
10	16	2527 500000000	2	4	255	255	0	

- Zoom to Layer: Calculates the bounding box of the current vector data, and all windows that contains this file will display globally in this bounding box range.
- Color by Elevation: Display the vector data by z value based on selected color bar.
- **Display by Selected**: Display the vector data in fixed color, as shown in the following figure:

🚭Display By Selected RGB						
Basic colors						Ì
	+					
Pick Screen Color						
		000	-	<b>n</b> 1.	055	121
Eustom colors	nu <u>e</u> :	300		<u>K</u> ed:	255	
	<u>S</u> at:	85	×	<u>G</u> reen:	170	×
	<u>V</u> al:	255	×	Bl <u>u</u> e:	255	*
Add to Custom Colors	<u>h</u> tml:	#ffa	aff			1
		0	K		Cance	1
		2		_		8 F



#### • **Remove**: Remove vector file from LiPowerline.

Note: Except "Import Data", the other function in context menu work on all windows that contains this vector file.

# **Tables Context Menu**

#### Brief

The right button menu of table data in the layer management tree mainly includes import and export table data, it also contains information, attribute, zoom to layer, and removal for single model data.

### Data Type Context Menu

• Import Data: The import data format is CSV(\*.csv). If click this function, pop-up the dialog, select data type as "Point" or "Circle", and set the specified field X, Y, Z, Diameter (if the data type is circle), and check whether to show labels.

ata Type Poin	ts	
Specify the F	ields	
x	x	•
Y	Ŷ	*
Z	Z	•
Show Lable	X	Ψ
Apply Select Para ata Type Circ	Apply All meter le	Cancel
Apply Select Para ata Type Circ Specify the F	r Apply All meter le ields	Cancel
Apply Select Para ata Type Circ Specify the F X	x Apply All meter le ields X	Cancel
Apply Select Para ata Type Circ Specify the F X Y	x Apply All meter le ields X Y	Cancel
Apply Select Para ata Type Circ Specify the F X Y Z	<pre>x Apply All meter le ields X Y Z</pre>	Cancel
Apply Select Para ata Type Circ Specify the F X Y Z Diameter(m)	<pre>x Apply All meter le ields X Y Z Label</pre>	Cancel

Select data type as "Point", the table file displayed as below:



Select data type as "Circle", the table file displayed as below:



• Remove All: Remove all table files from LiPowerline.

#### **Data Context Menu**

• Info: View the table's basic information, including path, the number of elements, the minimum and the maximum of X, Y, Z values.



• Attribute: Display the contents of the table. As shown in the following figure, double click specific row, the window will go to the position.

	TreeID	TreeLocationX	TreeLocationY	TreeHeight	CrownDiameter	CrownArea	CrownVolu
1	1	322511.520	4102089.780	60.570	10.913	93.534	3348.00(
2	2	322511.810	4102015.140	57.100	9,670	73.449	2548.50
3	3	322537.430	4102062.510	55.720	11.769	108.782	3763.62
4	4	322529.420	4102073.100	53.850	10.929	93.803	3236.31
5	5	322525.070	4102101.070	53.740	12.906	130.820	3520.82
6	6	322501.160	410 <mark>2109.6</mark> 80	53.510	7.978	49.989	1399.01
7	7	322522.530	4102143.800	52.390	7.669	46.192	1309.62:
8	8	322520.650	4102152.530	52.070	9.612	72.559	1960.914
9	9	322514.280	4102001.290	51,430	11.659	106.756	3493.82
10	10	322533.990	4102053.190	51.070	8.075	51.216	1411.419
11	11	322523.570	4102070.020	50.950	6.626	34.479	929.889
12	12	322619.080	4102017.2 <mark>4</mark> 0	50.010	12,047	113.983	3273.20:
13	13	322522.240	4102076.870	49.740	7.524	44.456	1332.91
14	14	322526.700	4102079,520	49.570	3.536	9.820	229.217
15	15	322537.320	4102163.130	49.220	8.669	59.022	1814.00:

- **Zoom to Layer**: Calculates the bounding box of the current table data, and all windows that contains this file will display globally in this bounding box range.
- **Remove**: Remove the selected file from LiPowerline.

Note: Except "Import Data", the other function in context menu work on all windows that contains this table file.

## **Model Context Menu**

#### Brief

The right button menu of model data in the layer management tree mainly includes import and export table data, it also contains information, display setting, zoom to layer, restatistics, export for single model data.

### Data Type Context Menu

- Import Data: The model formats that LiPowerline supported includes: Model (.*LiTin*), *LiModel* (.LiModel), OSG data (.*osgb*, .ive, .*desc*, .obj). Among them, the LiTIN format and LiModel format are LiPowerline defined model format. This function is the same with the function +, see Add Data.
- Remove All: Remove all model files from LiPowerline.

#### **Data Context Menu**

• Info: View the basic information of model file, including the path, resolution, the minimum and maximum of X, Y, Z. This function just for LiTin and LiModel file.



• View Mode: Set the model file's display mode, including display by elevation, display by texture, display by light. if select "Display by Elevation", pop-up the selection of color bar dialog, the display effect as below:



The user can [generate models with texture](../DataManagement/Conversion/ConverttoTextureLiModel.md). An example of "Display by Texture" is shown below:



if select "Display by Lighting", pop-up the selection of color bar dialog, the display effect as below:





- **Zoom to Layer**: Calculates the bounding box of the current model data, and all windows that contains this file will display globally in this bounding box range.
- **ReStatistics**: Recalculate basic information such as Min X Y Z and Max X Y Z. In general, if you edit the LiModel data, such as smooth height or repair height, you can use the Restatistics function.
- **Export**: This function is only for LiTin and LiModel file, and the export format is TIF. In General, after 3D visualization editing of LiModel and LiTIN which generated by DEM, it is necessary to convert the editing files to TIF format file.
- Remove: Remove the selected model data from viewer window or project.

Note: Except "Import Data", the other function in context menu work on all windows that contains this model file.

## Window Management

#### Brief

The **project windows** manage all windows(i.e. viewers) and data in windows. The user can remove data from window, edit display order by dragging data node, show/hide data in specified window by checking/unchecking the box before window/data node. The context menu(i.e. right-click menu) of data node, which differs depending on data types, is mainly used for data query, display, statistics, export, and removal, etc. These functions are effective on specified window.

Click the houtton to show the **project windows** as follows:



#### **Context Menu**

Open the context menu by right clicking window or data.

#### Window Context Menu

• Remove All: Remove all data from the selected window.

#### **Data Context Menu**

- Point Cloud Data Context Menu: Same as the context menu of point cloud data in layer tree.
- Raster Data Context Menu: Same as the context menu of raster data in layer tree.
- Vector Data Context Menu: Same as the context menu of vector data in layer tree.
- Table Data Context Menu: Same as the context menu of table data in layer tree.
- Model Data Context Menu: Same as the context menu of model data in layer tree.

Note: The context menu of window management is only effective on specified window, while the context menu of layer management is effective on all windows.

## Viewers

This menu provides operations to create, close and arrange windows.

- New Window
- Close
- Close All
- Tile Windows
- Cascade Windows

## **New Window**

Brief: Create new window in the current project.

### Steps

1. Click the menu *Viewers > Add Window*. The result is as follows.



Shortcut Key: Ctrl+F3

## Close

Brief: Close the active window in the current project.

### Steps

1. Click the menu *Viewers > Close*. The active window will be closed.

Shortcut Key: Ctrl+F4

## **Close All**

Brief: Close all windows except for the power line window in the current project.

### Steps

1. Click the menu Viewers > Close All. All windows are closed except for the power line window.

## **Tile Windows**

Brief: Rearrange all the viewers in tiled fashion.

#### Steps

1. Click the menu *Viewers > Tile Windows*. The result is as follows.



Note: This function needs at least one window in the current project.

## **Cascade Windows**

Brief: Rearrange all the viewers in cascaded fashion.

### Steps

1. Click the menu Viewers > Cascade Windows. The result is as follows.



Note: This function needs at least one window in the current project.

# Display

Display menu of the software.

- Render to File
- Save to Video
- Language
- Show Legend
- Show Coordinate Axis
- Shaders
  - EDL
  - Glass
- Class Setting Options

## **Render to File**

**Brief**: This tool can render the current 3D view as an image file (\*.bmp format is supported). The user can also change the zoom factor, which affects the final image size.

### Steps

- 1. Adjust the 3D view to get the scene you want to render.
- 2. Click *Display > Render to File* and you will get a dialog shown as follows.

Sender to	File		×
Zoom 1.00	🚽 Result: (1329 x 886)		
📃 Don't scal	e features (points size)		
Output path:	D:/LiDAR360/Data/Render to File.bmp		
		OK	Cancel

- 3. (Optional) Set the zoom factor.
- 4. (Optional) Check or uncheck the "Don't scale features (points size)" according to demand.
- 5. (Optional) Set the Output path.
- 6. Click "OK" to get the rendered image.

#### Settings

- Input: Current active window.
- **Zoom**: Default value is 1 (original image size). You can increase the rendered image size by setting larger zoom factor (the resulting size is displayed on the right).
- **Don't scale features (points size)**: By default unchecked. If it is checked, the rendered point size won't be increased, even if the zoom factor is greater than 1.
- Output path: The file path to which the image will be saved.

## Save To Video

Brief: Record the current window screen and save as video (mp4 and avi formats are supported).

#### Steps

1. Click Display > Save To Video, an interface will show as follows.

Save to V	i deo					2
Frame Rat	e 25 fp	s 🗼	Bitrate	10000	kbps	<u>A.</u>
Output path:	D:/LiDA	R360/Da	ta/ Viewer	-0.mp4		
				OK		Cancel

- 2. Set the frame rate(default is 25 frame per second).
- 3. Set the bit rate.
- 4. Set the output path of video.
- 5. Click "OK". The following interface is shown on the left-top corner of the current window.



- 6. Change the camera to get the scene which you want to record.
- 7. Click "Stop" or "Start"
  - Stop: Pause the current record.
  - Start: Recover the record.
- 8. Click "End" to finish recording. The video will be saved.

#### Settings

- Input: the scene of the window for record.
- Frame Rate: The frequency (rate) at which consecutive images called frames appear on a display.
- **Bit Rate**: Refers to the number of bits used per unit of playback time to represent the video. Lower bit rate may result in lower resolution of the picture and has mosaics on the picture, and however the higher bit rate may lead a larger video file.
- Output path: The file path to which the video will be saved.

## Language

The supported language in LiPowerline is English.

### Steps

1. Click *Display > Language > English* to switch menu language. It will be effective after software restart.



2. Click Yes to restart the software immediately; Or click Cancel to restart later.

## **Show Legend**

Brief: Show/hide the legend in display windows.

#### Steps

 Click *Display > Show Legend* to check/uncheck this option. Display window without legend:







## Show Coordinate Axis

Brief: Show/hide the coordinate axis in display windows.

#### Steps

1. Click *Display* > *Show Coordinate Axis* to check/uncheck this option.

Display window without axis:







# Shader

The software currently offers two special shaders: EDL and Glass. They can be combined with other display modes(such as display by elevation and display by intensity) to enhance display effect.

- EDL
- Glass

## **EDL Shader**

**Brief**: The EDL shader can enhance the rendering effect of depth discontinuity. With this tool the user can distinguish the foreground easily from the background .

The EDL effect can be enabled/disabled for individual display window. An example is shown below. The left window displays point cloud data by elevation without EDL effect. The right window is with EDL effect.



Note: The EDL Shader is only applicable to point cloud data.

## **Glass Shader**

Brief: With the glass shader point cloud object appears translucent.

This effect can be enabled/disabled for individual display window. An example is shown as follows.



Note: The Glass Shader is only applicable to point cloud data.

# **Class Setting Option**

**Brief**: The class setting of LiPowerline complies with the ASPRS standard. As show in the figure below, the class 0-9 and 12 are fixed class type, the 10th, 11th, and 13th-31th class are reserved class. The fixed class can't be modified, and the reserved classes are customizable. This function set the order of classes according to the requirements and it will be displayed in order on the dialog and profile function.

Classification Value (bits 0:4)	Meaning
0	Created, never classified
1	Unclassified
2	Ground
3	Low Vegetation
4	Medium Vegetation
5	High Vegetation
6	Building
7	Low Point (noise)
8	Model Key-point (mass point)
9	Water
10	Reserved for ASPRS Definition
11	Reserved for ASPRS Definition
12	Overlap Points <sup>2</sup>
13-31	Reserved for ASPRS Definition

#### Steps

1. Click *Display > Class Setting Option*, open the dialog (default list of classes):



class settings in the classification function interface are as shown in the following figure:

Se Se		Fil	e Name		
	V	1	00025	2pcv.LiData	
From Class	and the second	To Class:	1-UnClass	ified	
<ul> <li>Never Classified</li> <li>Ground</li> <li>Medium Vegetation</li> <li>Building</li> <li>Model Key Point</li> <li>Reserved10</li> <li>Select All</li> </ul>	<ul> <li>VnClassified</li> <li>Low Vegetation</li> <li>High Vegetation</li> <li>Low Point</li> <li>Water</li> <li>Other Classes</li> <li>Vnselect All</li> </ul>	Choose Att	tribute:	None	

The class setting interface in the profile is shown in the following figure:
9			4
Fr	om Class		
	Never Classified	📝 UnClassified	
	Ground	📰 Low Vegetation	e:
Ē	]Medium Vegetatio	n 🔲 High Vegetatio	n.
	Building	📰 Low Point	
	Model Key Point	🗌 Water	
	Reserved10	Other Classes	
Ø	Select All	🔘 Unselect All	
© To	Select All Class: HotKey-0	⑦ Unselect All UnClassified	
© To	Select All Class: HotKey-O HotKey-O	Unselect All UnClassified UnClassified	
© To	Select All Class: HotKey=0 HotKey=1 NotKey=1	Unselect All UnClassified UnClassified UnClassified Unclassified Unclassified	
© To	Select All Class: HotKey-O HotKey-O HotKey-1 HotKey-2 HotKey-3	© Unselect All UnClassified UnClassified Ground Low Vegetation Medium Vegetation	
© To	Select All Class: HotKey-O HotKey-O HotKey-1 HotKey-3 HotKey-4	© Unselect All UnClassified UnClassified Ground Low Vegetation Medium Vegetation High Vegetation	11.
© To	Select All Class: HotKey=0 HotKey=0 HotKey=1 HotKey=2 HotKey=3 HotKey=4 HotKey=5	O Unselect All UnClassified UnClassified UnClassified Ground Low Vegetation Medium Vegetation High Vegetation Building	
To	Select All Class: HotKey=0 HotKey=1 HotKey=2 HotKey=3 HotKey=4 HotKey=5 HotKey=6	© Unselect All UnClassified UnClassified Ground Low Vegetation Medium Vegetation High Vegetation Building Low Point	
To	Select All Class: HotKey-O HotKey-O HotKey-1 HotKey-2 HotKey-3 HotKey-4 HotKey-6 HotKey-7	© Unselect All UnClassified UnClassified Ground Low Vegetation Medium Vegetation High Vegetation Building Low Point Model Key Point	

2. Select one class, click the button  $\Downarrow$  to move down one step, click the button  $\oint$  to move to the bottom, click the button  $\uparrow$  to up one step, click button  $\uparrow$  to move to the top; or mouse drag the class to a fixed position.



Taking Reserved15 class as an example, set the reserved15 as the highest priority, the class settings in the classification function interface and the class setting interface in the profile are shown in the following figure:

S S	elect		File	e Name	
		1	00025	2pcv.LiData	
From Class		To Class:	1-UnClass	ified	*
Keserved15 VnClassified Low Vegetation High Vegetation Uow Point Vater Select All	<ul> <li>Never Classified</li> <li>Ground</li> <li>Medium Vegetation</li> <li>Building</li> <li>Model Key Point</li> <li>Other Classes</li> <li>Unselect All</li> </ul>	Choose At	tribute:	None	

		L
From Class		
Reserved15	Never Classified	
📝 UnClassified	📰 Ground	
🥅 Low Vegetation	🧾 Medium Vegetation	1
🗌 High Vegetation	Building	
🕅 Low Point	🦳 Model Key Point	
🗌 Water	Other Classes	]
🕐 Select All	🔘 Unselect All	2
To Class: HotKey-O	Reserved15	
To Class: HotKey=0. HotKey=0 HotKey=0	Reserved15 Reserved15 NpClassified	
To Class: HotKey=0. HotKey=0 HotKey=1 HotKey=2	Reserved15 Reserved15 UnClassified Ground	
To Class: HotKey=O. HotKey=O HotKey=1 HotKey=3 HotKey=3	Reserved15 Reserved15 UnClassified Ground Low Vegetation	111 N 1
To Class: HotKey=0 HotKey=0 HotKey=1 HotKey=2 HotKey=3 HotKey=4	Reserved15 Reserved15 UnClassified Ground Low Vegetation Medium Vegetation	The second s
To Class: HotKey=0. HotKey=0 HotKey=1 HotKey=2 HotKey=3 HotKey=4 HotKey=5 HotKey=6	Reserved15 Reserved15 UnClassified Ground Low Vegetation Medium Vegetation High Vegetation Building	and a second
To Class: HotKey=0 HotKey=0 HotKey=1 HotKey=2 HotKey=3 HotKey=4 HotKey=5 HotKey=6 HotKey=7	Reserved15 Reserved15 UnClassified Ground Low Vegetation Medium Vegetation High Vegetation Building Low Point	101 V V

3. Double click the class in the class list to setting the class's name. As shown below:

~			2
Class Name	Reserved15		
		OK	Cancel

- 4. Click "Default" to restore the class setting option to default.
- 5. Click "OK" to save the current class setting list.

6. Click "Cancel" to cancel the current class priority setting and restore to the previous setting.

# **Strip Alignment**

Airborne LiDAR measurement system is influenced by various error sources, of which the systematic errors (the largest error source) cause the systematic deviation of laser footprint coordinates. Mounting of LiDAR measurement system requires the axis of the scanning reference coordinate system and inertial platform reference coordinate system to be parallel. However, while mounting of system, it is not guaranteed that they are parallel, resulting in the so-called systematic boresight error. In the Strip Alignment module, airborne LiDAR point clouds of overlapping strips can be aligned through boresight calibration.

- Strip Alignment
- Control Point Report
- Adjust Elevation
- Strip Quality Analysis
- Elevation Difference Inspection Quality Analysis
- Overlap Quality
- Density Quality

# **Strip Alignment**

**Brief**: In the Strip Alignment module, airborne LiDAR point clouds of overlapping strips can be aligned through boresight calibration. This module includes the following functions: loading/deleting/splitting trajectories, cutting point cloud according to trajectories, matching trajectory and point cloud, transforming point cloud based on boresight calibration parameters, eliminating point cloud redundancy (cut overlap), etc.

### Usage

1. Open strip alignment module. Click *Menu* > *Strip Alignment* > *Strip Alignment*, and the corresponding interface is shown as follows.

trip	Alignment				8
₽.	- 🤊 🚸 🌧	MA 🔜			
(1)	N 24 Ju				
2	- <b>-</b>				
ir:					
	how/Hide	Color	File Name	Start Time	End Time

2. 🕂 Add Trajectories: After clicking this button, an interface pops up to ask you to set the work directory.



Set the directory and a dialog for adding trajectories will be shown as follows.

Open Trajectory Files			×
C (C:) 1_TLS Fore	st Sample Data	<b>▼</b> 49	Search 1_TLS Forest Sample D 🔎
Organize 🔻 New folder			E • 🗌 🙆
<ul> <li>Recent Places</li> <li>A360 Drive</li> <li>1</li> <li>OneDrive</li> </ul>		No items matc	h your search.
E Desktop Libraries Libraries tg E Computer C (C:) L SampleData			
J_TLS Forest Sample Data J 1102 J 1109	-		
File name:		•	POS File(*.pos) POS File(*.pos) SBET File(*.OUT)

LiPowerline supports two formats of trajectory files: POS(\*.pos) (text format file) and SBET(\*.out)] (binary format file).

 POS File Example 1: If the POS file does not contain GridX and GridY information, the user has to specify following headers (GPS time, longitude, latitude, height, roll angle, pitch angle and yaw angle) for data columns. An example is shown as follows.

Info Selec	t Coordinate						
GPSTime 🔻	Longi tude 🔻	Latitude 🔻	Height 🔻	Roll 🔻	Pitch 🔻	Heading 🔻	-
380954.000	112.53119	26.89695	378.543	7.170123	3.089011	-39.40653	III.
380954.008	112.53119	26.89695	378.537	7.200186	3.091478	-39.40341	L
380954.016	112.53119	26.89695	378.531	7.236871	3.093638	-39.40111	
380954.024	112.53119	26.89695	378.525	7.268309	3.101505	-39.39754	
380954.032	112.53119	26.89695	378.518	7.300756	3.111516	-39.39295	
380954.040	112.53118	26.89695	378.512	7.326979	3.117972	-39.38782	
380954.048	112.53118	26.89695	378.506	7.352587	3.118046	-39.38040	
380954.056	112.53118	26.89696	378.500	7.374573	3.115163	-39.37138	4
Skip lines O Separator	+ comme (ASCII cod	nt/header lin e:%i) ESP	es skipped: O TAB , (	;			

It is required to select the correct projection coordinate system as the following picture.

ilter	Add Coordinate Syst	em 🔻
ecently used coordinate reference system	15	
Coordinate Reference System	Authority ID	
WGS 84 / UTM zone 49N	EPSG:32649	
<pre>cordinate reference systems of the world</pre>	m I Hide deprecated	) CRS:
Coordinate Reference System	Authority ID	
Geographic Coordinate Systems		
<ul> <li>Projected Coordinate Systems</li> <li>User Defined Coordinate Systems</li> </ul>		

• POS File Example 2: If the POS file contains GridX and GridY information, the user has to specify following headers (GPS time, longitude, latitude, height, roll angle, pitch angle, yaw angle, GridX and GridY) for data columns. An example is shown as follows.

Info Se	lect Coord	inate							
GPSTim 🔻	Longi t 🔻	Latitu 🔻	Height 🔻	Roll 🔻	Pitch 🔻	Headin 🔻	GridX 🔻	Grid¥ 🔻	*
381150.4	112.53	26.915	388.044	-17.630	7.169287	-75.341	652695	297799	HI.
38 <b>1</b> 150	<b>1</b> 12.53	26.915	388.059	-17.674	7.170946	-75.420	652695	297799	4
381150	112.53	26.915	388.075	-17.720	7.173627	-75.496	652695	297799	
38 <b>11</b> 50	112.53	26.915	388.09	-17.774	7.181245	-75.567	652695	297799	
38 <b>1</b> 150	112.53	26.915	388.106	- <b>17.</b> 833	7.190593	-75.633	652694	297799	
38 <mark>1</mark> 150	112.53	26.915	388.121	-17.891	7.196966	-75.697	652694	297799	
381150	112.53	26.915	388.137	-17.946	7.204942	-75.765	652694	297799	
381150	112.53	26.915	388.152	-17.999	7.214331	-75.838	652694	297799	÷
Skip lines	0 🛊 +	comment/h	eader lines	skipped:	0				
Separator	(ASC:	II code:%i)	ESP	ſAB ,	(uni en)				

If the information of GridX or GridY is not correct, the POS File Example 1 can be used.

For both of the two examples, click "Apply" to make the current settings apply on current trajectory file, and all the trajectory files will be affected by the current settings if you click "Apply all".

- 3. Delete Trajectories:
  - 3.1 Select the trajectories to be deleted in the trajectory list.



• 3.2 Click "Yes" or "No". Current selected trajectories will be removed. While clicking "Yes", the corresponding trajectory files will be deleted. The figure below demonstrates the effect of the scenes before and after the deletion of the red trajectory.



Before Deletion



After Deletion

- 4. P Show Single Trajectory: The color of the selected trajectory will be changed gradually, and then the trajectory will twinkle several times.
- 5. 
   OP Pick Point: Left click a certain point in the trajectory and the information of this point will be displayed.



6. Oraw Polygon:

- 6.1 Click the Draw Polygon button to activate this function (Click again if you want to deactivate it).
- 6.2 Choose the vertexes of the polygon one by one by left click.
- 6.3 Delete added vertices in reverse order by right click, if some of them are unwanted.
- 6.4 Left double click to add the last vertex. The polygon will be stored in the "polygon.gv" file under the work directory. If this file exists, the polygon will be automatically loaded at the step 2.



- 6.5 The polygon can be modified using left mouse button to select and drag.
- 7. My Split Trajectories: Click this button to split the source trajectories by polygon. New generated trajectories will be stored as POS file format in the work directory and named by the GPS starting and ending times of the trajectory. An example of new file name is "GPSStartTime\_GPSEndTime.POS". The effect of cutting is shown as follows. After this procedure, step 3 can be used to delete undesired trajectories.



8. 🔜 Cut Point Cloud Based on Trajectories.

o

8.1 Click the button	to pop up a dialog.
----------------------	---------------------

<b>4</b>	Select	File Name
		LiDAR360.LiData
	rajectorys' Buffer	
Cut by Tr		

Select the point cloud data files to be cut. Check the "Cut by Trajectories Buffer" and set the Buffer parameter as desired.

- 8.2 Click "OK". LiPowerline will cut the point cloud by the trajectories and show the process speed accordingly. The cutting results will be saved and the name of the point cloud is identical to the corresponding POS file. A dialog pops up to ask the user whether to load the results or not.
- All Match Point Cloud and Trajectory: Click this button, the point cloud data and the corresponding trajectory will be displayed in the same color.



10. Display Point Cloud by Trajectory: Click the button to pop up a dialog that lists the point cloud files and the corresponding trajectories. Choose an appropriate color for each trajectory to display.

Point Cloud	Trajectory File	Color	
380954.000_381045.344.LiData	D:/LiDAR360/Dats/StripAlignOut/380954.000		
381150.400_381299.712.LiData	D:/LiDAR360/Data/StripALignOut/381150.400_···		
381332.976_381496.560.LiData	D:/LiDAR360/Data/StripAlignOut/301332.976		
381598.920_381756.928.LiData	D:/LiDAR360/Data/StripAlign0at/381598.920		
381812.648_381982.960.LiData	D:/LiDAR360/Dais/StripAlignOnt/381812.648		
382074.816_382222.832.LiData	D:/LiDAR360/Data/StripAlignOut/382074.016_···		
382309.480_382460.888.LiData	D:/LiDAR360/Data/StripAlignOnt/382309.480_**		

11. 🌦 Transform: Click this button to pop up a dialog.

ansform Type	Loaded H	oint Cloud						
	S	elect				File Na	ime	
		1			380954.0	00_3810	45.344.LiData	3
		C71			201150.4	00.2013	00.710.1.0.44	-
Automatic Ali;	gnment	Alignment Qu	nality					
Translatio	n TOL.	ס. ס5	١z	m Rotat	ion TOL. Roll 🔽	5 APitch	☑ △Heading	•
Translatio	n TOL.	0. 05 Ly 🗖 2	١z	m Rotat	ion TOL. Roll 📝	5 ∆Pitch	☑ ∆Heading	° S Calculate
Translatio	n TOL. ( 2 ection 0	0. 05 Ly 🗖 2	ΔZ	m Rotat ℤ △	ion TOL. Roll 🔽	5 APitch	♥ ∆Heading [	° Calculate
Translatio	n TOL.	0. 05 \Y 🗖 2	ΔZ m m	m Rotat	nion TOL. Roll V	5 ∆Pitch	☑ △Heading	° Calculate



#### Automatic Alignment:

Select the boresight error you want to correct, and set the Translation TOL and Rotation TOL. Click "Calculate" to generate the boresight error automatically and the result will be shown in the "Boresight Correction" part of the interface. After the calculation of automatic alignment, LiPowerline will figure out the Alignment Quality. The Alignment Quality will be shown in the "Alignment Quality" tab page. (Theory of correction based on automatic adjustment.)

10000 - 14								
	S	elect				File Name		
					380954.00	00_381045.	344.LiData	
		(7)			201150.40	0.201200	7111:0-4-	
Automatic Ali;	gnment	Alignment Qu	uality					
Before Align	ment							
Min Error		m	Max Error	Ŭ.	m	RMSE		m
After Alignm	ent							
Min Error		m	Max Error	1	m	RMSE		m
								Export
Boresight Corr	rection							
۸	0		m	∆R₀ll	0		٥	
$\Delta$ ı	0		m	△Pitch	0		•	H
ΔZ	0		m	$\triangle \texttt{Heading}$	0		0	

Manual Alignment:

Adjust the boresight error manually. (Theory of correction based on manual measurement.) Click "Apply" and the transformation of error correction will be applied on the selected Transform Type.  $\circ$  11.2 For both automatic and manual method, correction result can be checked in the profile window.



After transformation

 $\circ$  11.3 Buttons on the right of the "Boresight correction" provide the following operations: "loading from file", "saving to a file" and "cleaning".

• 11.4 If the alignment effect is satisfied, you can switch Transform Type from the "Loaded Point Cloud" to "Selected Point Cloud Files". Click "Apply" to finish the transformation.

anstorm type	Loaded Point Clo	ud				
	Loaded Point Clo Selected Point C	ud 'loud Bilor				
1	Serected Tornet C	Todd Lite?		THE	wante	
	2			380954.000_38	81045.344.LiData	
	.070			201150.400.20	01000 710 L D.++-	
Automatic Ali;	gnment Alignm	ment Quality				
Translatio	n TOL. 0.05		m Rotat	ion TOL. 5		0
Translatio	n TOL. 0.05	ΔΖ	m Rotat	ion TOL. 5 Roll 🔽 APit.	ch <b>V</b> AHeading	° alculate
Translatio	n TOL. 0.05	<u>α</u> Δz	m Rotat	ion TOL. 5 Roll 🗹 APit.	ch 🔽 AHeading	°
Translatio	n TOL. 0.05		m Rotat ℤ∆ ∆Roll	ion TOL. 5 Roll 🗹 APite	ch 🔽 AHeading C	° alculate
Translatio	n TOL. 0.05	∏ ∆Z	m Rotat	ion TOL. 5 Roll V APit. 0	ch <table-cell> 🛆 Heading C</table-cell>	° alculate

12. Cut Overlap: Click this button to set the Cut Overlap Parameters. Click "OK" button, then the redundant points between the overlapped trajectories will be classified or deleted.

1	Sel	ect		File Name			
		]	380954.0	000_381045.344.LiD	)ata		
	V	]	381150.400_381299.712.LiData				
V		381332.976_381496.560.LiData					
V		381598.920_381756.928.LiData					
		381812.6	548_381982.960.LiD	)ata			
	U	]	382074.8	316_382222.832.LiC	Data		
		]	382309.4	180_382460.888.LiC	)ata		
		]	382540.088_382676.328.LiData 382771.392_382913.328.LiData				
	V	]					
From Class	.100		Parameters	1-			
Never Cl	.assified	VnClassified	Type: (	Classify	•		
Medium 1	egetation/	High Vegetation	To Class: (	12-Overlap Points	•		
💟 Buildin;	t.	Low Point	Edge (m)		1		
Model K	ey Point	🗌 Water	Densi ty		10		
Reserve	110	Other Classes	🧿 By Angl	e with Trajectory	25 °		
🖱 Select .	411	🔘 Unselect All	🖱 By Scan	Angle	10 °		

- Parameters of Cutting point cloud based on Trajectories
  - Buffer: The remaining distance in both sides of trajectory while cutting.
- Parameters of Transform
  - Boresight Error
    - **ΔX/ΔY/ΔZ**: Correction parameters of boresight offset error.
    - **ΔRoll/ΔPitch/ΔHeading**: Correction parameters of boresight pose error.
  - **Automatic Alignment**: It matches corresponding points between strips automatically and calculates optimal correction value of boresight error via adjustment.
    - **Translation TOL**: The maximum translation tolerance of  $\Delta X$ ,  $\Delta Y$ ,  $\Delta Z$ . The default value is 0.05 m.
    - **Rotation TOL**: The maximum rotation tolerance of ΔRoll, ΔPitch, ΔHeading. The default value is 5°.
    - Options: Users can decide whether the 3 translations and 3 rotations are involved in adjustment to calculate correction values. For most aerial data, it is not recommended to correct ΔZ. In default state, all the rotations are selected while all the translations are unselected.
  - **Alignment Quality**: After automatic alignment calculation, LiPowerline will figure out the alignment quality and show the result in the alignment quality result tab.
    - Min Error: Minimum error of matched corresponding points.
    - Max Error: Maximum error of matched corresponding points.
    - **RMSE**: RSE error of matched corresponding points.
  - Transform Type:

- Loaded Point Cloud: The loaded point cloud which is matched with trajectory in LiPowerline. When the transformation is applied, the corresponding point cloud is modified and the transformation effect can be shown in real-time. When strip alignment module exits, relevant transformation is eliminated without saving.
- Selected Point Cloud Files: In this type, the file list area on the interface will be activated, users can choose which point cloud file(s) will participate in the transformation. Then the results will be saved to the file. It doesn't loss the information even though the strip alignment module exits.

#### • Parameters of Cut Overlap:

- Type:
  - Classify: Classify points into target category and save the result in the original point cloud file.
  - Delete: Classify points into target category and then delete them from initial point cloud data (Note: If the input point cloud contains points of target category, they will also be removed).
- From Class: Point cloud target category.
- **Edge**: Grid unit size (length) of overlapping area. This parameter is used to rasterize the point cloud data of the overlapped area.
- **Density**: Smallest point density of grid unit. If the point density is smaller than the defined threshold, these points will not be classified to redundant points.
- **By Angle with Trajectory**: Angle between point cloud and trajectory. If this angle is larger than the threshold, the point cloud will be classified to redundant points.
- **By Scan Angle**: If scanning angle is larger than the threshold, point cloud will be classified to redundant points. (Note: this function can only be used when scanning angle is recorded by point cloud.)

#### Note:

1. The matching principle of a point cloud file and a trajectory is that: Each GPS time of all the points in the point cloud is inside the trajectory's GPS time span.

2.In most cases, the effect from X,Y or Z is tiny, while the ground control points are needed for higher precision of Z value. Therefore, only Roll, Pitch and Heading are selected to take apart in the adjusting by default.

3. The result may not satisfy if accuracy of the POS data file is not enough, and users can make an manual alignment based on the result.

4. For Overlapped function, at least two pairs of matched point cloud and trajectories are needed.

# **Control Point Report**

#### Brief

Control point report tool will create a report about elevation difference of laser point clouds and ground control points, which can be used to check the elevation accuracy of laser point clouds and improve the height accuracy of laser point clouds using calculated adjusted values.

Control point file is the text file separated by comma. Every row is composed by 3 columns which are X, Y and Z. The first row is the header, and please refer to Control Point File Format for specified format. At least 3 control points are requested to successfully create the control point report.

The output report displays information of elevation difference between used laser point clouds and control points of elevation, statistic information of height difference like average magnitude, standard deviation, root mean square, average of elevation difference as well as maximum and minimum height difference.

### Usage

8 52 Control Point Report  $\overline{V}$ Select File Name 1 merge001\_Adjust Elevation.LiData From Class: 1;2; Parameters Max Slope: 45 \* Max Triangle: 20 Report Contents Known Points C:/data/controlPoints.txt Select LineId X Z Dz Y Known Z 1 473575.563 291005.332 127.244 Null Null 1 2 473576.899 291004.245 126.328 126.331 0.00276184 V 3 473576.899 291004.243 126.317 126.331 0.0137634 63 Point Size 0.10 🚔 Dz Limit 3 \*std dev Average Magnitude 0.092 Average Dz -0.088 Std Deviation 0.485 Minimum Dz -3.451 Root Mean Square 0.488 Maximum Dz 0.035 Calculate Export

Click Strip Alignment > Control Point Report

After computation, the position of every control point can be checked by left double click at any position on the control point row in order to jump to the location of control point. Using Profile tool can help to check the relative position between control points and point cloud more intuitively.



- Input Data: Input file can be single point cloud data file or point cloud data set.
- From Class (default value is "all class"): User needs to select the point cloud class which is used to check control point elevation accuracy, and normally point cloud of hard surface such as ground point, construction point, etc. are chosen.
- Max Slope (°, default value is "45"): Maximum terrestrial gradient tolerance. If gradient is larger than this value, elevation difference will not be computed. Normally control points are chosen at the flat terrain, therefore if gradient is too steep, the result will be easily affected by wrong information.
- Max Triangle (m, default value is "20"): The longest side length of triangle is used to avoiding the large deviation caused by elevation interpolation. If the side length of triangle is too long, it is indicated that points of initial category in point cloud area where control points are located are less and calculated error of elevation difference is large.
- Known Points: Input control point file.
- **Refresh**: If the statistical information of height difference in the dialog window such as average range of elevation difference, standard deviation, RMS, average of elevation difference as well as maximum and minimum height difference are not shown, click refresh button.
- Size Point (default value is "0.10"): The location of control points can be displayed in the window by double clicking the corresponding data in the list of control point report. The size of point controls the size of control points shown in the window.
- **Dz limit (default value is "3")**: Set the tolerance of Dz. If Dz is not within the tolerance, show red in order to inspect elevation difference with large error between point cloud and control points. Maximum tolerance = Average Dz + Dz × Std Deviation. Minimum tolerance = Average Dz Dz × Std Deviation.
- Calculate: After setting parameters, click this button to calculate elevation difference.
- Export: Export control point report file of TXT format. The file contains elevation error information of point cloud data and statistical information of Dz.

# **Adjust Elevation**

### Brief

The elevation of raw laser data is normally represented by ellipsoidal height. Normally these values need to be transformed to values in regional height system or local height system. For large area, the adjustment of elevation can not be defined as a mathematical formula. Hence, the model of elevation adjustment is required to be defined. The algorithm is to build triangular network model using known control point data as well as to interpolate and correct local points using height anomaly between different height systems. Adjusted elevation result can be checked according to the Control Point Report.

It is recommended to use control point data containing entire project region to adjust model in order to provide more accurate elevation information to the project border.

### Usage

Click Strip Alignment > Adjust Elevation

1	Select	File Name		
		LiForest.LiData		
input Fil	Le:			
Input Fi Jutput p	le: ath:sta/LiForest_Elevat			

- Input Data: Input files can be single point cloud file or point cloud data set.
- Input File: Users need to input adjustment model file of control points. This file data can be generated by tool of Control Point Report.
- Output path: Output adjusted point cloud data.

# **Strip Quality Analysis**

#### Brief

**Trajectory Quality Analysis** tool checks trajectory quality from the height analysis, speed analysis and flight attitude analysis.

#### Usage

Click Strip Alignment > Strip Quality Analysis.

Load trajectory file(s) and set the parameters of height analysis, speed analysis and fight attitude analysis. This tool supports generating reports for each analysis. Click **Export** to save the quality report in html format.

Trajectory List:					2
D:/sampledata/LiDAR360/2016	0804/380968.49	6 381028.024.pos			
D:/sampledata/LiDAR360/2016	0804/381116.18	4 381120.568.pos			
D:/sampledata/LiDAR360/2016	0804/381178.42	4 381183.424.pos			
D:/sampledata/LiDAR360/20160	0804/381342.86	4_381523.920.pos			
D:/sampledata/LiDAR360/2016	0804/381572.25	6_381745.824.pos			E 🕂
D:/sampledata/LiDAR360/2016	0804/381822.42	4_382011.720.pos			
D:/sampledata/LiDAR360/2016	080 <mark>4</mark> /382046.19	2_382217.536.pos			
D:/sampledata/LiDAR360/2016	0804/382313.22	4_382492.880.pos			
D:/sampledata/LiDAR360/2016	0804/382510.83	2_382674.896.pos			
D:/sampledata/LiDAR360/2016	0804/382771.47	2_382946.968.pos			-
Height Analysis					
Height Analysis Design Height: 350	m	Height Tolerance: 5		%	Generate Report
Height Analysis Design Height: 350 Speed Analysis	m	Height Tolerance: 5		8	Generate Report
Height Analysis Design Height: 350 Speed Analysis Design Speed : 25	m m/s	Height Tolerance: 5 Speed Consistency:	5	8	Generate Report Generate Report
Height Analysis Design Height: 350 Speed Analysis Design Speed : 25 Flight Attitude Analysis	m m/s	Meight Tolerance: 5 Speed Consistency:	5	\$ \$	Generate Report Generate Report
Height Analysis Design Height: 350 Speed Analysis Design Speed : 25 Flight Attitude Analysis Strip Deformation: 3	m m/s	Height Tolerance: 5 Speed Consistency:	5	%	Generate Report Generate Report Generate Report
Height Analysis Design Height: 350 Speed Analysis Design Speed : 25 Flight Attitude Analysis Strip Deformation: 3 Integral Report	m m/s	Meight Tolerance: 5	5	× ×	Generate Report Generate Report Generate Report

Click - to load data. The supported formats of POS files contain \*.OUT and \*.pos. Click — to clear loaded data. Click  $\checkmark$  to clear the loaded POS file(s).

- Height Analysis: Height analysis report contains strip name, max height, min height, height difference, height variance, mean height and qualified flag of each strip. The Yes is qualified, and No is unqualified. The mean height of qualified strip is displayed as green, or as red. Click **Export** button to save the result in html format.
- Design Height (m, default value is "0"): Designed height value.
- Height Tolerance (%, default value is "0"): The floating ratio of designed height. For example, 5% denotes that the qualified height range is between (1-5%) × designed height and (1 + 5%) × designed height.
- Generate Report: Click Generate Report button to save height analysis quality report.

Strip Name	Max Height	Min Height	leight Difference	Height Variance	Mean Height	Qualified
D:/sampledata/UDAR360/20160804/380968.496_381028.024.pos	388.517000	360.067000	28,450000	84.377869	377.142238	No
D:/sampledata/LiDAR360/20160804/381116.184_381120.568.pos	349.814000	349.065000	0.749000	0.044288	349.299186	Yes
D:/sampledata/UDAR360/20160804/381178.424_381183.424.pcs	355,305000	352,167000	3.138000	1.085294	553.980893	Ves
D:/sampledata/LiDAR360/20160804/381342.864_381523.920.pos	398.759000	319.536000	79.223000	288.443466	138.607984	Ves
D:/sampledata/LiDAR360/20160804/381572.256_381745.824.pos	364.448000	337,421000	27/027000	55.881072	348.842489	Yes
D:/sampledata/LiDAR360/20160804/381822.424_382011.720.pos	382.828000	296.560000	86.268000	498.202885	339.204829	Ves
D:/sampledata/UDAR360/20160804/382046.192_382217.536.pos	423.123000	354,149000	68.974000	215.674719	378.956766	No
D:/sampledata/UDAR360/20160804/382313.224_382492.880.pos	378.174000	339.546000	38.628000	127.106485	360.579943	Ves
D:/sampledata/LiDAR360/20160804/382510.832_382674.896.pos	401.492000	344.303000	57.189000	314.346527	375.705265	No

- **Speed Analysis**: The speed analysis report contains strip name, max speed, min speed, speed difference, speed variance, mean speed and qualified flag of each strip. The mean speed of qualified strip is displayed as green, or as red. Click *Export* button to save the result in HTML format.
- Design Speed (m/s, default value is "0"): Designed speed value.
- Speed Consistency (%, default value is "0"): The floating ratio of designed speed. For example, 5% denotes that the qualified speed range is between (1- 5%) × designed speed and (1 + 5%) × designed speed.
- Generate Report: Click Generate Report button to save speed analysis quality report.

Strip Name	Max Speed	Min Speed	Speed Difference	Speed Variance	Mean Speed	Qualified
D:/sampledata/UDAR360/20160804/380968.496_381028.024.pos	25.396278	22.858746	2.527532	0.306447	24.146894	Yes
D:/sampledata/LiDAR360/20160804/381116.184_381120.568.pos	25.396278	22.868746	2.527532	0.298557	24.127900	Yes
D:/sampledata/UDAR360/20160804/381178.424_381183.424.pcs	25.396278	22.868746	2,527532	0.277038	24.128684	Ves
D:/sampledata/LiDAR360/20160804/381342.864_381523.920.pos	25.980200	21.365729	4.614471	0.456836	74.205803	Ves
D:/sampledata/LiDAR360/20160804/381572.256_381745.824.pos	26.495029	21.365729	5.129300	0.580724	24,577498	Yes
D:/sampledata/LiDAR360/20160804/381822.424_382011.720.pos	26,495029	21.365729	5.129300	0.840213	24.218352	Ves
D:/sampledata/UDAR360/20160804/382046.192_382217.536.pos	26.953223	21.365729	5.587495	0.948660	24.420661	Ves
D:/sampledata/UDAR360/20160804/382313.224_382492.880.pos	26.953223	21.365729	5.587495	0.895407	24.350253	Yes
D:/sampledata/LiDAR360/20160804/382510.832_382674.896.pos	27.767175	21.365729	6.401446	1.163361	24.584238	Ves

- Flight Attitude Analysis: Flight attitude analysis report contains strip name, max roll, mean roll, max pitch, mean pitch, strip deformation (%) and qualified flag of each strip. The Yes is qualified, and No is unqualified. The strip deformation of qualified strip is displayed as green, or as red. Click Export button to save the result in html format.
- Strip Deformation (%, default value is "3"): According to the related data standard, the qualified threshold of strip deformation is generally set to 3%.
- Generate Report: Click Generate Report button to save flight attitude analysis quality report.

Strip Name	Max Roll	Mean Roll	Max Pitch	Mean Pitch	rip Deformation(9	Qualified
D:/sampledata/LiDAR360/20160804/380968.496_381028.024.pos	0.139342	0.053389	0.080410	0.017202	0.008324	Yes
D:/sampledata/LiDAR360/20160804/381116.184_381120.568.pos	0.075833	0.066035	-0.136734	-0.290275	0.077113	No
D:/sampledata/LiDAR360/20160804/381178.424_381183.424.pcs	0.097426	0,082223	-0.339158	-0.443768	0.128671	No
D:/sampledate/LiDAR360/20160804/381342.864_381523.920.pos	0.157390	0.062235	0.210310	0.039488	0.015483	Ves
D:/sampledata/LiDAR360/20160804/381572.256_381745.824.pos	0.112846	0.066136	0.255560	0.024674	0.020621	Yes
D:/sampledata/LiDAR360/20160804/381822.424_382011.720.pos	0.176866	0.072113	0.474735	0.047400	0.035580	No
D:/sampledata/LiDAR360/20160804/382046.192_382217.536.pos	0.132483	0,067952	0.188747	0.031388	0.016203	Ves
D:/sampledata/LiDAR360/20160804/382313.224_382492.880.pos	0.161122	0.058627	0.266678	0.036267	0.026196	Ves
D:/sampledata/LiDAR360/20160804/382510.832_382674.896.pos	0.131206	0.047944	0.148360	0.027442	0.015501	Yes

• Integral Report: Click Full Report button to save the integral report.

# **Elevation Difference Inspection Quality Analysis**

#### Brief

Elevation Difference Inspection tool analyzes the elevation difference between point clouds.

### Usage

Click Strip Alignment > Elevation Difference Inspection Quality Analysis

√ Se	elect		File Name	
			LiForest.LiDat	ta
]		LiForest	t_filter_Normaliz	ation.LiData
From Class V Never Classified V Ground Medium Vegetation Building Model Key Point Reserved10 Select All	<ul> <li>VnClassified</li> <li>Low Vegetation</li> <li>High Vegetation</li> <li>Low Point</li> <li>Water</li> <li>Other Classes</li> <li>Vnselect All</li> </ul>	Col 1 2 3 4	or	Value 0.150 0.100 0.050 0
tput path: E:/data/		Grid Size: Cut off Value:	2 0.5	m

- Input Data: Input files can be single point cloud file or point cloud dataset. The data to be processed must be opened in the LiPowerline.
- From Class: The point cloud classes used in the elevation difference quality inspection.
- Grid Size (m, default value is "1"): The grid size in the point cloud gridding.
- Cut off Value (m, default value is "0.5"): The data above the threshold will be ignored. The threshold is used to remove moving target.
- **Output Path**: The results of elevation difference quality inspection will be exported to the selected folder, which contains the result of each strip density quality inspection and integral report in HTML format.

# **Overlap Quality**

### Brief

Strip Overlap Analysis tool analyzes the overlap between point clouds.

## Usage

Click Strip Alignment > Overlap Quality

2	Select	File Name
		LiForest.LiData
		LiForest_filter_Normalization.
	Overlap Thresho	Ld 25 %
	Overlap Thresho	ld 25 %

- Input Data: Input file can be single point cloud file or point cloud dataset. The data to be processed must be opened in the LiPowerline.
- Input POS File: Click to load data. The supported formats of POS files contain \*.OUT and \*.pos. Click
   to clear the loaded data. Click to clear the loaded POS file(s).
- Overlap Threshold (%, default value is "25"): The overlap threshold between two adjacent strips.
- **Output Path**: The results of overlap quality inspection will be exported to the selected folder, which contains the results of each strip overlap quality inspection (in SHP format, the property table contains the profile check result which may be qualified, unqualified, non-overlapping or boundary) and integral report in html format.

# **Density Quality**

### Brief

Density Quality Analysis tool analyzes the density of point cloud.

## Usage

Click Strip Alignment > Density Quality

Select	File Name	
	LiForest.LiData	L
ensity Threshold	Liferant filter Normalization Li	Doto
Color	Value	
1	10	
2	20	
3	30	
4	40	
Note:Between value and its' nearest value Grid Size	<i>vill display its's color in result!)</i> 1m	
)utput path: E:/data/		
D. C	OF	Connel

- Input Data: Input file can be single point cloud file or point cloud dataset. The data to be processed must be opened in the LiPowerline.
- **Density Threshold**: The point density between the adjacent thresholds is shown in the corresponding color.
- Grid Size (m, default value is "1"): The grid size in the point cloud gridding.
- **Output path**: Select the output path of density inspection quality report. The folder contains the results of each strip density quality inspection and integral report in html format.

# **Data Management**

This chapter introduces the basic tools commonly used for point cloud and raster data processing. Contents include: point cloud tools, raster tools, clip tools, format conversion and data extraction.

- Point Cloud Tools
  - Outlier Removal
  - Noise Filter
  - Normalization
  - Normalization by Ground Class
  - Tile
  - Merge
  - Boundary
  - Subsampling
  - PCV
  - Define Projection
  - ReProjection
  - Extract Color from Image
  - Subdivision
  - Transformation
- Raster Tools
  - Band Calculator
  - Raster Mosaic
  - Raster Subdivision
- Clip
  - Clip by Circle
  - Clip by Rectangle
  - Clip by Polygon
- Conversion
  - Convert to LiData
  - Convert LiData to LiData
  - Convert to Las
  - Convert to ASCII

- Convert to Raster
- Convert to Shape
- Convert to DXF
- Convert Image to LiModel
- Convert to Texture LiModel
- Convert LiModel to Image
- Extract
  - Extract by Class
  - Extract by Elevation
  - Extract by Intensity
  - Extract by Return
  - Extract by Time
  - Extract by Serial Time
- Classify
  - Classify by Attribute
  - Classify Ground
  - Classify Low Points
  - Classify by Below Surface
  - Classify Isolated Points
  - Classify Air Points
  - Classify by Height Above Ground
  - Classify by Min Elevation
  - Classify by Close Point
  - Class Conversion
  - Classify Buildings
  - Classify Model Key Points

# **Point Cloud Tools**

The Point Cloud Tools include Outlier Removal, Noise Filter, Normalization, Tile, Merge, Boundary, Subsampling, PCV, Projection, Extract Color from Image, subdivision and Transformation.

- Outlier Removal
- Noise Filter
- Normalization
- Normalization by Ground Class
- Tile
- Merge
- Boundary
- Subsampling
- PCV
- Define Projection
- ReProject
- Extract Color from Image
- Subdivision
- Transformation

# **Outlier Removal**

### Brief

Common noises include high level gross errors and low level gross errors. As shown below, high level gross error is usually caused by the returns of high-flying objects (such as birds or aircraft) during the process of data collection; low-level gross error are returns with extremely low attitudes caused by the multipath effect of a laser pulse. The Outlier Removal tool aims to remove these errors as much as possible and therefore improve the data quality.



The algorithm will first search for each point's neighboring points within a user-defined area and calculate the average distance from the point to its neighboring points. Then, the mean and standard deviation of these average distances for all points are calculated. If the average distance of a point to its neighbors is larger than maximum distance (maximum distance = mean + n \* standard deviation, where n is a user-defined multiple number), it will be considered as an outlier and be removed from the original point cloud.

Effect picture:



### Usage

Click Data Management > Point Cloud Tools > Outlier Removal

	Select		File Name			
		1-2(1_2).LiData				
		2-3(2_3).LiData				
Weighbor Points: [	10	Multiples of std deviation: 5		🗌 Same With O	Drigin File Name	
utput path: C:/PR	OJECT/test/					

### Settings

- Input Data: The input file can be a single point cloud data file or multiple data files. File Format: \*.LiData.
- Neighbor Points (default value is "10"): The number of points required in the neighborhood to calculate the average distance of each point. If there are not enough points found, the algorithm will not be executed.
- Multiples of std deviation (default value is "5"): The factor multiplied by the standard deviation to calculate the maximum distance.
- Same With Origin File Name: Whether to use the same file name of origin file name.
- **Output path**: Path of the output file. After the algorithm being executed, a new file will be generated. When more than one files are entered, the path needs to be set to a folder.
- DefaultValue: If this button is clicked, all parameters will be set to default values.

Note: The algorithm can be performed repeatedly to improve the denoising results. The outlier removal results is limited if the noises are to dense.

# **Noise Filter**

### Brief

Remove noise from a point cloud. Unlike the denoising function, this function works better for objects with planar surfaces (e.g., walls, tunnel interiors, ground) and can filter out more noise points.

### Usage

Click Plugins > Point Cloud Tools > Noise Filter

Select	File Name		
$\checkmark$	1-2(1_2).LiData		
×	2-3(2_3).LiData		
ultiples of std deviati	ion: 1.00 🗘		
T Pomore Teologial Point	ta 🖂 Sama With Ouisia Bila 1		
] Remove Isolated Point	ts 🗌 Same With Origin File 1		
Remove Isolated Point	ts 🗌 Same With Origin File ) est/		

#### **Parameter Settings**

- Input Data: The input file can be a single point cloud data file or a point cloud dataset.
- Radius Search (meters) (default is "0.5"): Set the radius for fitting the plane. This method can be used when the user knows the approximate density of the point cloud.
- **Recommended Radius Search**: Automatically calculate a suitable search radius based on the input point cloud.
- Standard Deviation Multiplier (default is 1.0): Use the relative error (sigma) as the denoising criterion. The program automatically calculates the standard deviation (stddev) of the plane fitted to the neighborhood of each point P. If the distance d from the point to the plane is less than sigma\*stddev, the point P will be retained. Decreasing this value will result in more points being removed, and vice versa. Changing this value does not affect efficiency.

- **Remove Isolated Points**: If the number of points within the search radius is less than four (insufficient for plane fitting), the point is considered isolated. Users can choose whether to remove such points based on this parameter.
- Same With Source File Name: If checked, a new file with the same name as the source file but with noise removed will be generated in the output directory. Otherwise, the string "\_NoiseFilter" will be appended to the source file name.
- **Output Path**: The output folder path. After the algorithm is executed, a new file with noise removed will be generated in this directory.
- **DefaultValue**: If this button is clicked, all parameters will be set to default values.

# Normalization

#### Brief

The normalization tool can remove the influence of terrain relief on the elevation value of the point cloud data. This function requires that the extent of the DEM overlaps with the extent of the point cloud data. The normalization process is performed by subtracting the corresponding terrain elevation of the DEM from each point's Z value. The output of this function is similar to Normalization by Ground Class.



### Usage

Click Data Management > Point Cloud Tools > Normalization

2	Select	File Name LiForest.LiData		
put DEM	File		•	
	-53			
- Input Data: The input file can be a single point cloud data file or multiple data files. File Format: \*.LiData.
- Input DEM File: Users can select single or multiple single-band TIFF image files from the drop-down list. File format: \*.tif.
- - Users can add external DEM file data.
- =: Users can select a file in the list and click this button to remove the file from the list.
- d: Click this button to clear all the data in the list.
- **Output path**: Path of the output file. After the algorithm being executed, the new normalized file will be generated. When entering more than one file, the path will need to be set as a folder.

# **Normalization by Ground Class**

## Brief

The normalization tool can remove the effects of topographic relief on the elevation value of point cloud data. This function requires that the input data has already been classified into ground points and non-ground points. The normalization process is performed by subtracting the terrain elevation (represented by the elevation of the closet ground point to each point) from each point's Z value. The output of this function is similar to Normalization.

## Usage

✓ Select	File Nam	ne
	LiEorost LiE	
	LIFOTESLUL	Jata
	LIFOTESLUL	Jata
	LIFOTESLUL	Jata

Click Data Management > Point Cloud Tools > Normalization by Ground Class

- Input Data: The input file can be a single point cloud data file or multiple data files. File Format: \*.LiData.
- **Output path**: Path of the output file. After the algorithm being executed, the normalized new file will be generated. When entering more than one file, the path needs to be set as a folder.

## Tile

## Brief

Tile by Range divides the point cloud into a series of small data files based on the user-defined width and length of the small data file. This process begins from the lower-left corner of the input file's bounding box.

### Usage

Click Data Management > Point Cloud Tools > Tile

2	Select			File Nan	ne
				LiForest.Lil	Data
Width	500	m	Height	500	m
)utput path:	E:/data/				

- Input Data: The input file can be a single point cloud data file or multiple data files. File Format: \*.LiData.
- Width (default value is "500"): The width of the data block size, which is the length in the X-axis direction.
- Height (default value is "500"): The length of the data block size, which is the length in the Y-axis direction.
- Output path: Path of the output folder. After the algorithm being executed, new files will be generated.

## Merge

## Brief

Merge multiple point cloud files into a single point cloud file. This function is the reverse operation of Tile.

## Usage

Click Data Management > Point Cloud Tools > Merge

1	Select	File Name		
		LiForest.LiData		
		LiForest_filter_Normalization.LiDa		

- Input Data: The input file can be a single point cloud data file or multiple data files. File Format: \*.LiData.
- Output path: Path of the output folder. After the algorithm being executed, a new file will be generated.

# Boundary

## Brief

Use a regular hexagon to extract the boundary of a point cloud data. According to the **Edge**, determine the height of each regular hexagon, and draw each hexagon based on the bounding box of the point cloud data. If the number of points within a hexagon is greater than or equal to the user-defined **Density** value, this hexagon will be kept and merged with its connected hexagons. The ultimate output file is the final border vector file.



## Usage

Click Data Management > Point Cloud Tools > Boundary

2	Select		File Name			
			J. J. J.	LiForest.	LiData	
	178		1:5 Eb			
Edge	10	m	Density	1		
tput path:	E:/data/					-

- Input Data: The input file can be a single point cloud data file or multiple data files. File Format: \*.LiData.
- Edge (default value is "10"): The height of the hexagon, which is used to set the size of drowning a hexagon.
- **Density (default value is "1")**: The thresholding number of points in a hexagon, below which no hexagon will be drawn.

• **Output path**: Path of the output file. A new boundary vector file will be generated after the algorithm is executed. File format: \*.shp.

# Subsampling

### Brief

Subsampling point clouds, namely, reducing the number of point clouds, LiPowerline offers three methods for resampling: minimum point spacing, sampling rate, and octree.

## Usage

Click Data Management > Point Cloud Tools > Subsampling

Sele	ct	File Name		
$\checkmark$		1-2(1_2).LiData 2-3(2_3).LiData		
Sampling Type: Minimum Points Spacin	g:	Minimum Points Spac 0.2000	ing	
Sampling Type:		Minimum Points Spac	ing	-
- 	u Haisht	-69 46000		
☐ Handle Selected Cl ☐ Same With Origin F	ass: ile Name	:7-Insulator;28-Drai	nage Thread +	🗸 Select All
itput path: C:/PROJECT	/test/			4.4.4

- Input Data: The input file can be a single point cloud data file or multiple data files. File Format: \*.LiData.
- **Sampling Type**: This parameter defines the resampling method.
- **Minimum Points Spacing (default, default value is "0.2000")**: Users need to set a minimum point spacing between two points so that the minimum three-dimensional distance between any two points in the sampled point cloud will not be less than this value. The larger the value is set, the fewer points will be kept.
- Handle Points Below Height: If this item is checked, only points below that elevation are processed.
- Handle Selected Class: If this item is checked, only the points of the target category are processed.
- Same With Origin File Name: Whether to use the same file name of origin file name.
- **Output path**: Path of the output file. New file will be generated after the algorithm being executed.

## PCV

### Brief

PCV tool can be used to improve visualization effect of a point cloud. The principle of the PCV (Portion of Visible Sky) algorithm is to evenly distribute multiple light sources at the top of the hemisphere or sphere calculate, and then calculate the cumulative number of times when the light can be irradiated by illuminating each point in a point cloud. The last statistical result will be used as the intensity of the point cloud. The rendering effect of the point cloud intensity after PCV calculation is shown in the figure below.



## Usage

Click Data Management > Point Cloud Tools > PCV

Select the point cloud data that needs to be processed by PCV.

2	Select	File Name	
V		LiForest.LiData	

After the PCV process, the intensity range of a point cloud will be 0-255. By clicking on display by intensity or clicking display by the mixed mode, users can see the boundary between different land covers more clearly in the point cloud after PCV process. The figure below shows an example of intensity and height blend displaying effect after PCV calculation.



# **Define Projection**

## Brief

Define projection information for point cloud data, including geographic coordinates (usually latitude and longitude coordinates) and projection coordinates (plane coordinates converted by projection).

## Usage

Click Data Management > Point Cloud Tools > Define Projection

✓ Sele	ect		File Nam	e	
V		i i i i i i i i i i i i i i i i i i i	0-1(0-1).LiD	ata	
Current file's coordi	nate name:				
7ilter	0		Add Coord	inate System	
Recently used coor	dinate refe	rence systems			
Coordinate Reference	System	Authority ID			^
GGRS87		EPSG:4121			
WGS 84 / UTM zone	34N	EPSG:32634		<u> </u>	
GGRS87 / Greek Grid	ł	EPSG:2100			v
<				>	
Coordinate referen	ce systems	of the world	🗌 Hi de	deprecated CRS	Ss
Coordinate Reference	e System	Authority ID		9	^
> Geographic Coo	rdinate Syste	ms			
> Projected Coord	inate System.	5			
Ilear Datinad Co	ardinata Cur	tame			Y
- 1 - 1 - 1					_
Selected UKS:					_
					_
			OK	Cancel	

- Input Data: The input file can be a single point cloud data file or multiple data files. File format: \*.LiData.
- Filter: Users need to enter the customized coordinate system. By entering the coordinate system keywords, the corresponding coordinate system can be filtered from the Coordinate reference systems of the world table (for example: to set the point cloud coordinate system to WGS 84 / UTM Zone 49N, users can enter UTM 49N in the filter for fast screening, or enter its EPSG number: 32649 for quick search.) Users can also import external coordinate system settings by clicking the Add Coordinate System button.

- Add Coordinate System: Users can add external coordinate system settings or customize coordinate system settings. LiPowerline software provides four ways to add external coordinate system:
  - Import from WKT
  - Import from PRJ
  - Add Geographic Coordinate System
  - Add Projected Coordinate System
- Hide deprecated CRSs: Hide deprecated coordinate systems.

#### Import from WKT

WKT format can refer to the following way:

```
GEOGCS [
       "GCS_Beijing_1954"
     ,DATUM["D_Beijing_1954",SPHEROID["Krasovsky_1940",6378245.0,298.3]]
       ,PRIMEM["Greenwich",0.0]
       ,UNIT["Degree",0.0174532925199433]
       ,AUTHORITY["EPSG",4214]
   ]
   PROJCS[
       "MyProjCS"
       ,GEOGCS["WGS84",DATUM["WGS_1984",SPHEROID["WGS84",6378137,298.257223563,AUTHORITY["EPSG","7030"]],TOWGS84[0,0
,0,0,0,0,0],AUTHORITY["EPSG","6326"]]
       ,PRIMEM["Greenwich",0,AUTHORITY["EPSG","8901"]]
       ,UNIT["degree",0.0174532925199433,AUTHORITY["EPSG","9108"]]
       ,AUTHORITY["EPSG","4326"]]
       ,PROJECTION["Transverse_Mercator"]
       ,PARAMETER["latitude of origin",0]
       ,PARAMETER["central_meridian",-81],PARAMETER["scale_factor",0.9996]
       ,PARAMETER["false_easting",500000]
       ,PARAMETER["false_northing",0]
       ,UNIT["Meter",1]
   ]
```

#### Import from PRJ

PRJ format can refer to the following way:

+proj=longlat +ellps=aust\_SA +towgs84=-117.808,-51.536,137.784,0.303,0.446,0.234,-0.29 +no\_defs

Add Geographic Coordinate System

lame: New_GCS	501			
Datum				
Name:	Custon	1		-
Spheroid				
¥		Cil-11-		
Name:		Lustom		X
Semimajor	Axis:			
Inverse F	latteni	ng:		
Angular Un	it			
Name:		Custom		
Radians Par	· 1/mi+ ·			
naurans rei	oni c.			
Prime Meri	li an			
Name:	Custon	<u>į</u>		•
Longi tude:		•	1.	"
1. The second se				

- Name: Users can customize a geographic coordinate system name.
- Datum:
  - Name: Users can customize a datum name or select a known datum from the drop-down list.
  - **Spheroid**: If a user selects the datum from the drop-down list, the ellipsoid parameter does not require user to enter.
    - **Name**: The name of the spheroid.
    - Semimajor Axis: Spheroid's major semi axis.
    - Inverse Flattening: Inverse flattening of the spheroid.
- Angular Unit:
  - Name: Users can customize the angle unit name, or select the angle unit name from the drop-down list.
  - Radians Per Unit: Define the unit of arc in the geographic coordinate system.
- Prime Meridian:
  - **Name**: Users can customize the name of the central meridian, or select the name of the central meridian from the drop-down list.
  - Longitude: Input the central meridian longitude.

#### Add Projected Coordinate System

1 Coordinate System		
Custom		
	Value	
Custom		
nate System		
		Change
	Custom Custom Custom nate System	Custom Custom Custom Custom nate System

- Name: Users can customize the name of a projection coordinate system.
- Projection:
  - **Name**: Users can customize a projection name or select a known projection from the drop-down list. It should be noted that user-defined projections can be modified from a projection template selected from the drop-down list. Linear units:
- Linear Unit:
  - Name: Users can customize the linear unit name or select the linear unit name from the drop-down list.
  - Meters per Unit: Input meters per unit.
  - **Geographic Coordinate System**: Users can paste the geographic coordinate system parameters into the text box, or click **Change**.

#### Change

When the user clicks on the Modify button, the following dialog box will pop up for modifying the geographic coordinate system.

New Geographic Coordinate System
Authority ID
<i>ns</i>

The user can filter out the needed coordinate system through the filter operation, or can also add the geographic coordinate system through the **New Geographic Coordinate System** and the setting method is the same as Add Geographic Coordinate System.

# Reproject

### Brief

The point cloud can be converted by projection, including the conversion between geographic coordinate system and projected coordinate system. When different geographic coordinate systems are converted to each other, due to the differences between the ellipsoid used and the reference plane, it will involve the conversion between ellipsoids. LiPowerline provides the seven-parameter transformation model. Select the "using the sevenparameters" option and click the "Seven Parameters Setting" button. The user can enter the values for Xtranslation, Y-translation, Z-translation, X-axis rotation, Y-axis rotation, Z-axis rotation, and scale values for seven-parameter transformation.

### Usage

1	Select	File	Name		
		0-1(0	-1).LiData		
Current file's coordins	ate name:				
Use Seven Parameters	Sev	en Parameters Settin	ng		
/ilter			Add Coord	inate System	
Recently used coord	inate reference systems				
Coordinate Reference S	ystem	Authority ID			4
GGRS87		EPSG:4121			1
WGS 84 / UTM zone 34	4N	EPSG:32634			f
GGRS87 / Greek Grid		EPSG:2100			
<				>	
Coordinate reference	e systems of the world		🗌 Hi de	deprecated C	RS
Coordinate Reference	System	Authority ID			3
> Geographic Coord	linate Systems				1
< multiplication of multiplication of the second se	-*- **			>	
Selected CBS:					_
					-
Output path: C:/PROJECT	/data/0-1(0-1)_Reproject. LiDate	6		1.11	
					-

Click Data Management > Point Cloud Tools > Reproject

- Input Data: The input file can be a single point cloud data file or multiple data files. File Format: \*.LiData.
- Use Seven Parameters: User decides whether to use seven parameters for re-projection, if checked, seven parameters will be used.
- Seven Parameters Setting: Select the Use Seven Parameters option, click the Seven Parameters Setting button, and the Seven Parameters Dialog will pop up. Click to fill the seven-parameter values by opening

a txt file; click 💾 to save the set value as a txt file; click 🥖 to clear the entered value.

- X (m): The X translation in seven parameters.
  - Y (m): The Y translation in seven parameters.
  - **Z** (m): The Z translation in seven parameters.
  - Rx ("): The X-axis rotation in seven parameters.
  - Ry ("): The Y-axis rotation in seven parameters.
  - Rz ("): The Z-axis rotation in seven parameters.
  - λ (ppm): The zoom scale in seven parameters.
- Filtering: Users needs to input the customized coordinate system. By entering the coordinate system keywords, the corresponding coordinate system can be filtered from the Coordinate reference systems of the world table (for example: to set the point cloud coordinate system to WGS 84 / UTM Zone 49N, users can enter UTM 49N in the filter for fast screening, or enter its EPSG number 32649 for quick search.) Users can also import external coordinate system by clicking the Add Coordinate System button.
- Add coordinate systems: For details, refer to Define Projection Parameter Settings.
- Hide deprecated CRSs: Hide deprecated coordinate systems. •
- Output path: Path of the output file. New files will be generated after the algorithm is executed.

Seven Par	ameters:	
X (m)=	0.0000000000	
Y (m)=	0.00000000000	
Z (m)=	0.0000000000	
Rx (")=	0. 00000000000	
Ry(")=	0.00000000000	
Rz(")=	0.00000000000	
$\lambda(ppm) =$	0.00000000000	

Note: The reprojected point cloud must already have projection information. To check whether the current point cloud has projection information, users can select the data in the data list and its projection information will be displayed in the current file coordinate system.

## **Extract Color from Image**

## Brief

Extract Color from Image tool can extract RGB information from multi-band imagery and assigned them to each point in a point cloud. The user is required to enter one or more multi-band images that overlapping with the extend of the point cloud data.

After the process is completed, the display mode of the point cloud data will automatically change to RGB display (you can also click on the toolbar Button, to display the point cloud in RGB).

### Usage

File Name
LiForest.LiData

Click Data Management > Point Cloud Tools > Extract Color from Image

- Input Data: The input file can be a single point cloud data file or multiple data files. File Format: \*.LiData.
- Input File: The user needs to enter one or more multi-band images that are geographically overlapping with the point cloud data. If the image data has already been opened in the software, click the drop-down button to select the data, or you can click is to open the external image data. Click is to remove selected images from the list and click is to clear the image data list. File format: \*.tif.

## Subdivision

## Brief

Subdivision tool can divide a point cloud to a series of frames based on the user defined scales. Currently, LiPowerline supports four subdivision scales: a scale of 1:5000 (taken to 1 km), 1:2000 (taken to 0.1 km), 1:1000 (taken to 0.1 km), and 1:500 (taken to 0.01km). Moreover, only subdivision in rectangular is supported currently. The frame ID will be named by the coordinate number, which is composed of the southwest corner of the frame (Y coordinate + X coordinate). After the operation is completed, a vector file will be generated in shp format recording each subdivided frame.

## Usage

Click Data Management > Point Cloud Tools > Subdivision

Subdivision				L
Input LiData Fi	1e 🗌			•
	16			
	Scale:	1:500	•	
Output path: E:,	Scale: 'data/	1:500	•	

- Input LiData File: Input the point cloud data to be subdivided. If the point cloud data is already open in the software, click the drop-down button to select the data; or you can click 
  to open external point cloud data. Click 
  to remove the selected data. Click 
  to clear the image data list. File format: \*.LiData.
- Scale: User-defined scale. LiPowerline has four scales: 1:500, 1:1000, 1:2000, 1:5000.
- **Output path**: Path of the output folder. After the algorithm is executed, a new shp file will be generated.

# Transformation

## Brief

LiPowerline software supports multiple coordinate conversion methods. Users can select a conversion type to perform point cloud data conversion according to their needs.

The four supported coordinate conversion methods are:

- Linear
- XYMultiply
- Translate and Rotate
- 3D Affine

## Steps

- 1. Input Data: The input file can be a single point cloud data file or multiple data files. File Format: \*.LiData.
- 2. Select the **Transformation Type**. The user selects the desired conversion type from the drop-down box and sets the relevant parameters.
- 3. **Output path**: Path of the output folder. After the algorithm is executed, new files after transformation will be generated.

## Usage

Click Data Management > Point Cloud Tools > Transformation

## Settings

#### Linear

7	Select		File Nan	ne
		1	LiForest,Li	Data
ran Lii X=	sformation Type [] lear Parameters	.inear * x +	•	
ran Lii X= Y=	sformation Type I near Parameters	.inear * x + * y +	• 0 0	
ran Lii X= Y= Z=	sformation Type I near Parameters 1 1 1	.inear * x + * y + * z +	• 0 0 0	
ran Lii X= Y= Z=	sformation Type I near Parameters 1 1 1 1 path: data/LiFore	.inear * x + * y + * z + est_Transform	O     O     O     nation. LiData	(

The linear transformation is used to pan and zoom a point cloud. A panning and scaling parameter need to be set to the X, Y, Z coordinates, respectively. The targeted coordinates are calculated using the following formula:

$$\begin{cases} X = S_x * x + P_x \\ Y = S_y * y + P_y \\ Z = S_z * z + P_z \end{cases}$$

Among them: Sx, Sy, Sz are the scaling factors for the x, y, and z coordinates. Px, Py, and Pz are the panning parameters for the x, y, and z coordinates. x, y, and z are the original coordinates, and X, Y, and Z are coordinates obtained after the linear transformation.

#### XYMultiply

	2	Select				File	Name	
		V				LiFore	<mark>st.Li</mark> Data	
ran	sformati	ion Typ	e XYMul	tiply	_	,	•	
XY	multipl	y Para	meters	106281			-	
ХҮ Х=	multipl O	y Para	meters 1	*	x +	0	_	* 3
ХҮ Х= Ү=	multipl 0 0	y Para + +	meters 1 O	*	x + x +	0		* y * y

The target coordinates are calculated using the following formula:

$$\begin{cases} X = P_x + a * S_x + b * S_y \\ Y = P_y + c * S_x + d * S_y \\ Z = P_z + e * S_z \end{cases}$$

Among them, Px, Py, Pz, a, b, c, d, e are the transformation parameters, Sx, Sy, Sz are the original coordinates, and X, Y, Z are the transformed coordinates. This is often used as a 2D Helmert transformation.

#### **Translate and Rotate**

J	Sele	đ			File Name	
	V			Li	Forest.LiData	
'rsns Tra	formation Type Tr nslate and Rotate	enslate and Parometers	Rotate 🔻			
λ =	0					
Dx=	0	Rx=	0	٥		
Dy=	0	Ry=	0	٠		
Dr=	0	Rz=	0	( <b>•</b> )		
(Tip:	s.the number of digits	after The deci	mal point must l	he at least 8, in orde	r to reach mm-lev	el accurary!

The target coordinates are calculated using the following formula:

$$\begin{bmatrix} X \\ Y \\ Z \end{bmatrix} = (1+\lambda) \begin{bmatrix} R_{11} & R_{12} & R_{13} & D_x \\ R_{21} & R_{22} & R_{23} & D_y \\ R_{31} & R_{32} & R_{33} & D_z \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} x \\ y \\ z \end{bmatrix}$$

R11, R12, R13, R21, R22, R23, R31, R32, R33 are calculated as follows:

$$R11 = cos(Ry) * cos(Rz)$$

R21 = cos(Ry) \* sin(Rz)

R31 = -sin( Ry )

 $R12 = \sin(Rx) \sin(Ry) \cos(Rz) - \cos(Rx) * \sin(Rz)$ 

 $R22 = \sin(Rx) \sin(Ry) \sin(Rz) + \cos(Rx) * \cos(Rz)$ 

R32 = sin( Rx ) \* cos( Ry )

 $R13 = \cos(Rx) \sin(Ry) \cos(R_z) + \sin(Rx) * \sin(Rz)$ 

R23 =  $\cos(Rx) \sin(Ry) \sin(Rz) - \sin(Rx) * \cos(Rz)$ 

R33 =  $\cos(Rx)^* \cos(Ry)$ 

- λ (default value is "0"): Scale conversion factor applied to X, Y, Z.
- Dx, Dy, Dz (default value is "0"): Panning values added to X, Y, Z.
- Rx, Ry, Rz (default value is "0"): The angle of rotation about the X, Y, and Z axes in degrees.

Note: To achieve millimeter-level accuracy, there should be at least eight decimal places after the decimal point.

#### 3D Affine

~	S	elect			File Name	
		V		L	iForest.LiData	
Irans 30 J Dx= Dv=	formation Type Affine Paramete O	3D Affine rs Mor=	•	kx=	0	
Dr=	0	Mz=	0	Rr=	0	•
	s the number of dis	gits after The dec	imal point must	be at least 8, in ora	ler to reach mm-level (	accurary!)

The target coordinates are calculated using the following formula:

$$\begin{cases} X = D_x + (1 + M_x) * x + R_z * y - R_y * z \\ Y = D_y + (1 + M_y) * y - R_z * x + R_x * z \\ Z = D_z + (1 + M_z) * z + R_y * x - R_x * y \end{cases}$$

- Dx, Dy, Dz (default value is "0"): Panning values added to X, Y, Z.
- Mx, My, Mz (default value is "0"): Scale factor applied to the X, Y, and Z axes.
- Rx, Ry, Rz (default value is "0"): The angle of rotation about the X, Y, and Z axes in degrees.

Note: To achieve millimeter-level accuracy, there should be at least eight decimal places in the user inputs.

# **Raster Tools**

Raster tools include Band Calculation, Raster Mosaic, and Raster Subdivision.

- Band Calculator
- Raster Mosaic
- Raster Subdivision

# **Band Calculator**

## Brief

**Band Calculator** tool can generate a new raster image based on a user-defined map algebra equation from two single-band images.

Band operator functions and operators include: Basic operations: plus (+), minus (-), multiply (×), and divide ( $\div$ ); Trigonometric functions: sine sin(x), cosine cos(x), tangent tan(x), arcsine asin(x), arc cosine acos(x), arc tangent atan(x); Other mathematical functions: natural exp(x), natural logarithm ln(x), logarithm to base a log(a, x), square root sqrt(x), quadratic power Power2, cubic power Power3, round integer part, inverse

The band operation function can be applied to single or two raster images, and the input data must meet the following conditions:

- (1) The input data must be a single-band image;
- (2) The input data must have the same spatial resolution;
- (3) The spatial range of the input data must have intersections.

### Usage

Click Data Management > Raster Tools > Band Calculator

( 1.00	* •	Band 1		•	8
		Operation: [+	•		
( 1.00	* *	• Band 2		•	
lutput path	2				• •

### **Settings**

• **Output path**: Path of the output folder. After the algorithm is executed, a new file will be generated after the band operation.

## **Raster Mosaic**

### Brief

**Raster Mosaic** refers to the technical process of merging two or more images to one image. LiPowerline provides seven sampling methods: **Nearest Neighbour**, **Bilinear**, **Cubic**, **CubicSpline**, **Lanczos**, **Average**, and **Mode**. It is the reverse operation of Raster Subdivision.

### Usage

Input Tiff Fi	ile			•
	Sample Type:	Nearest	leighbour 🔻	]

Click Data Management > Raster Tools > Raster Mosaic

- Input Tiff File: Users can select multiple files (>1) to be processed from the drop-down list.
- 4: Users can add multiple external images for image mosaic.
- d: Click this button to clear all images in the list.
- Sample Type: Users need to select the sampling type from the drop-down list.
  - NearestNeighbour (default): Nearest neighbor, sampled from the nearest neighbor.
  - Bilinear: Bilinear sampling (2 x 2 cores).
  - Cubic: Cubic convolution approximation (4 x 4 kernels).
  - CubicSpline: Cubic B-spline approximation (4×4 kernel).
  - **Lanczos**: Lanczos Window Sine Interpolation (6×6 Cores). Lanczos can be used as a low pass filter or to smoothly interpolate the value of a digital signal between its samples.
  - Average: Calculate the average of all non-value pixels.
  - Mode: Select the most frequently occurring value for all sampling points.
- Output path: Path of the output folder. After the algorithm is executed, a new file will be generated.

# **Raster Subdivision**

## Brief

The raster subdivision tool is the inverse operation of raster mosaic. The frame number adapts the coordinate number and consists of the southwest corner of the frame (Y coordinate + X coordinate). A scale of 1:5000 is taken into 1 km, 1:2000 and 1:1000 to 0.1 km, and 1:500 to 0.01 km.

## Usage

👼Raster Subdi	vision	×
Input File	•	
	Scale 1:500 🔻	
		-
Output path:		1.10

Click Data Management > Raster Tools > Raster Subdivision

- Input File: Users can select the file to be processed from the drop-down list.
- Users can add external files that need to be processed.
- Scale (default "1:500"): Users can select a targeted scale. LiPowerline has four scale options: 1:500, 1:1000, 1:2000, and 1:5000.
- **Output path**: Path of the output folder. After the algorithm is executed, new subdivided files will be generated.

# Clip

The clipping tools include Clip by Circle, Clip by Rectangle and Clip by Polygon.

- Clip by Circle
- Clip by Rectangle
- Clip by Polygon

# **Clip by Circle**

## Brief

Clip by circle tool extracts the point cloud data within user-defined circle(s), and the extracted points can be saved in one or multiple files.

## Usage

Click Data Management > Clip > Clip by Circle

✓ Select	File Name
	LiForest.LiData
~	Circle Center
Coordinate(m)	Y Coordinate(m)
16 - 17	2002
Radius	(m)
Radius	(m) File 🔘 Generate Multiple Files
Radius Generate a tput path: E:/data/	(m) File O Generate Multiple Files

- Input Data: Input one or more point cloud data files. File Format: \*.LiData.
- X Coordinate (m): Enter the X coordinate of the circle center.
- Y Coordinate (m): Enter the Y coordinate of the circle center.
- Radius (m): Enter the radius of the circle.
- Generate a File: Extract all the point cloud data within 2D circle(s) to one file.
- **Generate Multiple Files**: Extract the point cloud data within each circle and save them to one individual file. The file is named by its center and radius by default.
- -: Click this button to add the coordinates and radius of a circle to the processing list. Perform the same operation to add multiple clipping circles.
- Click this button to load external data files. The file format refers to the Clip Range File Format in the appendix.
- \_\_\_: Click this button to remove the selected row(s) in the processing list.

• **Output path**: The generated file will be saved in this output path.

# **Clip by Rectangle**

## Brief

Clip by rectangle tool extracts the point cloud data within user-defined rectangular(s), and the extracted points can be saved in one or multiple files.

## Usage

Click Data Management > Clip > Clip by Rectangle

√ Se	elect	File Na	me
	V	LiForest.L	. <mark>i</mark> Data
Rectangle Re	gion		
Y	Maximum (m)		1
X Minimum(m)		X Maximum(m)	
Y	Minimum (m)		]
Y 💿 Gei	Minimum(m) nerate a File	🔘 Generate Multipl	e Files
Y 💿 Gei	Minimum(m) nerate a File	🔘 Generate Multipl	e Files
Y Ger	Minimum(m) nerate a File	💮 Generate Multipl	e Files
Y Ger itput path: E	Minimum(m) nerate a File :/data/	💮 Generate Multipl	• Files

- Input Data: Input one or more point cloud data files. File Format: \*.LiData.
- Y Maximum (m): Enter the maximum Y coordinate of the rectangle.
- Y Minimum (m): Enter the minimum Y coordinate of the rectangle.
- X Minimum (m): Enter the minimum X coordinate of the rectangle.
- X Maximum (m): Enter the maximum X coordinate of the rectangle.
- Generate a File: Extract all the point cloud data within the rectangle to a file.
- Generate Multiple Files: Extract the point cloud data within each rectangle and save them to one file. The

file is named by the rectangle's lower left corner coordinate and the rectangle's width and height by default.

- - Click this button to add the entered rectangle range to the processing list. Perform the same operation to add multiple clipping regions.
- Click this button to load external data files. The file format refers to the Clip Range File Format in the appendix.
- \_\_\_\_: Click this button to remove the selected row(s) in the processing list.
- Output Path: The generated file will be saved in this output path.

# **Clip by Polygon**

## Brief

Clip by polygon tool extracts the point cloud data within user-defined polygon vector file, and the extracted points will be saved in one file.

## Usage

Click Data Management > Clip > Clip by Polygon

2	Select	File Name
	V	LiForest,LiData
hape File		▼] [
hape File utput pat	h:'orest_Clip b	▼ y Polygon. LiData

## **Settings**

- Input Data: Input one or more point cloud data files. File Format: \*.LiData.
- Shape File: Select the vector file loaded into LiPowerline software from the drop-down menu, or click the button
   to load the external vector data file.
- Output Path: The generated file will be saved in this output path.

Note: The vector data file used to clip the point cloud data must be a polygon file (not point or line file), and currently MultiPolygon files are not supported.

# Conversion

Conversion Tools contain Convert to LiData, Convert LiData to LiData, Convert to Las, Convert to ASCII, Convert to Raster, Convert to Shape, Convert to DXF, Convert Image to LiModel, Convert to Texture LiModel, Convert LiModel to Image, Convert Raster to ASCII.

- Convert to LiData
- Convert LiData to LiData
- Convert to Las
- Convert to ASCII
- Convert to Raster
- Convert to Shape
- Convert to DXF
- Convert Image to LiModel
- Convert to Texture LiModel
- Convert LiModel to Image

## **Convert to LiData**

## Brief

Convert to LiData can convert point cloud data in LAS or LAZ formats to LiPowerline customized point cloud format (LiData format).

## Usage

Click Data Management > Conversion > Convert to LiData

ttributes To I	Export				20
V X	V 1	🔽 Z	🔄 Number of	the Return	
✓ R	☑ G	☑ B	🗹 Direction	of Scan Flag	
🗹 Intensity	🗹 Scan Angle	🔽 User Data	🔽 Edge of F	light Line Fl	ag
🗸 GPS Time	🗹 Classification	🗹 Point Source ID	🗹 Number of	Returns of G	iven Pulse
Select Al	ll 🔘 Unselect All				
RGB Range: 💿	Origion () 0~255(		ibit)		

- File List: Import the file that needs to be converted. The file formats currently supported are : .las, .laz. Users need to click to select the point cloud data; users can select one or more file(s) in the existing list and click to delete them from the list; users can click  $\checkmark$  to remove all files in the list.
- Attributes to Export: Users can select the attributes that need to be exported. All Las attributes are supported.
- **RGB Range**: User can select the RGB range of the output file, which can be output by the source file or converted to 8 and 16 bits.
- **Output Path**: Path of the output folder. After the conversion is executed, the converted new file(s) will be generated.

# Convert LiData to LiData

## Brief

Convert the current point cloud to another version of the LiData format.

## Usage

Click Plugins > Conversion > Convert LiData to LiData

1	Select	File Name	1
		1-2(1_2).LiData	
		2-3(2_3).LiData	
Version o:	f LiData: 1.9		*

## **Parameter Settings**

- File List: Input file to be converted(.LiData).
- LiData Version: The version of output LiData file.

## **Convert to Las**

## Brief

Convert to Las can convert point clouds in LiData format to LAS format, namely the standard Lidar point cloud data format.

## Usage

Click Data Management > Conversion > Convert to Las

1	Select		File Name	
			1-2(1_2).LiData	
			2-3(2_3).LiData	
ttributes To V X V R	Export I G 	✓ Z ✓ B	<ul> <li>✓ Number of the Return</li> <li>✓ Direction of Scan Flag</li> <li>✓ Edge of Flight Line Flag</li> </ul>	
🗸 Intensity	🗹 Scan Angle	U OSEL DALA		
☑ Intensity ☑ GPS Time	✓ Scan Angle ✓ Classification	Point Source ID	🗹 Number of Returns of Given Pul	se
✓ Intensity ✓ GPS Time ● Select A RGB Range: ●	<ul> <li>✓ Scan Angle</li> <li>✓ Classification</li> <li>11 ○ Unselect All</li> <li>0rigion ○ 0~255(</li> </ul>	<ul> <li>✓ Point Source ID</li> <li>(8bit) ○ 0~65535(16)</li> </ul>	☑ Number of Returns of Given Pul bit)	se
<ul> <li>✓ Intensity</li> <li>✓ GPS Time</li> <li>● Select A</li> <li>RGB Range: ●</li> <li>put path:</li> </ul>	<ul> <li>✓ Scan Angle</li> <li>✓ Classification</li> <li>11 ○ Unselect All</li> <li>○ Origion ○ 0<sup>~</sup>255 (</li> </ul>	<ul> <li>✓ Point Source ID</li> <li></li></ul>	✓ Number of Returns of Given Pul bit)	se

- Input Data: The input file can be a single point cloud data file or multiple data files. File Format: \*.LiData.
- Attributes to Export: Users can select the attributes that need to be exported. All Las attributes are supported.
- **RGB Range**: User can select the RGB range of the output file, which can be output by the source file or converted to 8 and 16 bits.
- **Output Path**: Path of the output folder. After the conversion being executed, the converted new file(s) will be generated.
# **Convert to ASCII**

### Brief

The Convert to ASCII tool can convert the LiData point cloud to ASCII format, a text format that can be easily viewed in a text editor.

### Usage

Click Data Management > Conversion > Convert to ASCII

7	Select		File Name
			LiForest.LiData
attributes to	Export		
V X	🖉 Y	[√] Z	📝 Return Number
🗸 R	🔽 G	☑ B	📝 Direction of Scan Flag
🕖 Intensity	📝 Scan Angle	📝 Vser Data	📝 Edge of Flight Line Flag
🗸 GPS Time	📝 Classification	V Point Source ID	Vumber of Returns (given pulse) Export Format
Select A	ll 🔘 Unselect All		TXT 🔻 Separator: Comma 💌
tnut nath F.	/data/LiForest Conve	ert to ASCII tyt	

- Input Data: The input file can be a single point cloud data file or multiple data files. File Format: \*.LiData.
- Attributes to Export: Users can select the attributes that need to be exported. All Las attributes are supported.
- Export Format: LiPowerline supports two suffix formats: txt and csv, and support separators are: commas, spaces and TAB.
- **Output path**: Path of the output folder. After the conversion is executed, the converted new file(s) will be generated.

# **Convert to Raster**

#### Brief

The Convert to Raster tool can convert LiData point cloud data to raster images according to the **Attribute** of the points in **Cell Value** method.

#### Usage

Click Data Management > Conversion > Convert to Raster

1	Select		File Name	
			LiForest,LiData	
XSize 2		m YSize 2		
Attribute Z		💌 Cell Value Mi	nimum 🔻 💟 Merge f	files into one

- Input Data: The input file can be a single point cloud data file or multiple data files. File Format: \*.LiData.
- XSize (m, default value is "2"): The X pixel resolution of the output raster.
- YSize (m, default value is "2"): The Y pixel resolution of the output raster.
- Attribute (default is "Z"): Select the point attribute used to calculate the raster cell value.
  - Z (default): Generate the raster data using the Z value of the point cloud data.
  - Intensity: Generate raster data using the intensity values of the point cloud data.
  - Scan angle: Generate raster data using the scan angle of point cloud data.
  - Return number: Generate raster data using the return number of the point cloud data.
  - **Number of returns of given pulse**: Raster data is generated using the number of returns of given pulse of the point cloud data.
- Cell value: Choose how to fill raster pixel values.
  - Minimum (default): Use the smallest attribute value as the value of a raster cell.
  - Average: Use the average of attribute values of all points within a raster cell as its value.
  - Maximum: Use the largest attribute value as the value of a raster cell.
- Merge files into one: Users can set merging all raster into one data file. If not checked, each point cloud data will be generated into a separate raster file.
- Output path: Path of output folder. After the algorithm is executed, the converted new file is generated.

# **Convert to Shape**

### Brief

The Convert to Shape tool can convert point cloud files in LiData format to point files in vector format.

### Usage

Click Data Management > Conversion > Convert to Shape

4	Select		File Name
			LiForest.LiData
Attributesr t	o Export		
√ X	V Y	I Z	📝 Return Number
🔽 R	📝 G	В	👿 Direction of Scan Flag
🚺 Intensity	📝 Scan Angle	📝 User Data	📝 Edge of Flight Line Flag
🗸 GPS Time	📝 Classification	V Point Source ID	📝 Number of Returns (given pulse)
Select A	ll 🔘 Unselect All		
tput path: E:	/data/LiForest_Conve	ert to Shape.shp	- + + +

- Input data: The input file can be a single point cloud data file or multiple data files. File Format: \*.LiData.
- Attributes to Export: Users can select the attributes that need to be exported, and all Las attributes are supported. The selected attributes will be written in the attributes of the shape file data.
- **Output path**: Path of the output folder. After the conversion being executed, the converted new file will be generated.

# **Convert to DXF**

### Brief

The Convert to DXF tool can convert LiData format point cloud files to point vector data in DXF format. LiPowerline software exports DXF files in ASCII format.

### Usage

Click Data Management > Conversion > Convert to DXF

🗹 Sel	ect	File Name
		LiForest.LiData
From Class		Tile
📝 Never Classified	🔽 UnClassified	No Tile
Ground	🗌 Low Vegetation	💿 Tile by Rows and Colums
🗌 Medium Vegetatio	n 🗌 High Vegetation	Rows: 3 Columns: 3
Building	Low Point	Tile by Width and Height
Model Key Point	🔲 Water	
Reserved10	Other Classes	Width: 100 m Height: 100 m
🔊 Select All	🔘 Unselect All	
1	Likevert Convert to DVR	

- Input Data: The input file can be a single point cloud data file or multiple data files. File Format: \*.LiData.
- From Class: Source class (es).
- **Tile**: Since the amount of point cloud data is often large, the software provides an optional tile mode that can split the input data file to a number of tiles.
  - No Tile: Export a single DXF file.
  - **Tile by Rows and Columns**: According to the boundary of the point cloud data, the point cloud will be split into a total number of rows \* columns data blocks evenly, and a single DXF file will be generated.
    - Rows (default value is "3"): User-defined number of rows that the point cloud want to be split into.
    - Columns (default value is "3"): User-defined number of columns that the point cloud want to be split into.
  - **Tile by Width and Height**: The point cloud will be split into a number of tiles from the lower left corner by the specified width and height, one DXF file per block.
    - Width (m, default value is "100"): User-defined block width.
    - Height (m, default value is "100"): User-defined block height.
- **Output path**: Path of the output folder where the converted new file(s) will be generated.

# **Convert Image to LiModel**

### Brief

Convert image to LiModel tool can convert single-band raster data (DEM, DSM, CHM, etc.) to LiModel format. The LiModel format is a LiPowerline software customized format that allows the converted single-band raster data to be displayed and edited in a 3D window.

### Usage

Jutput path:		

Click Data Management > Conversion > Convert Image to LiMode

- Input Tiff File: Users can select the file to be processed from the drop-down list.
- - -: Users can add files to be converted that have not been opened.
- =: Users can select a file in the list and click this button to remove the file from the list.
- d: Click this button to clear all files in the list.
- **Output path**: Path of the output folder. After the conversion being executed, the converted new file(s) will be generated.

# **Convert to Texture LiModel**

### Brief

Convert to Textured LiModel tool is based on the Convert Image to LiModel tool, which maps color values of a DOM data to the LiModel model for display. This function only supports single file data conversion.

### Usage

Click Data Management > Conversion > Convert to Texture LiModel

Input DEM	•	) []
Input DOM	•	
Output LiModel		
	ОК	Cancel

- Input DEM: Users can select a file to be converted from the drop-down list or use the button
   to load an external data file. Single-band raster data is required.
- Input DOM: Users can select a desired file from the drop-down list or use the button to load an external data file. The selected color image needs to have at least three bands.
- **Output LiModel**: Path of the output file. After the conversion being executed, the converted new file will be generated.

# Convert LiModel to Image

### Brief

Convert LiModel to Image tool converts LiModel format files to raster images in TIFF format. After editing LiModel data, users can use this function to convert the data to TIFF format.

### Usage

Click Data Management > Conversion > Convert LiModel to Image

nput LiModel File	•	
iput Dimodel 1110		
		4
		2
		_
utput path:		

- Input LiModel File: User can select a file to be processed from the drop-down list.
- -: Users can add external data files to be converted.
- =: Users can select a file in the list and click this button to remove the file from the list.
- d: Click this button to clear all the data in the list.
- **Output path**: Path of the output folder. After the conversion being executed, the converted new file will be generated.

# Extract

Extraction tools include Extract by Class, Extract by Elevation, Extract by Intensity, Extract by Return, Extract by Time, and Extract by Serial Time.

- Extract by Class
- Extract by Elevation
- Extract by Intensity
- Extract by Return
- Extract by Time
- Extract by Serial Time

# **Extract by Class**

### Brief

Extract by class tool can extract all the point cloud data of the user-selected class, and save the data in one file. This function supports multiple file operations.

### Usage

Click Data Management > Extract > Extract by Class

<b>V</b>	Select	File Name	
	$\checkmark$	1-2(1_2).LiData	а
	$\overline{\checkmark}$	2-3(2_3).LiData	
] Outp Outpu () la:	ut Separately 🗌 t File Suffix: — s	Same With Origin Fil	e Name
0utp Outpu 0 1a:	ut Separately 🗌 t File Suffix: — s	] Same With Origin Fil IiData	e Namo
] Outp Outpu () la: rom Cl	ut Separately 🗌 t File Suffix: — s ass: 2:4:6:7:16::	Same With Origin Fil LiData 17:20:23:27:28:	e Namı
0utp Outpu 1s: rom Cl utput	ut Separately t File Suffix: s ass: 2:4:6:7:16: path:	Same With Origin Fil LiData 17:20:23:27:28:	e Namı

- Input Data: Input one or more point cloud data files. File Format: \*.LiData.
- **Output Separately**: This parameter is not selected by default. If it is selected, one file is output for each category.
- Same With Origin File Name: This parameter is deselected by default. If it is selected, the output file name is the same as the source file.
- Output File Suffix: Suffix of output file.
- From Class: Users need to select the class to be extracted from the drop-down list. The unavailable status in the drop-down list represent the corresponding category that does not exist in the file.
- **Output path**: Path of the output folder. After the algorithm being executed, the extracted new file(s) will be generated.

# **Extract by Elevation**

### Brief

Extract by Elevation tool can extract the point cloud data in the user-defined elevation range to a file. This function supports multiple file operations.

### Usage

Click Data Management > Extract > Extract by Elevation S

2	Select		File Name	
			LiForest.LiDat	a
Min 1	00	m Max	200	1
	nath://data/liForar	t Futurat hu	Flowetion LiDete	

- Input Data: Input one or more point cloud data files. File Format: \*.LiData.
- Min (m, default value is "100"): Users need to enter the minimum elevation value of the point cloud data to be extracted.
- Max (m, default value is "200"): Users need to enter the maximum elevation value of the point cloud data to be extracted.
- **Output path**: Path of the output folder. After the algorithm being executed, the extracted new file(s) will be generated.

# **Extract by Intensity**

### Brief

Extract by Intensity tool can extract all the point cloud data within the user-defined intensity range. This function supports multiple file operations.

### Usage

Click Data Management > Extract > Extract by Intensity

Z Select		File Name		
		LiForest,LiDat	a	
in 10	0	Max 200		
.put p	ath:/LiForest_Ext	ract by Intensity. LiData	0232	

- Input Data: Input one or more point cloud data files. File Format: \*.LiData.
- Min (default value is "100"): Users need to enter the minimum intensity value of the point cloud data to be extracted.
- Max (default value is "200"): Users need to enter the maximum intensity value of the point cloud data to be extracted.
- **Output path**: Path of the output folder. After the algorithm being executed, the extracted new file(s) will be generated.

# **Extract by Return**

### Brief

Extract by Return tool can extract all the point cloud data of the user-defined return number, and saved the data in a file. This function supports multiple file operations.

### Usage

Click Data Management > Extract > Extract by Return

2	Select	File Name
		LiForest.LiData
	Return number	First Return 🔻

### Settings

- Input Data: Input one or more point cloud data files. File Format: \*.LiData.
- **Return number**: Users need to select the return number of the point cloud data to be extracted. Click on the drop-down menu to select the return number, including: first return, last return, 2nd return, 3rd return, 4th return, and returns after 4th.
- **Output path**: Path of the output folder. After the algorithm being executed, the extracted new file(s) will be generated.

Note: If the data does not have the return number selected by the user, the extraction will not be executed.

## **Extract by Time**

#### Brief

Extract by GPS time tool can extract all the point cloud data within the user-defined GPS time range, and save them in a file.

#### Usage

Click Data Management > Extract > Extract by Time

FileList E	:/data/LiForest.LiData			,
Min Time	526494.500	Max Time	528236.625	
Start Time	526494.500	End Time	528236.625	
		)	1	
	StartTime		EndTime	[4
)utput path	: E:/data/LiForest/			[

- File List: Select the file to be processed from the drop-down list.
- Min Time: Displays the minimum GPS time value in the point cloud file selected by the user. This value does not require user settings.
- Max Time: Displays the maximum GPS time value in the point cloud file selected by the user. This value does not require user settings.
- Start Time (default value is "min Time"): Input the minimum GPS time value of the point cloud data to be extracted.
- End Time (default value is "max Time"): Input the maximum GPS time value of the point cloud data to be extracted. This value must be larger than the start time.
- 1 if you want to extract the point cloud at a specified interval, enter the interval value in the text box, and then click this button, the values of the start time and end time will increase at the set interval.
- de: Add the input time range to the range list. All point cloud data in the time range will be extracted into one file.
- E: Users can click this button to load external GPS range file. The time range in the file needs to be between the **min Time** and the **max Time**. The file format can be referred to the appendix for information in the GPS time file format.
- =: Users select a row in the time range list and click this button to remove the row from the list.
- **Output Path**: Path of the output folder. After the algorithm being executed, the extracted new file will be generated.

# **Extract by Serial Time**

### Summary

Extract by Serial Time tool helps the user to extract the points in customized GPS time period and save them to a separate file.

### Usage

Click Data Management > Extract > Extract by Serial Time.

FileList D:/Data/data/30-	11 (30_31). LiData	
FileList Filter:		
Min Time 202533.094	Max Time 202789.2	19
Start Time 202533.09 🗘	End Time	202623.62
Output path: ta/30-31 (30_31	_Extract by Serial Time.LiData	
	08	Concol

- File List: Select the file to be processed from the file list.
- File List Filter: Automatically select files to be processed based on the fields entered by the user.
- **Min Time**: Display the minimum GPS time value in the point cloud file selected by the user. This value does not require user settings.
- Max Time: Display the maximum GPS time value in the point cloud file selected by the user. This value does not require user settings.
- Start Time (default value is "Min Time"): Input the minimum GPS time value of the point cloud data to be extracted.
- End Time (default value is "Max Time"): Input the maximum GPS time value of the point cloud data to be extracted.
- Output Path: The path of the output file.

# Classify

LiPowerline can be used to classify unclassified point cloud, or to reclassify points that have already been classified.

- Classify by Attribute
- Classify Ground
- Classify Low Points
- Classify by Below Surface
- Classify Isolated Points
- Classify Air Points
- Classify by Height Above Ground
- Classify by Min Elevation
- Classify Closeby Point
- Class Conversion
- Classify Buildings
- Classify Model Key Points

# **Classify by Attribute**

#### Brief

This function classifies the point cloud into another class according to their attributes. Currently available classification attributes include Absolute Elevation, Intensity, GPS Time, Scan Angle, and Return Number. In addition, the function can restore all classes and/or reclassify the point cloud for undesirable classification results.

#### Usage



Select		File Name				
			samı	ole.LiData		
From Class		To Class:	1-UnClass	ified		
Building Ground UnClassified High Vegetation Model Key Point Select All	Medium Vegetation Powerline Never Classified Low Vegetation Low Foint Other Classes O Unselect All	Choose Att	tribute:	None <u>None</u> Absolute Elevation Intensity Time Angle Return		

- Input Data: The input file can be a single point cloud data or a point cloud dataset, which must be opened in the LiPowerline software.
- From Class: Source class(es).
- To Class: Target class.
- Choose Attribute: The selected attribute will be used to classify the point cloud.
  - None (default): The default setting will change all points in the From Class option to To Class.
  - **Absolute Elevation**: Classified by elevation range. If the elevation value of a point is between the specified range, it will be assigned to the **To Class**.
  - **Intensity**: Classified by intensity range. If the intensity value of a point is between the specified range, it will be assigned to the **To Class**.
  - **Time**: Classified by GPS time. If the GPS time value of a point is between the specified range, it will be assigned to the **To Class**.
  - **Angle**: Classified by scan angle. If the scan angle value of a point is between the specified range, it will be divided into the **To Class**.
  - **Return**: Classified by the return number. If the return number at a point is between the specified range, it will be assigned to the **To Class**.

# **Classify Ground**

### Brief

Ground points classification is an important operation of point cloud preprocessing, which can be implemented in LiPowerline with an improved progressive TIN densification filtering algorithm (Zhao et al.,2016).

The algorithm first generates a sparse triangulated irregular network(TIN) through seed points, and then iteratively processes layer-by-layer densification until all ground points have been classified. The specific steps of the algorithm are described as follows:

- 1. The initial seed point selection. If the point cloud contains buildings, the **maximum building size** is taken as the grid size to grid the point cloud, and for the point cloud without the building, the default value is used as the grid size. Take the lowest point in the grid as the starting seed point.
- 2. Build a TIN. The initial TIN was constructed using the initial seed point.
- 3. Iterative densification process. Traverse all the unclassified points, query the triangles that each point belongs to in the horizontal projection plane; Calculate the distance(d) from the point to the triangle and the max angle between the point and three vertices with the triangles plane. As shown in the figure below, the distance and max angle are compared with the **Iteration distance** and **Iteration angle**, separately. If it is less than the corresponding threshold, then the point is classified as a ground point and added to the triangulation. Repeat this process until all ground points have been classified.



The flow of algorithm is shown in the figure.



### Usage

Click Classify > Classify Ground

4	Select					File Name			
					Si	ample.LiData			
From Class		To Class:	2-Ground						
Powerline	Tower	Far an ete	r 3						
Wever Classified	VnClassified	Max Buil	ding Size:	20	m Max 1	Terrain Angle:	88		۰
Ground	Low Vegetation	Tteratio	n Angle:	30	° Tter	ation Distance:	1.6		
Building	Low Point	E Beduc	e Iteratio	n Angle When Edg	ge Length<	5	n		192
Model Key Point	Other Classes	Stop '	friangulat	ion When Idge La	ngth<	1			
🖱 Select All	🕐 Unselect All	🔄 Only	Key Point	5					
		Tolerar	ice Above [	0.15 m G	rid Size	20		m	
		Tolerar	ice Below [	0.15 m					

#### Settings

- **Input Data**: The input file can be a single point cloud data or a point cloud dataset, which must be opened in the LiPowerline software.
- From Class: Source class(es).
- To Class: Target class.
- Max Building Size (m, default value is "20"): The maximum length of the building edge that exists in the point cloud scan. If this parameter is set too small, the flat roof of the building may be mistaken as the terrain. When there is a building in the point cloud data, the maximum building size can be measured by using the Length Measurement in the menu bar. The value of this parameter should be greater than the measured value. For point cloud data without buildings, this parameter can use the default value of 20m.
- Max Terrain Angle (°, default value is "88"): The maximum slope of the terrain shown in the point cloud. This parameter can determine whether the points nearby the ground points belong to the ground or not. Usually, the parameter can be set as default.
- Iteration Angle (°, default value is "30"): The allowable range of angles between unclassified points and ground points. For areas with large topography and undulations, it can be bigger.Generally, it is set between 10 to 30 degrees. In addition, the iteration angle should adjust with the iteration distance.
- Iteration Distance (m, default value is "1.6"): Distance threshold between the unclassified points and the triangle in the triangle mesh. When the topography is highly undulating, it should be set to a larger value. The general setting is 1~2 meters. In addition, the iteration distance should adjust with the iteration angle.
- Reduce Iteration Angle When Edge Length < (m, default value is "5", Optional): When the triangle length of the points to be classified is smaller than the threshold, the iteration angle should be decreased. Use the parameter to indicate that when the point to be classified corresponds to the length of the triangle in the triangulation network is less than the threshold, the iteration angle is reduced accordingly. When a sparse ground point needs to be obtained, the threshold may be increased accordingly.
- Stop Triangulation When Edge Length < (m, default value is "1", Optional): When the triangle length of
  the point to be classified corresponds to the length of the triangle is less than the threshold, the densification
  of triangulation network is stopped. This value can prevent the locally generated ground point from being too
  dense. When this value increase, the ground points will be sparse, and vice versa.</li>
- Only Key Points (Optional): Extract key points of terrain model on the basis of ground point filtering. This function can preserve the key points on the terrain and sparse the points on the flat area. For the specific usage, please see Classify Model Key Points.

Note: Because the actual terrain is complex and changeable, when using this function to perform ground point classification, different parameters needs to be adjusted in order to achieve relatively ideal results. In addition, the classification result in local area can be reclassified by Classify Ground by Selected and the Classify by Interactive Editing tool.

```
@inproceedings{
    author={Zhao X Q, Guo Q H, Su Y J and Xue B L},
    title={Improved progressive TIN densification filtering algorithm for airborne LiDAR data in forested areas},
    booktitle={ISPRS Journal of Photogrammetry and Remote Sensing,117:79-91},
    year={2016}
}
```

# **Classify Low Points**

### Brief

The low point refers to the noise point that is lower than the actual terrain. The existence of the low point will affect the extraction of the ground point, because the progressive triangulation filtering algorithm is based on the seed points represented by the lowest point of the gridded point cloud. Therefore, filtering out the low point is a preprocessing operation, which directly affects the filtering effects, the establishment of a digital model, and the generation quality of contour lines. The triangulated terrain model created by the ground points with low points is shown below.



The distribution of low points is divided into individual points or clusters. The algorithmic flow of this function is:

- 1. Traverse the point cloud and search for points to be classified within a certain range of **radius** of the current single point or point cluster.
- 2. Calculate the maximum **height difference** between the current point and the neighboring point, which is compared with the threshold.
- 3. If the value is greater than the threshold, the current point is considered to be a low point, otherwise, it is not classified as a low point.

### Usage

Click Classify > Classify Low Points

		ļ	iFores	t,LiData	
From Class		To Class:	7-Low	Point	
✔ Never Classified Ground Medium Vegetatio Building Model Key Point	✔ UnClassified Low Vegetation n High Vegetation Low Point Water	Paramete Points N Radius: Height:	rs umber:	1 5 0.5	m
🗌 Reserved10	Other Classes				

- Input Data: The input file can be a single point cloud data or a point cloud dataset, which must be opened in the LiPowerline software.
- From Class: Source class(es).
- To Class: Target class.
- **Points Number (default value is "1")**: When the number of points is set to 1, the single low point is classified. If it is greater than 1, cluster low points are classified.
- Radius (m, default value is"5"): The radius threshold between the unclassified point and the neighboring point.
- Height (m, default value is"0.5"): The height difference threshold between the unclassified point and the neighboring point.
- DefaultValue: Click this button to set all parameters as default.

# **Classify by Below Surface**

#### Brief

This function classifies points in the initial category that are below the elevation of the surrounding neighborhood. For example, when the starting category is ground, this method can be used to classify points lower than the surface elevation to be the lower-than-the-surface point. The main algorithm idea of this function is:

- 1. Search for a certain number of nearest points for the current point in initial class.
- 2. Fit the plane with the nearest point.
- 3. Calculate the absolute value of the height difference between the current point and the plane. If the value is less than the set **Z tolerance**, it is not categorized. If it is greater than the tolerance, go to the next step.
- 4. Calculate whether the difference between the current point elevation and the average value of the neighboring points is greater than the **Limit** of the standard deviation. If it is greater than, then it is classified as the target category; otherwise, it is not classified.

#### Usage

Click Classify > Classify by Below Surface

7	File Name sample.LiData				
From Class Building Ground Tower UnClassified High Vegetation Model Key Point	<ul> <li>Medium Vegetation</li> <li>Fowerline</li> <li>Never Classified</li> <li>Low Vegetation</li> <li>Low Foint</li> <li>Other Classes</li> </ul>	To Class: [ Parameter Limit: Z toleran	8-Model Key 3 .ce: 0.1	/ Point *st m	d deviation
DefaultVelue	U UNSELECT ALL		_	OK	Green

- Input Data: The input file can be a single point cloud data or a point cloud dataset, which must be opened in the LiPowerline software.
- From Class: Source class(es).
- To Class: Target class.
- Limit (default value is"3"): The multiple of the mean squared error of the neighboring point fitting plane of the unclassified points. The larger the value, the less points will be classified into the target class.
- Z tolerance (m, default value is"3"): The threshold of height difference. The point to fit plane distance less than this value is not classified. The larger the value, the less points will be classified into target class.
- DefaultValue: Click this button to set all parameters as default.

# **Classify Isolated Points**

### Brief

This function classifies points in a certain area of point cloud, which is generally used to find outliers in the air or below the ground.

### Usage

Click Classify > Classify Isolated Points

J			
a little i		sample.LiData	
From Class	To Class:	1-UnClassified	
Ground     □ Powerline       □ Tower     ☑ Never Classi       □ UnClassified     □ Low Vegetation       □ High Vegetation     □ Low Point	fied on Radius:	umber: 3 5	m
Model Key Point Other Class	es		

- Input Data: The input file can be a single point cloud data or a point cloud dataset, which must be opened in the LiPowerline software.
- From Class: Source class(es).
- To Class: Target class.
- **Points Number (default value is"3")**: If the number of points in the neighboring radius are less than or equal to the value, the point is considered as an isolated point.
- Radius (m, default value is"5"): Neighboring search radius.
- DefaultValue: Click this button to set all parameters as default.

# **Classify Air Points**

### Brief

This function classifies points that are significantly higher than the surrounding points into airborne noise points. The idea of the algorithm is the same as the principle of Outlier Removal in the data management module.

### Usage

Click Classify > Classify Air Points

1	Select		File Name			
		sample.LiData				
From Class	Medium Vesetation	To Class:	1-UnClassified			
Ground Tower UnClassified High Vegetation Model Key Point Select All	Powerline  Never Classified  Low Vegetation  Low Point  Other Classes  Vnselect All	Taramete Neighbor Multiple	ns Points: s of std deviation:	10		
)efaultValue			0K	Cancel		

- **Input Data**: The input file can be a single point cloud data or a point cloud dataset, which must be opened in the LiPowerline software.
- From Class: Source class(es).
- To Class: Target class.
- Neighbor Points (default value is"10"): The number of neighbors that will be used to determine whether a point is a noise in the sky. Calculate the distance between each point to the nearest point and calculate the standard deviation of the nearest distances.
- Multiples of std deviation (default value is"5"): If the deviation of points beyond the minimum allowable threshold, they are considered as noise in the sky. The larger the threshold, the less the noise will be divided into.
- DefaultValue: Click this button to set all parameters as default.

# **Classify by Height Above Ground**

### Brief

This function classifies the points on the surface of the terrain with a certain height, which can quickly classify vegetation at different heights. For example, this classification can be performed three times to separate low vegetation (0-1m), medium vegetation (1-10m), and high vegetation (10-100m), see the figure below.



### Usage

Click Classify > Classify by Height Above Ground

From Class: 2 - Ground	
From Class: 2 - Ground	
	đ
Building Medium Vegetation To Class: 3-Low Vegetation	
Tower VNever Classified Parameters	
UnClassified Low Vegetation Min Height: 0 m	
High Vegetation Low Point Max Height: 1 m	
Model Key Point Other Classes	
🖱 Select All 🖉 Unselect All	

- **Input Data**: The input file can be a single point cloud data or a point cloud data set, which must be opened in the LiPowerline software.
- From Class: Source class(es).

- **Ground Class**: The default ground point is 2-class.
- To Class: Target class.
- Min Height (m, default value is "0"): The minimum height difference of the area to be classified above the ground points.
- Max Height (m, default value is "1"): The maximum height difference of the area to be classified above the ground points.
- **DefaultValue**: Click this button to set all parameters as default.

Note: This function need to contain the ground point in the cloud.

# **Classify by Min Elevation**

### Brief

This function classifies the points at a certain height within a certain radius in the source class.

### Usage

Click Classify > Classify by Min Elevation

V Selec	t		File Name	
		sa	mple.LiDat	a
From Class Building Ground Tower UnClassified High Vegetation Model Key Point	Medium Vegetation Powerline Never Classified Low Vegetation Low Foint Other Classes	To Class: ( Parameter Min Heigh Max Heigh Radius:	3-Low Veg rs at: 0 at: 1 5	etation m m m
DefaultValue			ОК	Cancel

- Input Data: The input file can be a single point cloud data or a point cloud data set, which must be opened in the LiPowerline software.
- From Class: Source class(es).
- To Class: Target class.
- Min Height (m, default value is"0"): The minimum height difference in the area to be classified above the lowest point within the radius.
- Max Height (m, default value is"1"): The maximum height difference in the area to be classified above the lowest point within the radius.
- Radius (m, default value is"5"): The radius of the area needs to be classified at the current point, which needs to be classified.
- DefaultValue: Click this button to set all parameters as default.

# **Classify Closeby Point**

## Summary

This tool can classify point clouds close to other classes. For each point in the "from class", the software looks for the point cloud in the specified 2D or 3D neighborhood, and determines whether these points meet certain conditions (such as containing a specified class). If the conditions are met, the point is classified into the "to class".

### Usage

Se	lect		File Name			
I	2		1-2(1_2).LiData			
		2-3(2_3).LiData				
oseby Class: 2,4,6,7,	16, 17, 20, 23, 27, 28,		÷	>>		
From Class	355	To Class:	1-UnClassified		3	
Never Classified	🗌 UnClassified	Search Method:	: 3D			
✓ Ground Medium Vegetation Building	Low Vegetation High Vegetation Noise	Radius	1.00			
Model Key Point	Other Classes					
) Select All	🔘 Unselect All					
DefaultValue			OK	Cancel		

Click Classify > Classify Closeby Point

### **Parameters**

- Input Data: The input data can be single or multiple, must have been opened in Lipowerline.
- Closeby Class: If class in from class is detected in neighbour area, that point will be reclassified.
- from Class
- to Class
- Search Method: Support 2D or 3D neighbourhood.
  - Radius: Neighbourhood search radius.

# **Class Conversion**

### Summary

A certain class of the point cloud can be converted into another class according to attribute characteristics in batches. Currently available tools include: absolute elevation, intensity, GPS time, scan angle and return times. If you are unsatisfied about the classification result and wish to do it all over again, you can use this tool to recover point cloud class.

### Usage

Click Plugin > Classify > Class Conversion

✓ Select		File Name	•	^
$\checkmark$		1-2(1_2).LiData		
$\checkmark$	☑ 2-3(2_3).LiData		ata	~
From Class:		Convert to Class	:	^
0-Never Class	0-Never Classified			
1-UnClassified	1-UnClassified			
2-Ground	2-Ground			
3-Low Vegeta	3-Low Vegetation			
4-Medium Ve	4-Me	dium Vegetation		
				Y

### **Parameters**

- Input Data: The input data can be single or multiple, must have been opened in Lipowerline.
- from Class
- to Class
- Attribute: Classify by attribute.

- None(by default): Change all points in "from class" to "to class".
- Absolute Elevation: Classify by absolute elevation.
- Intensity: Classify by intensity.
- **GPS time**: Classify by GPS time.
- Scan Angle: Classify by scan angle.
- **Return Times**: Classify by return times.

# **Classify Buildings**

### Brief

This function classifies buildings in point cloud data.

### Usage

Click Classify > Classify Buildings

V Select	File	Name	
	samp	le.LiData	
From Class	Ground Class: 2	- Ground	
Ground Dowerline	To Class: 6	-Building	Ċ
Tower 🔽 Never Classified	l Parameters		
UnClassified Low Vegetation	Normal Radius:	3	m
🗌 High Vegetation 🗌 Low Point	Angle Threshold :	10	٥
Model Key Point Other Classes	Elevation Toleranc	e: 0.6	m
🖱 Select All 🛛 🔘 Unselect All	Minimum Points Num	ber: 100	
	Max Slope:	60	•
	Max Building Size:	60	m

- **Input Data**: The input file can be a single point cloud data file or a point cloud dataset, which must be opened in the LiPowerline software and has already been classified by ground points.
- From Class: Source class(es).
- Ground Class: The default ground point is 2-class.
- To Class: Target class.
- Normal Radius (m, default value is "3"): The radius of the neighborhood when calculating the normal vector of each point in the point cloud. Usually set to 4-6 times the distance between points.
- Angle Threshold (°, default value is "10"): The angle threshold between two points in plane clustering. When the actual angle of two points is less than the threshold, the two points will be clustered into the same group.
- Elevation Tolerance (m, default value is "0.6"): The distance threshold from point to plane in plane clustering, which is expected to be slightly larger than the average point distance. When the actual distance is less than the threshold, the point and plane will be clustered into the same group.
- Minimum Points Number (default value is "100"): The minimum points number of building patches.
- Max Slope (°, default value is "60"): The angle between the plane and the vertical direction. Greater than this value is not considered as the top of the building but the wall or other classes.

- Max Building Size (m, default value is "60"): The maximum length of buildings, which was used for the detection of building patches between blocks.
- **DefaultValue**: Click this button to set all parameters as default.

Note: Using this function requires that the point cloud has been classified by ground points.

# **Classify Model Key Points**

### Brief

This function can thin a certain level of the classified points. It is generally used to generate a sparse point set that retains the key points in the complex terrain area and thin the points in the flat area from the extracted dense ground points.

The idea of the algorithm is: first, meshing of point cloud data, and then use the seed points in the grid to establish the initial triangulation network. According to the upper and lower boundary thresholds, the points that meet the conditions are added to the triangulation network. The process is iterated until all of the key points of terrain model are classified. In the following figure, the yellow point is the ground point and the purple point is the key point of terrain model.



#### Usage

Click Classify > Classify Model Key Points

V	Select			File Name		
			sample.LiData			
From Class: Parameters	2-Ground	•	To Class:	8-Model Key P	oint 🔻	
Tolerance Above	0.15	m Grid Size:	20			m
Tolerance Below	0.15	m				

- Input Data: The input file can be a single point cloud data or a point cloud dataset, which must be opened in the LiPowerline software.
- From Class: Source class(es).
- To Class: Target class.
- **Tolerance Above (m, default value is"0.15")**: The maximum allowable elevation tolerance value over the triangulation model composed by the original points. The larger the value, the more sparse the key points will

be extracted, and vice versa.

- **Tolerance Below (m, default value is"0.15")**: The maximum allowable elevation tolerance value under the triangulation model composed by the original points. The larger the value, the more sparse the key points will be extracted, and vice versa.
- Grid Size (m, default value is"20"): The value is used to ensure the density of key points extracted from the model. For example, if you want to ensure that there is at least one point in the grid every 20 meters, this value is set to 20.
- **DefaultValue**: Click this button to set all parameters as default.

## Rectify

2

**Brief**: This tool is used for coordinate rectification of to-be-aligned data with respect to reference data. The two datasets can be "point cloud and point cloud", "point cloud and image", or "image and image". At least 3 pairs of homologous points(or fitted spheres in point cloud) should be added in the datasets, which are displayed in separate windows, before the calculation of transformation parameters. You can evaluate the accuracy using the residuals of homologous points listed in the table window.



### Usage

#### Click Plugins > Rectify

Note: You have to create at least two display windows (except the profile window) before using this tool.

### Steps

1. Create two display windows and load the reference data and the to-be-aligned data into separate windows. Click the **Rectify** tool to open the following dialog.

Reference window: 🔽	iewer-0 🔻
Alignment window: 🔽	iewer-2 🔹

2. Select **Reference window** for the reference data and **Alignment window** for the to-be-aligned data. Then click the **Binding** button. The following table window with a series of tools pops up.



- 3. (Optional) Click the Change Datum button to exchange the reference window and alignment window, if they were mistaken.
- 4. (Optional) Click the Load Data button to load homologous points from existing file. Then you can skip the manual measurement (steps 5, 6, 7).
- 5. Click Pick Point or Pick Registration Sphere to measure a pair of homologous points (or fit a pair of spheres) in reference window and alignment window. If spheres are fitted, their centers are used as homologous points.
- 6. Click the button Add Point to add blank row for a new pair of homologous points.
- 7. Repeat steps 5 and 6 to pick at least three pairs of homologous points (or spheres).
- 8. **(Optional)** If the option Predict is checked and there exist at least 3 pairs of homologous points, the corresponding position in the reference window will be predicted after picking a point in the alignment window.
- 9. **(Optional)** The user can exclude a pair of homologous points in the calculation of transformation parameters: (1) Uncheck the row of the homologous points in the table; (2) Or click the Delete Point button after selecting the corresponding row.
- 10. **(Optional)** The user can modify the coordinates of added homologous points: (1) Pick point again in the alignment window and reference window after selecting a row of homologous points; (2) Or double click the coordinates in a row, then input new values directly.
- 11. **(Optional)** The user can view each homologous point quickly for quality check: Double click a row in the table to jump to the corresponding positions in the display windows.
- 12. (Optional) Click the Save Data button to save the homologous points to file.
- 13. Click the button Transform to calculate transformation parameters and generate aligned data.

#### Toolbar

💾 😂 🧏 🕂 🛶 Point Size: 20 枽 🗖 Predict 🕂 🌍 R=0.10m 🔮 RMS<10% 😫 🍣

Following functions are integrated in the toolbar.

Save Data: Save homologous points to file.

Load Data: Load homologous points from file (Please refer to File Format of Homologous Points).

**Solution** Change Datum: Exchange reference window and alignment window. The homologous points are also exchanged.

Add Point: Add blank row for a new pair of homologous points in the table.

**Delete Point**: Delete selected row in the table.

Point Size (Default: "20"): Point size of homologous points in display windows.

**Predict (Default: Unchecked)**: If this option is checked and there exist at least 3 pairs of homologous points, the corresponding position in the reference window will be predicted after picking a point in the alignment window.

- - Pick Point: Pick homologous points in reference window and alignment window.

Pick Registration Sphere: If target ball is used for point cloud registration, this function can fit sphere automatically after clicking the target ball in point cloud. The sphere center is used as homologous point.
 R: Radius for sphere fitting. Please input the actual radius of target ball.

**RMS**: The threshold of root mean square error for sphere fitting. Please set larger value for point cloud of low quality in case of fitting failure.

**Transform**: The coordinates are rectified based on homologous points. While processing image data, the user can specify different methods, which include polygonal correction and polynomial correction. The polynomial correction varies depending on N pairs of homologous points.

Polynomial Correction	Condition
Primary Polynomial	3 <= N < 6
Quadratic Polynomial	6 <= N < 10
Cubic Polynomial	10 <= N

# **Power Line**

To handle and analyze power line channel based on point cloud data, including Distribution Network Inspection, Point Cloud Realtime Condition, Vector Realtime Condition, Simulation Condition, Completion Acceptance, Fine Inspection, Measurement and Toolbox etc.



- Distribution Network Inspection
- Point Cloud Realtime Condition
- Vector Realtime Condition
- Simulation Condition
- Completion Acceptance
- Fine Inspection
- Measurement
- Tool Box
- Detection Result List

# **Distribution Network Inspection**

Distribution network inspection is suitable for quickly classifying and detecting the point cloud after collecting data for field operations, and generating clearance dangerous point detection reports. This module also supports generating distribution network trajectory and archiving photos. Specific functions are as below:

Point Cloud	Distributing	g Network Inspec	rtion 1	Point Cloud	Realtime	Condition	Vector Realt	tina Cana	lition Simulation	Condition	Completion Acc	eptance	Fine Inspection Plugin	ns
	1		÷ċ	2	3D	Hc	*	1		5 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	IX.		2	
Project Configuration	Mark Tower	Clip/Classify	Classify Tools ,	2D Profile	3D Profile	Class Order	Batch Processing	Clear	Multiple Directory Report	Start/End	Tower Inclination	Photo Archiving	Open Working Directory	
Configuration	Tower	Classi	fy	Profil	e Classifio	ation	Tre	e Barrier	Analysis	Trajectory	Tower Mea	Image	Tools	

- Add Data
- Settings
- Mark Tower
- Clip and Classify
- Classification Tools
- Profile Tools
- Batch Processing
- Clear
- Multiple Directory Report
- Trajectory Planning
- Measure Tower Inclination
- Photo Archiving
- Open Working Directory

# Settings

#### Summary

Power line parameter settings include common settings and detection parameter settings. Common settings include working directory, input point cloud spatial coordinate, classification and detection parameters, detected line voltage level; classify detection parameter settings include class settings, detection types, and safety distance settings.

### **Common Settings**

The user can set the working directory, input point cloud spatial coordinate, classification and detection parameters, detected line voltage level and add configuration tables. The software can record the user's last 5 input history records. User can select the most recently used item in the drop-down list. The working directory is used to manage the project. The prj.ini file in the working directory records the point cloud coordinate system, classes and detection parameters, and voltage level of the current project.

nput Point Cloud Spatial Coordinate	and the second s		
assification and Detection Parameters:	D:/work/workfile/data/test/test_zml	-	
atected Line Voltage Level	225kv		Add Configuration 7abl

- Working Directory: Used to save the intermediate and final results.
- Input Point Cloud Spatial Coordinate: The coordinate system of the point cloud data.
- Classification and Detection Parameters: Set the path of the xml format configuration file.
- Detected Line Voltage Level: The voltage level of the detected power line.
- Add Configuration Table: If the detection line voltage level list is empty and does not contain the current voltage level, user can add a new voltage level by adding a configuration table and set its safety distance detection parameters.

## **Detection Parameter Settings**

Displays key detection classes and safety distance detection parameters. User can add voltage levels and then configure their corresponding detection parameters, including clearance distance analysis and crossing analysis. Clearance detection distance analysis includes detections for different classes of objects, as well as different safety distance and distance detection methods. For scissors crossing analysis, user only needs to set the classes to be detected, and user does not need to set a safety distance.

round	1:	2-Ground	-	Low Vegetation:	3-Low Vegetation	v
edium	) Vegetation:	4-Medium Veze	station -	High Vegetation:	5-High Vegetation	~
oise:	in a <del>T</del> hursdon ann an A	7-Noise	*	Conductor:	16-Conductor	÷
ruct	ures:	17-Structure	+	Scissors Crossing U	p: 18-Scissors Crossing Up	~
isso	ors Crossing D	own: 19-Scissors C	rossing Down 🔻	Shield Wire:	20-Shield Wire	~
aina	age Thread:	28-Drainage 1	'hread 🔻	]	1	
Clea	arance Detecti	on Scissors Cro	ssing Analysis			
	Select	Class	Detection Type	Dangerous		*
1		2-Ground 🔻	Space Distant 🔻	11		
2		3-Low Vegetai ▼	Space Distan( 🔻	7		
3	1	4-Medium Veg: 🔻	Space Distant 🔻	7		
4	<b>V</b>	5-High Veget: 🔻	Space Distand 🔻	7		ш
5	V	6-Building 🔻	Horizontal/SI 🔻	5/9		
6	7	11-Railway 🔻	Space Distand 🔻	14		
7	1	12-Road 💌	Space Distant 🔻	14		
8	V	19-Scissors ( 🔻	Space Distanc 🔻	6		
9		20-Shield Wir 🔻	Space Distan( 🔻	6		-
A	dd Row Del	ete Selected Row	Add Column Delet	e Selected Column Mo	dify Selected Column Name	
					Save Sa	ve As

- Select: Whether to detect this class.
  - Checked (default): Detect the danger point in this class.
  - Unchecked (default): Do not detect the danger point in this class.
- Class: Select the number (from 1 to 32) of the class in the drop-down menu.
- Detection Type: Select the detection type in the drop-down menu.
  - **Clearance Distance**: Judge the point whether to be a danger point by the clearance distance. If the distance is less than this value, it is a danger point.
  - **Vertical Distance**: Judge the point whether to be a danger point by the vertical distance. If the distance is less than this value, it is a danger point.
  - **Horizontal Distance**: Judge the point whether to be a danger point by the horizontal distance. If the distance is less than this value, it is a danger point.
  - **Horizontal Distance / Vertical Distance**: Firstly judge the point whether to be a danger point by the horizontal distance. If the distance is less than set horizontal value, it is a danger point. If the distance is larger than set horizontal value, judge the point whether to be a danger point by the vertical distance.
  - **Horizontal Distance / Clearance Distance**: Firstly judge the point whether to be a danger point by the horizontal distance. If the distance is less than set horizontal value, it is a danger point. If the distance is

larger than set horizontal value, judge the point whether to be a danger point by the clearance distance.

- Horizontal Distance / Vertical Distance / Clearance Distance: Firstly judge the point whether to be a danger point by the horizontal distance. If the distance is less than set horizontal value, it is a danger point. If the distance is larger than set horizontal value, judge the point whether to be a danger point by the vertical distance. If the distance is less than the set vertical distance, it is a danger point. If the distance is larger than the set vertical distance, it is a danger point. If the distance is larger than the set vertical distance, it is a danger point. If the distance is larger than the set vertical distance, judge the point whether to be a danger point by the clearance distance then.
- Add Row: Add a new detection class record.
- Delete Selected Row: Delete the selected row of detection class.
- Add Column: Add a new column for a severity level threshold. I.E., severe, important, and general.
- Delete Selected Column: Delete the selected column.
- Modify Selected Column Name: Modify the name of selected column.
- Save: Save the configuration to the current xml file.
- Save as: Save the configuration as a new xml file.

Note: In crossing analysis, if user does not select the detection class, software will only analyze the upper crossing and lower crossing by default.

# **Tower Edit**

Tower editing includes Tower List, Mark Distribution Network Tower and Tower Tools. The tower list provides a single line tower marking tool that supports marking tower points and importing and exporting tower files in multiple formats. Marking distribution network towers is a tower marking and management tool provided for multiple lines in the distribution network. It supports managing tower information for multiple lines in a tree structure, automatically creating work directories, and generating tower files. Tower tools provides various tower operation related functions, such as automatically saving tower files, automatically extracting tower points, and generating tower account.

- Tower List
- Mark Distribution Network Tower
- Tower Tools

# **Mark Tower**

### Summary

After clicking in the point cloud data and choosing the tower type, user can save the result into LiTower file. After adding the position information of the tower, the software will automatically generate the index and name information of the tower. Index is a number starting from the starting value and incrementing by 1. By default, name is the same as Index. Tower type includes "None Type", "Tension Tower" and "Straight Line Tower". Double-click the row for each tower to jump to that tower in the displaying window. By checking or unchecking the checkbox in front of "Show All Tower Points" to display or hiding the tower points in the window. Point size can be modified. By clicking the hot key "S" and "D" on the keyboard to move the edited tower record forward or backward.

Name	Туре		Index	
1	Tension Tower		1	
2	Tension Tower		2	
3	Straight Line Tower		3	
4	Tension Tower		4	
5	Straight Line Tower		5	
6	Tension Tower		6	
7	Tension Tower	-	7	
8	Straight Line Tower		8	
9	Straight Line Tower	•	9	
10	Straight Line Tower	•	10	
11	Straight Line Tower	-	11	
12	Tension Tower		12	
13	Straight Line Tower		13	
14	Straight Line Tower	•	14	
15	Straight Line Tower	( <b>*</b> )	15	
16	Tension Tower		16	
17	Tension Tower		17	
18	Straight Line Tower	-	18	
19	Straight Line Tower		19	

- Show All Tower Point(checked by default): Display the tower names or indexes in the window. Uncheck this option to hide the all the tower names or indexes.
- By Index: Display the tower index.
- By Name: Display the tower name.
- **Display Mode**: In the 3D view of Mode 1, the size of the tower annotation changes with the zoom of the view, while in the 3D view of Mode 2, the size of the tower annotation remains fixed and unchanged.

- Point Size(meters)(default value is "5.0"): Set the red marker sphere and text font size of the tower.
- Start Index: The number of the first tower is set to 1 by default.

### **Mark Tower**

Click this button to start to pick the tower points. Click again to exit this function and save the current tower information to the tower.LiTower file in the working directory.

### Add Tower Backward

Add a tower record after currently selected record.

### Add Tower Forward

Add a tower record before currently selected record.

#### **Delete Tower**

Delete the current selected tower record.

#### **Modify Tower Position**

Modify the position of the selected tower.

### **Tower Centralization**

Click this button and the centralize tower window will popup. Click to select several points on the tower, and click calculate button to get the center point of the tower. Click the function button again to exit this function, and the tower information will be stored in the tower.LiTower file in the working directory.



## **Clip Point Cloud**

Clip point cloud in the view to facilitate tower marking operations.

## **Cancel Clip**

Cancel clipping point clouds in the view and restore the original point cloud view.

## **Batch Edit Tower Name**

Right-click on the "Name" column in the tower list, and the popup selection menu is shown in the figure below, including "Add Prefix", "Adding Suffix", and "Batch Editing". It can be used to add prefix, suffix, or simultaneous edit the tower names.



## **Batch Edit Tower Type**

Right-click on the "Type" column in the tower list, and the popup selection menu is shown in the figure below, including "Set As Straight Line Tower" and "Set As Tension Tower". User can modify the tower type as straight line tower or tension tower in batches.

Tvn	e	Index
100	Set As Straig	ht Line Tower
Tension	Set As Tensio	n Tower
CONTRACT AND ADDRESS OF ADDRESS ADDRES		

#### **Import Tower File**

Input the tower file and renew the tower list in LiTower, txt, csv, and kml format. If the input file is in txt or csv format, user can follow the steps below to load the tower information.

Index	• X •	Y .	z 🔹	Туре 🔻	Name 🔹	-
28			24.3.49000000	N	28	III
29	mater and-	anuanau we -	202.420000	N	29	
30		275123440.440-	3408.2993000	z	30	
31			281,950000	N	31	
32	antiat ano-	2713442 13-	361,579000	z	32	
33		anukan ka-	384.000000	z	33	
34	-000 700	271.08674.000	494,380000	z	34	+
Skip lines 1 Separator	🚔 + comment, (ASCII code:%	/header lines s Si) ESP TAB	kipped: O			

- 1. Adjust the data type for each column, and select the number of skipped rows and the type of separator.
- 2. If the input data's coordinates are in latitude and longitude, user can check the "Transform" option in tab to convert the geographic coordinates into projected coordinates.
- 3. Click "Apply" to import the tower file and renew the tower list.

#### **Export Tower File**

Export the information in the current tower list to LiTower, KML and CSV file.

.e Format: KML		
🖉 Point File:	le/data/test/NewTowerPoint.kml	4.4.4
Line File:	lle/data/test/NewTowerLine.kml	1.1.1
] Point Line File:	ata/test/NewTowerPointLine.kml	3.555

- 1. Select the export file format, including LiTower,KML and CSV format. User can choose the export types of point, line, point and line when selecting KML.
- 2. Set the output path.
- 3. Click "OK" to export the tower file.

# **Mark Distribution Network Tower**

## Summary

By managing towers according to distribution network lines, selecting tower positions through mouse interaction, selecting tower types, and saving them as JSON format files. After adding the position of the tower, the software will automatically generate default Index and Name information. The Index is incremented based on the starting value, and the Name is consistent with the Index by default. The tower types include "None Type", "Tension Tower" and "Straight Line Tower". Double click on the row where each tower record is located to jump to the corresponding tower location. Select to show/hide all branches or tower points of the selected branch through the "Show Branch" checkbox, and select to show/hide tower Connections through the "Show Tower Connections" checkbox, with adjustable point sizes. The keyboard shortcuts S and D can move the edited tower record forward and backward.

ine List	Tower List			
Branch Name	Name	Туре	Index	

- Show Branch(by default selected): By default, all branches are selected and the tower name or tower index is displayed in the window view. Uncheck to hide the tower name or tower index.
- By Index: Display the tower index.
- By Name: Display the tower name.
- Show Tower Connections(by default selected): Show tower connections in the window view, uncheck to hide tower connections.
- Point Size(meters)(default value is "0.5"): Set the size of the red identification ball and text font for the tower.
- Show Mode: In the 3D view of Mode 1, the size of the tower annotation changes with the zoom of the view,

while in the 3D view of Mode 2, the size of the tower annotation remains fixed and unchanged.

• Start Tower Index: The number of the first tower is set to 1 by default.

#### **Open File**

Open the distribution network tower file(\*.json) and refresh the line list and tower list.

#### Save File

Save line and tower information to a file (\*.json).

#### **Import File**

🔄 Import tower files (\*.LiTower \*.kml), and manually maintain the line branch relationships after importing.

#### Add Branch

Add a line branch. If no branch is selected in the line list, create a main branch. If a tower of a branch is selected, create a sub branch of that branch.

Branch Name:	×
bratten name.	
Branch Color:	
Attribute:	

Stranch Settings	×
Branch Name:	
Parent Branch Name:	*
Main Branch Name:	
Start Tower Name:	*
Branch Color:	
Attribute:	
🗌 Main Branch	OK

- 1. Branch Name: Set the name of the branch line.
- 2. Branch Color: Set the branch line color.
- 3. Attribute: Optional input of information to be recorded.
- 4. Parent Branch Name: Select an existing branch as the parent branch.
- 5. Main Branch Name: read-only status, automatically updated based on the selected parent branch, used for viewing.
- 6. Start Tower Name: Select a tower from the parent branch as the starting tower.
- 7. Main Branch: If no tower is selected for adding a branch, it is selected by default. Otherwise, it is not selected. If it is not selected, the parent branch and starting tower need to be set.
- 8. Click "OK" to create a new branch and update the line list.

## **Modify Branch**

To use this function, you should first select the branch to be modified in the line list before making any modifications. The modification items are consistent with "Add Branch".

## **Delete Branch**

Delete the currently selected branch and its subordinate branches, as well as the tower records under these branches.

## **Clear Line List**



### Add Tower Backward

Add a tower record after currently selected record.

## **Add Tower Forward**

Add a tower record before currently selected record.

#### **Delete Tower**

Delete the current selected tower record.

## **Modify Tower Position**

Modify the position of the selected tower.

### **Generate Working Directory**

Generate the corresponding working directory for each branch, and output the working directory and tower file (\*.LiTower) for each branch according to the specified output path.

10	- n ' + z'l
Merge MML	_  foint file
🗌 Generate Tower	Distance Account
Branch Start Towe	r Name Settings
🖲 Use Branch Tow	er Naming Rules
🔿 Vse Start Towe	r Index
🔘 Use Original T	ower Name
Working Directory	Folder Settings
	Name
🗌 Adjust Tower	and the second se
- 🗌 Adjust Tower • Prefix 🔿 Su	ıffix N
<ul> <li>Adjust Tower</li> <li>Prefix</li> <li>Su</li> <li>Use Second Tow</li> </ul>	uffix N er Name
Adjust Tower Prefix Su Use Second Tow utput Path:	uffix N er Name

- 1. Generate KML: It is not selected by default. If selected, a KML file will be generated, otherwise it will not be generated.
- 2. Merge KML: Not selected by default. When generating KML, selecting "Merge KML" will generate a merged KML to the output path, otherwise it will not be generated.
- 3. Point File: Not selected by default. When generating KML, selecting "Point File" will generate a point file to the output path, otherwise it will not be generated.
- 4. Generate Tower Distance Account: It is not selected by default. If selected, a tower distance account will be generated; otherwise, it will not be generated.
- 5. Use Branch Tower Naming Rules: It is selected by default. If selected, according to the naming rules for branch line towers, set the name of the starting tower for the branch line.
- 6. Use Start Tower Index: It is selected by default. If selected, use the starting tower index of the branch line as the tower name.
- 7. Use Original Tower Name: It is not selected by default. If selected, use the tower name from the previous level of the line as the starting tower name for the branch line.
- 8. Adjust Tower Name: It is not selected by default. If selected, set the prefix or suffix of the tower name in the working directory folder name.
- 9. Use Second Tower Name: It is not selected by default. If selected, Check this option to use the name of the second tower as the starting tower name for lines with parent branches. In other cases, use the name of the first tower as the starting tower name.
- 10. Output path: Select the output path.
- 11. Click "OK" to output the working directory and specify the output file.

### **Batch Clip Section**

Batch clip point cloud data based on the marking results of the distribution network towers. The

functional interface is shown in the following figure, click to add pending data, click to remove the selected data, click selected data, click selected data, click selected data, click to clear the data list.

Data File	Log		
F:/Data/Se	ctionData/9-10(9_10	).LiData	^
F:/Data/Se	ctionData/8-9(8_9).L	Data	بالأبر
F:/Data/Se	ctionData/7-8(7_8).L	Data	
F:/Data/Se	ctionData/6-7(6_7).L	Data	
F:/Data/Se	ctionData/5-6(5_6).L	Data	
F:/Data/Se	ctionData/4-5(4_5).L	Data	
F:/Data/Se	ctionData/3-4(3_4).L	Data	
F:/Data/Se	ctionData/2-3(2_3).L	Data	
F:/Data/Se	ctionData/16-17(16_	17).LiData	. 🥌
F:/Data/Se	ctionData/15-16(15_	16).LiData	~
Clip Parame Channel Wid Point Cl	ters th: 60.00m 0 oud Compression	Segment Buffer: 10	.00m 0
Root Direct	ory:		
		Start	Exit

- Channel width(meters)(default to "60"): The width that extends along the direction of the power line towards both sides. The software can record the user's current settings and automatically restore them when opened again.
- Extension length(meters)(default to "10"): The extension distance at both ends of the tower.
- Point cloud compression(not selected by default): Perform thinning on the processed data.
- Root directory: Set the output root directory.

## **Batch Edit Tower Names**

Right click on the "Name" column header of the tower list, and a selection menu will pop up as shown in the following figure, including "Add Prefix", "Adding Suffix", and "Batch Editing". It can be used to add prefix, suffix, or simultaneous edit the tower names.

Na	T
	Add Prefix
	Add Suffix
	Batch Editing

## **Batch Edit Tower Types**

Right click on the "Type" column header of the tower list, and a selection menu will pop up as shown in the following figure, including "Set As Straight Line Tower" and "Set As Tension Tower". User can modify the tower type as straight line tower or tension tower in batches.

ame	Type	Index	Att
tinica	Set	t As Straight Line Tow	/er
	Set	As Tension Tower	

# **Tower Tools**

## Auto Save Tower File

Set a time interval to automatically save tower files and prevent tower data loss due to unexpected situations.



## **Reverse Sequence Of Tower**

Automatically reverse the list of towers and save it to the specified file.

### **Extract Tower Point**

Interactive extraction of tower point: Manually select the area where the target line is located and automatically extract tower point within that area. Commonly used in scenarios where multiple lines are parallel, try to avoid including other lines when selecting boxes.

Automatic extraction of tower points: Using input point clouds for classification, clustering the tower point clouds and extracting tower point. The extracted tower point can be sorted based on the wire connection relationship between the towers.

Extract Tower	Point	×
<b>a</b> %		

Data File	Log				
D:/work/w	orkfile/data/test/	data/20-21(2	20_21).LiData		
D:/work/w	orkfile/data/test/	data/19-20(*	19_20).LiData		
					TTP.
					1
					i.
Sort					
Start Tower	Index: 1	•	Cluster Radius:	4.00m 🗘	
Similar Rat	io: 0.50	-			
				-	- 1
	-321:14		Default	Start	Exit

- Set Parameters
  - Sort: Whether to sort, if not checked, default sorting will be used.
  - **Start Tower Index**: The starting value of the tower number is incremented in sequence for subsequent tower numbers.
  - **Cluster Radius(meters)(default value is "4.00")**: The clustering radius of tower point clouds is generally set as the minimum distance between towers.
  - **Similar Ratio**: The height similarity of the same series of towers is generally the ratio of the minimum height to the maximum height of all towers.
  - Threads Num(4 by default): Set the number of thread when running the tool.
  - Default: Restore default parameter settings.

#### **Extract Tower Points Based On Photos**

Automatically extract tower points based on photos. The functional interface is shown in the following figure, which can process multiple data simultaneously. Click to add pending data, click to remove the selected data, click to clear the data list.

Data File L	og		
			÷
			/
/ LiTower	5	Z KML	
utput Path: /wo	rk/workfile	/data/test/	11.11
	0%	OK	Concol

- Set Parameters
  - **LiTower**: Selected by default. Select to output the LiTower file. If not selected, the LiTower file will not be output.
  - KML: Selected by default. Select to output the KML file. If not selected, the KML file will not be output.
  - Output Path: Set the output path of the analysis result file, which defaults to the working directory.

#### **Calibrate Tower Point Position**

Automatically calibrate the position of tower points. To use this function, the tower points should be classified first before calibration.

### **Tower Material Type Settings**

Edit the material type of the tower, which can be opened and saved as a file (\*. txt). The file is applied to Measure Tower Inclination.

х <u>т</u>	ower Material Typ	e Settings			1 and
	Tower Index	Tower Name	Tower Material		^
1	1	1	Angle Steel Tower		
2	2	2	Angle Steel Tower		
3	3	3	Angle Steel Tower	Ŧ	
4	4	4	Angle Steel Tower		
5	5	5	Angle Steel Tower		
6	6	6	Angle Steel Tower		
7	7	7	Angle Steel Tower	Ť	
8	8	8	Angle Steel Tower		-

## **Tower Account**

Generate a tower account file.

# Clip/Classify

## Summary

Clipping and classifying the point cloud data into segments. The classification process will classify the tower, conductor, shield line, insulator, drainage thread, scissors crossing line, ground, vegetation, buildings, road, and water in the point cloud. This function can process multiple data simultaneously. Click to add the data to be processed. Click to remove the selected data. Click to clear the data list.

## Usage

Click Clip/Classify > Clip and Classify.

Data File Log	fy s					
D:/Data/Section D:/Data/Section D:/Data/Section D:/Data/Section D:/Data/Section D:/Data/Section	Data/6-7(# 1Data/5-6(# 1Data/4-5(# 1Data/2-3(# 1Data/2-3(# 1Data/1-2(# 1Data/0-1(#	*6_#7).LiData *5_#6).LiData *4_#5).LiData *2_#3).LiData *1_#2).LiData *0_#1).LiData *3_#4).LiData				다. 
☑ Clip				🗹 Classify		19
Clip Parameter Channel Width: Start Tower Inde Point Cloud C	Classify x: compression	Parameter 50 0	m	Segment Buffer: End Tower Index:	7	m
butput Path; D:	/Data/Secti	onData/				]

☐ Clip				🗹 Classi fy		
Clip Parameter	Classify Parameter					
] Shield Line Ground	Insulstor And Dr	ainage Thread	🗹 Sei ss	ors Crossing Vp 🔽	Scissors Crossir	ng Down 🗸 Noise
Max Building Si	ze: 20	n		Max Terrain Angle:	88	•
Iteration Angle	: 8	•		Iteration Distance:	1.4	m
🗹 Reduce Itera	tion Angle when Edge Ler	ngth < 5			m	
🗹 Stop Triangu	lation when Edge Length	٤ 2			m	
🗌 Buildings —				🔽 Other Lines		
Building Class:	6-Building			Other Line Class:	23-Other Line	
🗌 Water				🗌 Hi ghway		
Water Class: 9	Temporary Building		~	Highway Class: 12	-Road	*
☐ Process Overla	uping krea					
utput Path: D./	Data/SectionData/					
eads Num (1-32)	1				Infaul+ Val	ne Start Frit

## Settings

- Output Path: Set the output path.
- Clip (Checked by default): Clip the data into segments. If this option is unchecked, the data will not be clipped.
  - **Channel Width (meter) (default value is "60")**: Width extending along both sides of the power line. The software can record the user's current settings and automatically restore the settings when opened again.
  - Segment Buffer (meter) (default value is "10"): Extension distance at both ends of the transmission tower.
  - **Start Tower Index**: Towers with index numbers smaller than this value do not participate in gear shifting. The default value is the minimum Index in the tower file.
  - **End Tower Index**: Towers with index numbers greater than this value do not participate in gear shifting. The default value is the maximum Index in the tower file.
  - Point Cloud Compression (Unchecked by default): Resampling the processed data.

• Classify (Checked by default): Using deep learning classification strategies to classify categories such as towers, conductors, shield lines, insulators, drainage thread, scissors crossing up, scissors crossing down, other lines, buildings, water, highway and noise.

- Shield Line: Classify shield lines.
- Insulator And Drainage Thread: Classify insulators and drainage threads, with this option available for voltage levels of 35kV and above.
- Scissors Crossing Up: Classify scissors crossing up.
- Scissors Crossing Down: Classify scissors crossing down.
- **Noise**: Classify noises.
- Ground Points: Please refer to the classify ground tool for details.
- Buildings: Classify building points.
- Other Lines: Classify parallel lines.
- Water: Classify water points.
- Highway: Classify road points.
- Process Overlapping Area(Checked by default): Process the overlapping areas between segments in the section data to ensure consistent point cloud categories; If not checked, the point cloud in the overlapping

area of adjacent segment data may flicker during browsing due to inconsistent categories.

- Threads Number (default value is "6"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.
- **Default Value**: Restore the default parameter settings.

Note: The segmented data will be stored in the output path folder. The name of the file will be (Smaller Tower Index\_Larger Tower Index). In order not to impact the following steps, it is highly recommended not to change the file name. After the automatic classification, user need to check the accuracy of the result and manually modify it in the Profile Tools.

# **Classification Tools**

## Summary

Classification tools are mainly used to automatically classify the point cloud in different classes. The tool set includes classify ground, classify by attribute, classify low points, classify by below surface, classify isolated points, classify by height above ground, classify by min elevation, classify buildings, and classify model key points.

- Classify by Attribute
- Classify Ground
- Classify Low Points
- Classify by Below Surface
- Classify Isolated Points
- Classify Air Points
- Classify by Height Above Ground
- Classify by Min Elevation
- Classify Buildings
- Classify Model Key Points

# **Batch Detection and Analysis**

### Summary

According to the tower file, the point cloud is processed in a procedure of detection and analysis, and the dangerous point detection and scissors crossing analysis are carried out in sequence, the dangerous point image and report are generated. The detection and analysis batch processing interface is shown in the figure below. This function can process multiple data at the same time. Click to add data. Click to remove data selected(remove the first record of the list if no data is selected). Click to clear data list.

## Usage

\* Batch Processing × Function Option 🗹 Analysis Report Clearance Danger Point: 🗹 Analysis 🗹 Report Scissors Crossing: Vector File: v Data File Danger Point Scissors Crossing Image Report Log + Threads Number(1-32) 4 . Default OK Cancel

Click Distributing Network Inspection > Tree Barrier Analysis > Batch Processing

#### **Parameters**

- Clearance Danger Point Detection: Run Clearance Danger Point Detection.
  - Analysis(checked by default): Detect dangerous clearance points based on the set safety distance threshold.
  - Report(checked by default): Generate clearance danger point detection report.
- Scissors Crossing Analysis: Run Scissors Crossing Analysis.
  - Analysis(checked by default): Perform scissors crossing analysis based on the set parameters.
  - Report(checked by default): Generate scissors crossing analysis report.
- Vector File: Input the vector file in shp format. The software can record the user's current settings and user can restore the settings in the drop-down menu or select button next time when opening this function.
- **Simulation File**: Input the simulation file (\*.LiSim file). The software can record the user's current settings and user can restore the settings in the drop-down menu or select button next time when opening this function.
- Clearance Danger Point Detection: Parameters in Danger point detection
- Scissors Crossing Analysis: Parameters in Scissors Crossing Analysis
- Generate Image: Parameters in Generate Image
- Generate Report: Parameters in Generate Report
- Log: Show log of processing.
- Threads Number(4 by default): To set the number of running threads, can support 1-32 threads. The software can record the user's current setting and automatically restore the setting when it is opened again.
- Default: Recover default settings.

Note: If user opens the function from the vector real-time working conditions module, user needs to set the vector file; if user opens the function from the simulation working conditions module, user needs to set the working conditions simulation file.

# **Generate Image UI**

#### Summary

The UI for image generating.

Image Parameter				
🗹 Scale Factor:	1	🗌 Color Setting:		
Front View Width:	1000 p	x Front View Height:	450	рх
Top View Width:	1000 p	x Top View Height:	350	рх
Profile Thickness:	0.0000 m	Prefix of Tower:		
Suffix of Tower:		Point Size:	1	-
🗌 True Color		🗌 Use EDL Effect		
Subsampling)				
X Size: 0.5		m Y Si	ze: 0.5	m
Z Size: 0.1		m		

- Image Parameter:
  - Scale Factor(checked by default): The scale for the generated image.
  - Color Setting: Set the color of the different classes of point cloud.
  - Front View Width (pixels) (default is "1000"): Front view width in pixel.
  - Front View Height (pixels) (default is "450"): Front view height in pixel.
  - Top View Width (pixels) (default is "1000"): Top view width in pixel.
  - Top View Height (pixels) (default is "450"): Top view height in pixel.
  - Profile Thickness(meter) (default is 10): Profile thickness of the images.
  - Prefix of Tower: Prefix of the tower name.
  - Suffix of Tower: Suffix of the tower name.
  - True Color(unchecked by default): Generate images based on true color of point clouds.
  - Use EDL Effect(unchecked by default): Generate images using EDL enhancement effects.
- Subsampling(unchecked by default): Set whether to resample the point cloud.
  - Grid size X, Y, Z (meters) (default is "0.5, 0.5, 0.1"): Construct a three-dimensional voxel of X YZ, one point is reserved in each voxel.

# **Generate Report UI**

### Summary

The UI for report generating.

Report Name:				
Assessor Company:	El Bu	ectrical Transmission reau/Company:		
Line Name:	123			
Collection Date:	2024/04/26	Calculate H	)y Week	Seconds
Voltage Level:	10kV			Ŧ
Point Cloud Coordinate:	WGS 84 / UTM zone	48N	•	
Target Coordinate:	WGS 84		•	
Report Path:	D:/data/			

- Report Name: The title of the report.
- Assessor Company: The company which generates the report.
- Electrical Transmission Bureau / Company: The name of power supply bureau or company.
- Line Name: Line name.
- Collection Date: The date on which point cloud was collected.
- Calculate By Week Seconds: Point cloud collection time is calculated by weeks seconds.
- Voltage Level: Cannot be changed by user.
- Point Cloud Coordinate: The point cloud coordinate system used in the report.
- Target Coordinate: The coordinate system used in the report.
- **Report Path**: The output path of the report.

# Clear

### Summary

Clear the results of quick report of danger points, cross over detection, etc. The clear interface is shown in the following figure. This function can clear multiple data simultaneously. Click to add point cloud data to be deleted. Click to remove the first item from the list (when there is no data selected)/selected data. Click to clear the data list.

Data File Log		
		<b>P</b>
		iteen a
		/
Clear File		/
Clear File ☑ Clearance Danger	Scissors Crossing	/
Clear File ☑ Clearance Danger Clear Attribute	Scissors Crossing	
Clear File ☑ Clearance Danger Clear Attribute ☑ Clear Danger Attribute	Scissors Crossing	

#### Usage

Click Distributing Network Inspection > Tree Barrier Analysis > Clear

- Clear File
  - Clearance Danger: Check to clear clearance danger files in the project directory.
  - Scissors Crossing: Check to clear scissors crossing files in the project directory.
- Clear Attribute
  - Clear Danger Attribute: Check to clear danger attribute.
- Threads Number (default value is "4"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.

# **Multiple Directory Report**

### Summary

Based on the original reports, the software can merge the reports automatically. This is especially suitable for the scenarios such as batch data processing and cross projection band data processing. Click - to add the working directories need to be processed. Click — to remove the selected working directory. Click / to clear the working directory list. Click the list item to confirm the working directory information.

fulti Vork Directories Log		Basad on Point Cloud	O Based on Var	tor Tata	) Based on Simulation I	1070
inse chors va⊁ duretarise: Files View: > DyData	#	Detection Type Clearance Danger Generate Report	Scissors Crossing	□Tree Fall	🗌 Tree Growth	
	1	Assessor Company: Line Name: Collection Date:	2024/04/19	Electrical Bureau Valtage Level:	i. Jakv	
		Target Coordinate: Report Fath:	WS 84 8 /Bata/		· · · ·	
	5	Other Display in Degrees(lat	citude and Longitude)			
Flease click item and confirm infonation Start Tower Name: Ind Tower Name:						

## **Confirm information**

After adding the working directories, click the list item to confirm the working directory information.

- Start Tower Name: The name of starting tower.
- End Tower Name: The name of ending tower.
- Point Cloud SRS: The coordinate system of the point cloud.

- **Data Type**: Select the data type to be processed. The data type includes point cloud based data, vector based data, and data based on working conditions simulation. The software can record the user's current settings and automatically restore the settings when opened again.
  - Based on Point Cloud: Extract the powerline data from the original point cloud data.
  - **Based on Vector Data**: Extract the powerline data from the vector file, and other classes objects from original point cloud data.
  - **Based on Simulation Data**: Extract the powerline data from the simulation file, and other classes objects from original point cloud data.
- **Detection Type**: User can select multiple options. Set the detection type, and generate corresponding reports.
  - Clearance Danger: Clear the clearance danger point detection result in the cache folder.
  - Scissors Crossing: Clear the scissors crossing point detection result in the cache folder.
  - Tree Fall: Clear the tree fall detection result in the cache folder.
  - Tree Growth: Clear the tree growth detection result in the cache folder.

- Generate Report: Set the parameters for report generation.
  - Assessor Company: The company which generates the report.
  - Electrical Bureau: The name of power supply bureau or company.
  - Line Name: The name of the power line section.
  - Voltage Level: Cannot be changed by user.
  - Collection Date: The date on which point cloud was collected.
  - Target Coordinate: The coordinate system used in the report.
  - Report Path: The output path of the report.
- Other:
  - **Display in Degrees(Latitude and Longitude)**: The coordinates are displayed in longitude, latitude, or radians.
- Simulation File: If user choose to generate the report based on the simulated working conditions data, it is required to set the simulation file (\*.LiSim file).

Note: To ensure the order of automatic merge, please add the working directories in order.

# **Distribution Network Inspection**

## Summary

Distribution network inspection module allows users to configure inspections, interactively select tower component points, and automatically generate distribution network inspection trajectory through software.

## Usage

Click on the "Distribution Network Inspection" tab to open the menu, click the "Start/End" button to expand the menu of trajectory planning, as shown in the following figure.



- File Menu
- Trajectory Menu
- Waypoint
- Tools Menu
- Setting

# **Distribution Network Trajectory Operation**

## Summary

The distribution network trajectory menu is shown in the following figure, which includes functions such as clip tower, generating distribution network trajectory, model generating trajectory, and safety analysis.



**Clip Tower** 

## **Generate Distribution Network Trajectory**

The dropdown menu also includes generating channel trajectory, generating point cloud data collection trajectory, interactively generating trajectory, and merging/splitting trajectory files.



Generate Distribution Network Trajectory

Generate Channel Trajectory

Generate Point Cloud Data Collection Trajectory

## **Generate Trajectory With Interactive Method**

Pick the photo point with the mouse, and then add waypoints based on the scene direction to generate trajectory.
🖲 ådd In Order				
🔘 Aug in ofder 🔘 Insert After Se	lected Point			
Automatic Waypoint	Generation -			
🗹 Take Photo		📃 Safety	Analysis	
Camera Type: Phant	om 4 RTK(4:3	)	- E	dit Waypoint
Shooting Distance:	5.00m	* Wavr	oint Snee	d 3 00m/ *

- Add Method: Set the order of waypoint addition.
  - Add In Order: After selecting, add waypoints in order.
  - Insert After Selected Point: After selecting, insert a waypoint after the selected waypoint.
- Automatic Waypoint Generation:
  - **Take Photo**: Check to generate waypoints with photo information. Uncheck to generate auxiliary waypoints and tower crossing waypoints, etc.
  - Safety Analysis: Check to perform real-time safety analysis when adding waypoints.
  - Camera Type: Set the camera type. By default, it is read from the camera configuration.
  - Edit Waypoint: Click to jump to the edit waypoint function.
  - Shooting Distance: Set the distance from the waypoint to the photo point.
  - Waypoint Speed: Set waypoint speed.
- Select Point Cloud With Ctrl:Click the Ctrl key to pick up the photo point again with the mouse and modify the current waypoint position.

### Merge/Split Trajectory Files

Merge and split distribution network trajectory files in different ways.Click to add trajectory files. Click to remove the selected vector data(remove the first record of the list if no data is selected). Click to clear data list. Click to sort the trajectory files by tower names.

- Options:
  - **Merge(Trajectory Without Part Points)**: Merge multiple trajectory files in the order of the file list, and the merged number of waypoints should not exceed the maximum number of waypoints.
  - **Split(By Tower)**: Split the trajectory according to the principle of the closest horizontal distance between the waypoint and tower position, and save the trajectory file in the output directory.
- Merge Parameters:
  - **Maximum Waypoints Count**: Set the maximum number of merged waypoints, and when it exceeds the maximum number of waypoints, the log will prompt and output.
- Output Path: When merging, set the path to the merged file. When splitting, set the output folder.

Trajectory Files Log	
	-
Options • Merge(Trajectory Without	Part Points) O Split(By Tower
Merge Parameters	
Maximum Waypoints Count: 15	5
Maximum Waypoints Count: 15 utput Path: /FineInspection/#	5 : MergedTrajectory.json

Generate Distribution Network Tower Trajectory(Surround Method)

From Model

Generate Trajectory Model

Safety

# **Measure Tower Inclination**

### Summary

By selecting the top and bottom points on the tower, calculate the tower inclination rate and the tower height along the line direction and vertical line direction. And save the result in the specified directory.

### Usage

Click Measurement > Measure Tower Inclination





### **Tower Point List**



, ,



1.1.1

Add bottom tower points.

Delete selected the tower points.

Y Modify the selected tower point.

Clear tower points. This function includes "Clear Top Points", "Clear Bottom Points", and "Clear All Points".

# Calculate

Calculate the tower inclination according to the picked points. And display the result in the result list.

#### **Result List**

Open the tower inclination file.

Save the tower inclination file. The default position to save the information is the "TowerInclination.txt" file in the tower analysis folder in the working directory.

Delete the selected record.

Clear the records in the list.

6

Import automatic calculation result of tower inclination.



Auto Calculate Tower Inclination.



Calculate Qualification By Specification.

#### **Parameters**

- Tower Name: Name of the target tower.
- Tower Height(meters): The tower height information fetched from the point cloud data.
- **Tilt Rate of Line Direction**: The inclination of the transmission tower along the main direction connecting with the next transmission tower.
- Tilt Rate of Vertical Line Direction: The inclination of the tower along the direction perpendicular to the main direction of the line connecting to the next tower.
- Standard Value: If tower tilt rate is lower than this value, this tower is consider qualified.
- Tilt Direction of Line Direction: Tilt direction of line direction of the tower.
- Tilt Direction of Vertical Line Direction: Tilt direction of vertical line direction of the tower.
- Qualification: Does the calculation result meet the standard value.

#### **Auto Calculate Tower Inclination**

#### Summary

Analyze and calculate the tower with the selected point cloud data, automatically calculate the tower tilt parameter and save it to the result list. The function interface is shown in the following figure, which can process multiple data at the same time. Click to add data. Click to remove data selected. Click to clear data list.

Data File Log		
D:/work/workfile,	/data/test/data/19-20(19_20).LiData	
D:/work/workfile/	/data/test/data/18-19(18_19).LiData	
		+
		-
Parameter		
Tower Body Class:	17-Structure	•
Layer Height:	0.30m	<b></b>
Tower Width:	40.00m	\$

### **Parameters**

- Tower Body Class: Pole point cloud category number.
- Layer Height(meters): Calculated layer height.
- Tower Height(meters): Set tower height.

### **Tower Inclination Report**

Save the tower inclination file and generate the report.

Tower Inclination R	eport	
Data File Log		
D:/work/workfile/da D:/work/workfile/da	ata/test/data/19-20(19_20).LiData ata/test/data/18-19(18_19).LiData	+
		1
Generate Report	Angle	
Assessor Company:	Electrical Transmission Bureau/Company:	
Line Name:	11	
Target Coordinate:	₩GS 84 🗸	•••
Report Path:	ork/workfile/data/test/AnalysisReport/	
	Start	Exit

### Parameters

#### Please refer to Report Parameters for details.

Note: Before using this tool, user needs to classify the transmission tower in the point cloud.

Note: The tower tilt rate is the percentage of the ratio of the tower tilt value S to the height above the ground H; that is, the tilt rate = the tilt value / the entire height of the tower.

# **Open Working Directory**

# Summary

Open the working directory of the current power line project.

# **Point Cloud Realtime Condition**

To handle and analyze power line channel based on point cloud data and to generate analysis report. Specific functions are as below:

Point Cloud	Distributing	Retwork Inspect	ion Point Cl	loud Realti	as Conditi	on. Ver	tor Reality	ne Canditi	on Simil	stim Cm	dition Comp	Letion Acce	phanne Zine	Inspect	ion P	lugins		
Project	Mark	Information	Clip/Classify	Classify	20 2D	30 3D	Hc	Danger	¥ Scissors	() Water	Batch	) Tree	Tree Growth	Tree	<b>S</b> Clear	Image	Report	Multiple Directory
Configuration	Tower	-		Tools .	Profile	Profile	Order	Points	Crossing		Processing	Growth	Warning	Fall				Report
Configuration	Tower	Collection	Clip/Clas	sify	Profil	e Classific	ation		Realtim	e Analysis		Early	Warning Analy	sis			Report	£

- Add Data
- Settings
- Mark Tower
- Information
- Clip and Classify
- Classification Tools
- Profile Tools
- Danger Points Detection
- Scissors Crossing Analysis
- Water Analysis
- Batch Processing
- Tree Growth Analysis
- Tree Growth Warning Analysis
- Tree Fall Analysis
- Clear
- Generate Image
- Generate Report
- Multiple Directory Report

# **Line Information Collection**

Line information collection includes line name, power line type, collection time and working condition parameter.

- Line Name
- Power Line Type
- Collection Time
- Working Condition Parameter

# Line Name

# Summary

Set the line name of current line.

1		**6*
Line Na	ame:	
		a 1

# **Power Line Type**

# Summary

Select the transmission tower type (straight line tower / tension tower) and then set the line type between each two towers. Save the power line type file.

# Usage

Click Collection > Information > Power Line Type.

🎘 Power Line Type	- 🛈 🙆	
Start Tower Name	End Tower Name	Power Line Type

# **Open File**

Open the power line type file

## Save File

Save the power line type file. The default output path is the information folder in the working directory. The results are in the "SectionPowerLineType.csv" file.

## Add Power Line Type

Add a new power line type, and set the start and end transmission towers name.

	1	100
Start Tower Name:	28	Ť
End Tower Name:	57	್
Power Line Type:	ACSR-720/50	-
	OK C	ancel

# **Delete Power Line Type**

Delete the selected power line type.

# Modify Power Line Type



Modify the selected power line type.

# **Check Availability**

Check if there is any overlap in the power line type of different tower sections.

# **Collection Time**

# Summary

Set the collection time in different tower sections. Save the collection time file.

# Usage

Click Collection > Information > Collection Time.

Calledon Calledon Calledon	
----------------------------	--

# **Open File**

Open the collection time file.

### Save File

Save the collection time file. The default output path is the information folder in the working directory. The results are in the "CollectionTime.csv" file.

# **Add Collection Time**

Set the start and end transmission towers name, and set the collection time.

Collection Tim	ne Sett	ing				×
Start Tower Name:	10					
End Tower Name:	13					+
Collection Time:	2019	-	12	-	25	
		OK		0	ancel	Ļ

# **Delete Collection Time**

Delete the selected collection time.

# **Modify Collection Time**

Modify the selected collection time.

# **Check Availability**

Check if there is any overlap in the collection time of different tower sections.

# **Working Condition Parameter**

# Summary

Set the working condition parameter in different tower sections. Save the working condition parameter file.

# Usage

Click Collection > Information > Working Condition Parameter.

Start Tower Name	End Tower Name	Scanning Condition Wire Temperature(%)	Scannir
------------------	----------------	--	---------

#### **Open File**

Open the working condition parameter file.

### Save File

Save the working condition parameter file. The default output path is the information folder in the working directory. The results are in the WorkingConditionParameter.csv file.

### Add Working Condition Parameter

Set the start and end transmission towers name, and set the working condition parameter.

tart Tower Name:	#0			
nd Tower Name:	#7			
-Scanning Conditio	ons		i ons	
Wire Temperature:	0.00°C	🗧 🛛 Wire Temperature:	20.00°C	\$
Ice Thickness:	10.00mm	Ice Thickness:	0.00mm	\$
Wind Speed:	0.00m/s	Wind Speed:	10.00m/s	\$

# **Delete Collection Time**

Delete the selected working condition parameter.

# **Modify Collection Time**

Modify the working condition parameter.

# **Check Availability**

Check if there is any overlap in the working condition parameter of different tower sections.

# **Danger Points Detection**

#### Summary

Judge if the point is a danger point according to the clearance distance and the set safety distance. The interface of the clearance danger point detect function is shown as follow. This function can process multiple data simultaneously. Click to add the data to be processed. Click to remove the selected data(remove the first record of the list if no data is selected). Click is to clear the data list.

# Usage

#### Click Realtime Analysis > Danger Points

			60 XX55 W		-
W:/Users/XDF/Des	ktop/Data/dat	a/40-41(40_41)	LiData		-
W:/Users/XDF/Des	ktop/Data/dat	a/39-40(39_40)	.LiData		
W:/Users/XDF/Desk	ktop/Data/dat	a/38-39(38_39)	.LiData		
					1
Detection Parameter					
🗌 Cluster By Class					
Cluster By Class Win Distance:	0.3	m	Safe Distance:	fer to the xml	file!
Cluster By Class Min Distance: Cluster Threshold:	0.3 15	n	Safe Distance: Max Cluster Range:	fer to the xml 20	file!
Cluster By Class Min Distance: Cluster Threshold: Vector File:	0.3 15	m	Safe Distance: Max Cluster Range:	fer to the xml 20	file! m

#### **Settings**

- Detection Parameter:
  - Cluster By Class(Unchecked by default.): Used to control whether to cluster the result by class. If this option is checked, the danger points will be clustered into different groups if they are in different classes; otherwise, the class information will not influence the clustering process. The software can record the user's current settings and automatically restore the settings when opened again.
  - **Min Distance (meters) (default value is "0.3")**: Points with clearance distance less than this distance are not detected as danger points, as they are considered to be noise. The software can record the user's current settings and automatically restore the settings when opened again.

- Safe Distance (meter) (default value is "4.5"): If the distance between the detected point and the power line point is greater than the minimum distance and less than or equal to the safe distance, the point is considered to be a danger point. If the xml file is not set, user needs to enter the safety distance; otherwise, this parameter is extracted from the xml file. When using the xml to set the parameter, user can set different safety distances for different classes, and for different severity level.
- Cluster Threshold (meter) (default value is "15.0"): The maximum spatial separation distance when the detection results are clustered. This value should be smaller than the maximum clustering range. Three-dimensional Euclidean clustering is used to cluster the danger points. The software can record the user's current settings and automatically restore the settings when opened again.
- Max Cluster Range (meters) (default value is "20.0"): After the detection results are clustered, if the length along the power line direction is greater than this value, they are divided into multiple dangerous point clusters. The software can record the user's current settings and automatically restore the settings when opened again.
- Vector File: Input the vector file in shp format. The software can record the user's current settings and user can restore the settings in the drop-down menu or select button next time when opening this function.
- **Simulation File**: Input the simulation file (\*.LiSim file). The software can record the user's current settings and user can restore the settings in the drop-down menu or select button next time when opening this function.
- Threads Number (default value is "4"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.
- Default Value: Restore the default parameter settings.

Note: After the analysis, user can check the result accuracy in Clearance Danger Point List.

Note: If user opens the function from the vector real-time working conditions module, user needs to set the vector file; if user opens the function from the simulation working conditions module, user needs to set the working conditions simulation file.

# **Scissors Crossing Analysis**

# Summary

Calculate the scissors crossing point by cross analysis on the power line and the detected classes of points. The interface of scissors crossing analysis is shown as follow. This function can process multiple data simultaneously. Click to add the data to be processed. Click to remove the selected data(remove the first record of the list if no data is selected). Click is to clear the data list.

# Usage

Click Realtime Analysis > Scissors Crossing

Data File	Log					
,						
D:/work/w	/orkfile/	/data/test/data/2	20-21(20_21).	LiData		
D:/work/w	/orkfile/	/data/test/data/1	9-20(19_20).	LiData.		
						西市
						_
						1
		22				
Jetection I	aramete	if			1272	-12
Cluster Rad	lius: 3.	.0	m	Buffer Size	e: 0.5	m
Add Dang	ger Poin	its into Calculat	tion	Split C	rossing Line	
	6				~	
Vector File						
Vector File			10.0			20072

# Settings

- Detection Parameter:
  - **Cluster Radius (meter) (default value is "3.0")**: The maximum spatial distance when clustering crossing points. The crossing point clusters in the range extract the nearest vertical distance point as the crossing point of the cluster.
  - **Buffer Size (meter) (default value is "0.5")**: The power line point cloud in a certain buffer area near the horizontal range of cross line will participate in the calculation.
  - Add Danger Points into Calculation(unchecked by default): Add danger points to the analysis and calculation of intersection points.
  - Split Crossing Line(unchecked by default): Calculate the intersection point of each wire separately.
- Vector File: Input the vector file in shp format. The software can record the user's current settings and user can restore the settings in the drop-down menu or select button next time when opening this function.
- Simulation File: Input the simulation file (\*.LiSim file). The software can record the user's current settings and user can restore the settings in the drop-down menu or select button next time when opening this function.
- Threads Number (default value is "4"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.
- **Default Value**: Restore the default parameter settings.

Note: After the analysis, user can check the result accuracy in Scissors Crossing Analysis List.

Note: If user opens the function from the vector real-time working conditions module, user needs to set the vector file; if user opens the function from the simulation working conditions module, user needs to set the working conditions simulation file.

# Water Analysis

#### Summary

Based on the "black hole" in the point cloud data, those continuous hollow areas which meets requirements in the set parameters will be determined as the water area. Then the software will calculate the distances from the power line points to the water surface to judge if the point on the power line is danger point. The interface of water analysis is shown as follow. This function can process multiple data simultaneously. Click to add the data to be processed. Click to remove the selected data(remove the first record of the list if no data is selected). Click to clear the data list.

# Usage

Click Realtime Analysis > Water

land the second				
W:/Users/XDF/Des	sktop/Data/d	ata/40-41(40_41).LiData		\$
W:/Users/XDF/Des	sktop/Data/d sktop/Data/d	ata/39-40(39_40).LiData		
				1
1				
Detection Parameter	r			
Safe Distance:	4.5	m Density Threshold:	0	/ M <sup>2</sup>
Smoothing Factor:	2	Area Threshold:	400	M <sup>2</sup>
			•	
Vector File:				

### Settings

- Detection Parameter:
  - Safe Distance (meter) (default value is "4.5"): The threshold of safety distance. If the distance from the power line to the waterbody under it is less than this value, the corresponding point on the power line will be recognized as a danger point.
  - **Density Threshold (/square meter) (default value is "0")**: The threshold used to extract the waterbody from the point cloud. Those areas with point density lower than or equal to this value will be recognized as "suspected waterbodies". After this extracting, merge the suspected waterbodies close to

each other.

- **Smoothing Factor (default is "2")**: Smooth the edge of the waterbody. The smaller the value is, the finer the smoothing effect will be.
- Area Threshold (square meter) (default value is "4000"): The threshold to extract the waterbody. If the detected area is larger than this value, it will be recognized as waterbody.
- Vector File: Input the vector file in shp format. The software can record the user's current settings and user can restore the settings in the drop-down menu or select button next time when opening this function.
- **Simulation File**: Input the simulation file (\*.LiSim file). The software can record the user's current settings and user can restore the settings in the drop-down menu or select button next time when opening this function.
- Threads Number (default value is "4"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.
- Default Value: Restore the default parameter settings.

Note: If user opens the function from the vector real-time working conditions module, user needs to set the vector file; if user opens the function from the simulation working conditions module, user needs to set the working conditions simulation file.

# **Tree Growth Analysis**

# Summary

Based on the result of individual tree segmentation, calculate and extract the danger points after a certain period of growth. This function can process multiple data simultaneously. Click to add the data to be processed. Click to remove the selected data(remove the first record of the list if no data is selected). Click to clear the data list.

# Usage

Click Early Warning Analysis > Tree Growth

Data File Lo	g					
						÷
						1
'ree Growth Par	ameter	Cluster P	'arameter	Tree Segmen	tation Param	neter
Options © Constant G	rowing S	Speed	C	) Custom Growin	ng Speed for	Species
Tree Growth Sj	peed					
Growth Years:	1			year		
Growth Rate:	0.3			meter/year		
imulation File	:				Ŷ	]
		]		Default Value	Start	Exit
-eads Num(1-32)	. 4	-1			100000000	

Options			
🔿 Constant Growing S	peed 🖲	Custom Growing Speed for S	Species
Tree Growth Speed			
Start Time: 2024/4	÷	nd Time: 2024/4 🌻	
Tree Species Growth B	ate File:		

# Settings

- Tree Growth Parameter:
  - **Constant Growing Speed (default)**: If this option is checked, "Growth Speed" will be allowed to be set, and all kinds of trees will be considered to grow at this growth rate.
    - Growth Years (year) (default value is "1"): Set the predicted growth time. The software can record the user's current settings and automatically restore the settings when opened again.
    - **Growth Rate (meter/year) (default value is "0.3")**: Set the tree growth rate. The function can record the user's current settings and automatically restore the settings when opened again.
  - **Custom Growing Speed for Species**: If this option is checked, user can set the growth rate for different tree species in the table. Tree species files can be generated from Tree Species Classification, and the default growth rate is 1 meter / year.
    - Start Time: Set the start time of growth.
    - End Time: Set the end time of growth.
    - Tree Species Growth Rate File: Set the growth rate file path for tree species.
- Clustering Parameter:
  - **Cluster(unchecked by default)**: If this option is checked, the software will cluster the result; otherwise, the software will not cluster the result. The software can record the user's current settings and automatically restore the settings when opened again.
  - Cluster Threshold (meter) (default value is "15.0"): The maximum spatial separation distance when the detection results are clustered. This value should be smaller than the maximum clustering range. Three-dimensional Euclidean clustering is used to cluster the danger points. The software can record the user's current settings and automatically restore the settings when opened again.
  - **Max Clustering Range (meter) (default value is "20.0")**: After the detection results are clustered, if the length along the power line direction is greater than this value, they are divided into multiple dangerous point clusters. The software can record the user's current settings and automatically restore the settings when opened again.
  - Safe Distance (meter) (default value is "4.5"): If the distance between the detected point and the power line point is greater than the minimum distance and less than or equal to the safe distance, the point is considered to be a danger point. If the xml file is not set, user needs to enter the safety distance; otherwise, this parameter is extracted from the xml file. When using the xml to set the parameter, user can set different safety distances for different classes, and for different severity level.
- Tree Segmentation Parameter:
  - **Smoothing Factor (default value is "1.5")**: Individual tree segmentation smoothing coefficient. If there are too many trees, increase the smoothing factor, otherwise, decrease the smoothing factor.
  - **Height Above Ground (meter) (default value is "1.0")**: Point clouds above ground by distances greater than this value are used for individual tree segmentation, and less than this value will not be segmented.
- Vector File: Set vector file in shp format. The software can record the user's current settings, and can be

selected through the drop-down menu or selection button when it is opened again.

- Simulation File: Set the input simulation file (\*.LiSim file).
- Threads Number(default value is "4"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.
- **Default Value**: Restore the default parameter settings.

Note: After the analysis, user can check the result accuracy in Tree Growth Analysis List.

Note: If the individual tree segmentation operation has been performed on the point cloud, this step will not be performed and the analysis will be performed directly. If user wants to perform individual tree segmentation again, user needs to clear the segmentation result with the Clear function, and then perform this operation, or directly execute the Individual Tree Segmentation function.

Note: If user opens the function from the vector real-time working conditions module, user needs to set the vector file; if user opens the function from the simulation working conditions module, user needs to set the working conditions simulation file.

# **Tree Growth Warning Analysis**

#### Summary

Based on the result of individual tree segmentation, calculate the years of each tree to grow to be a danger tree. The interface of tree growth warning analysis is shown in the figure below. This function can process multiple data simultaneously. Click to add the data to be processed. Click to remove the selected data. Click to clear the data list.

# Usage

Click Early Warning Analysis > Tree Growth Warning

D:/Data/data/29-30(29 3	I).LiData
D:/Data/data/28-29(28_2	)).LiData
Tree Growth Parameter	Tree Segmentation Parameter
Tree Growth Parameter	Tree Segmentation Parameter © Custom Growing Speed for Species
Tree Growth Parameter	Tree Segmentation Parameter © Custom Growing Speed for Species
Tree Growth Parameter Constant Growing Speed Tree Growth Speed Growth Bate: 0.3	Tree Segmentation Parameter © Custom Growing Speed for Species meter/wear
Tree Growth Parameter Constant Growing Spee Tree Growth Speed Growth Rate: 0.3	Tree Segmentation Parameter © Custom Growing Speed for Species meter/year

e Growth Speed —			
e Species File:			
Nar	ne	Growth Speed	(meter/year)

# Settings

- Tree Growth Parameter:
  - **Constant Growing Rate (default)**: If this option is checked, "Growth Speed" will be allowed to be set, and all kinds of trees will be considered to grow at this growth rate.
    - Growth Rate (meter/year) (default value is "0.3"): Set the tree growth rate. The function can record the user's current settings and automatically restore the settings when opened again.
  - **Custom Growing Speed for Species**: If this option is checked, user can set the growth rate for different tree species in the table. Tree species files can be generated from Tree Species Classification, and the default growth rate is 1 meter / year.
    - Tree Species Growth Rate File: Set the growth rate file path for tree species.
- Tree Segmentation Parameter:
  - **Smoothing Factor (default value is "1.5")**: Individual tree segmentation smoothing coefficient. If there are too many trees, increase the smoothing factor, otherwise, decrease the smoothing factor.
  - **Height Above Ground (meter) (default value is "1.0")**: Point clouds above ground by distances greater than this value are used for individual tree segmentation, and less than this value will not be segmented.
- Threads Number (default value is "4"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.
- Default Value: Restore the default parameter settings.

Note: After the analysis, user can check the result accuracy in Tree Growth Warning Analysis List.

Note: If the individual tree segmentation operation has been performed on the point cloud, this step will not be performed and the analysis will be performed directly. If user wants to perform individual tree segmentation again, user needs to clear the segmentation result with the Clear function, and then perform this operation, or directly execute the Individual Tree Segmentation function.

# **Tree Fall Analysis**

#### Summary

Based on the result of individual tree segmentation, analyze the danger points on the trees during the falling procedure. The interface of tree fall analysis analysis is shown in the figure below. This function can process multiple data simultaneously. Click to add the data to be processed. Click to remove the selected data. Click to clear the data list.

### Usage

Click Early Warning Analysis> Tree Fall

Data File Log					
D:/Data/data/29-30(	29_30).LiData				
D:/Data/data/28-29(	28_29).LiData				÷
					1
					7.7
Tree Segmentation Pa	rameter				
Sigma: 1.5	Height	Above Ground:	1.0		m
Detection Parameter					
Cluster					
Cluster Threshold:	5	m Max Clu	ster Range:	20	m
Safe Distance:	the xml file!	Offset 3	Percentage:	0	
Remove Danger Tree	e Top				
Simulation File:				•	e e e
		6			

# Settings

- Tree Segmentation Parameter:
  - Smoothing Factor (default value is "1.5"): Individual tree segmentation smoothing coefficient. If there

are too many trees, increase the smoothing factor, otherwise, decrease the smoothing factor.

- **Height Above Ground (meter) (default value is "1.0")**: Point clouds above ground by distances greater than this value are used for individual tree segmentation, and less than this value will not be segmented.
- Detection Parameter:
  - **Cluster**: This option is unchecked by default. If this option is checked, the software will cluster the result; otherwise, the software will not cluster the result. The software can record the user's current settings and automatically restore the settings when opened again.
  - Cluster Threshold (meter) (default value is "15.0"): The maximum spatial separation distance when the detection results are clustered. This value should be smaller than the maximum clustering range. Three-dimensional Euclidean clustering is used to cluster the danger points. The software can record the user's current settings and automatically restore the settings when opened again.
  - **Max Cluster Range (meter) (default value is "20.0")**: After the detection results are clustered, if the length along the power line direction is greater than this value, they are divided into multiple dangerous point clusters. The software can record the user's current settings and automatically restore the settings when opened again.
  - Safe Distance (meter) (default value is "4.5"): If the distance between the detected point and the power line point is greater than the minimum distance and less than or equal to the safe distance, the point is considered to be a danger point. If the xml file is not set, user needs to enter the safety distance; otherwise, this parameter is extracted from the xml file. When using the xml to set the parameter, user can set different safety distances for different classes, and for different severity level.
  - Offset Percentage (default value is "0"): The percentage of the tree's horizontal offset relative to the height of the tree when falling.
  - **Remove Danger Tree Top**: Not selected by default. If the detected treetops are already a clearance danger point, when this option is checked, the tool will not record this point; otherwise, it will be recognized as a danger point. The software can record the user's current settings and automatically restore the settings when opened again.
- Vector File: Set vector file in shp format. The software can record the user's current settings, and can be selected through the drop-down menu or selection button when it is opened again.
- Simulation File: Set the input simulation file (\*.LiSim file).
- Threads Number (default value is "4"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.
- Default Value: Restore the default parameter settings.

Note: After the analysis, user can check the result accuracy in Tree Fall Analysis List.

Note: If the individual tree segmentation operation has been performed on the point cloud, this step will not be performed and the analysis will be performed directly. If user wants to perform individual tree segmentation again, user needs to clear the segmentation result with the Clear function, and then perform this operation, or directly execute the Individual Tree Segmentation function.

Note: If user opens the function from the vector real-time working conditions module, user needs to set the vector file; if user opens the function from the simulation working conditions module, user needs to set the working conditions simulation file.

# Clear

#### Summary

Clear the danger point attributes and the the corresponding file of the point cloud. The interface of clear function is shown in the figure below. This function can process multiple data simultaneously. Click to add the data to be processed. Click — to remove the selected data. Click / to clear the data list.

#### Usage

Click Report > Clear

Log				
ionData/6-7(#	¢_#7).LiData			
ionData/5-6(#	<sup>#5_#6).LiData</sup>			-{}-
ionData/4-5(#	t4_#5).LiData			-
ionData/2-3(#	<sup>‡</sup> 2_#3).LiData			0
ionData/1-2(#	1_#2).LiData			-
ionData/0-1(#	<sup>t0_#1</sup> ).LiData			
ionData/3-4(#	<sup>±</sup> 3_ <mark>#4).LiDa</mark> ta			1
)anger	🗌 Scissors Crossing	🗌 Water		
a	🗌 Tree Growth Warning	🗌 Tree Fall		
≥ction	🗌 Drainage Thread Clearance	🔲 Phase Spacin	ıg	
	Images	Power Line A	und Shield Lin	le Distance
te				
er Attribute	🗌 Clear Tree Segmentati	on		
2.15			1	
	ionData/3-6(# ionData/4-5(# ionData/2-3(# ionData/2-3(# ionData/1-2(# ionData/0-1(# ionData/3-4(# Danger h ection te er Attribute	ionData/0-7(#0_*7).LData ionData/5-6(#5_#6).LiData ionData/4-5(#4_#5).LiData ionData/2-3(#2_#3).LiData ionData/1-2(#1_#2).LiData ionData/0-1(#0_#1).LiData ionData/3-4(#3_#4).LiData Danger	IonData/o-/(#0_*7,LiData ionData/5-6(#5_#6).LiData ionData/2-3(#2_#3).LiData ionData/1-2(#1_#2).LiData ionData/0-1(#0_#1).LiData ionData/3-4(#3_#4).LiData Danger	IonData/S-((#5_#7),LiData ionData/S-6(#5_#6).LiData ionData/2-3(#2_#3).LiData ionData/1-2(#1_#2).LiData ionData/0-1(#0_#1).LiData ionData/3-4(#3_#4).LiData Danger Scissors Crossing Water h Scissors Crossing Tree Fall ection Drainage Thread Clearance Phase Spacing Images Power Line And Shield Lin te er Attribute Clear Tree Segmentation

#### **Settings**

- Clear File: Select the file types need to be clear.
  - Clearance Danger: Clear the clearance danger point detection result in the cache folder.
  - Scissors Crossing: Clear the scissors crossing point detection result in the cache folder.
  - Water: Clear the water body detection result in the cache folder.
  - Tree Growth: Clear the tree growth detection result in the cache folder.
  - Tree Growth Warning: Clear the tree growth warning detection result in the cache folder.
  - Tree Fall: Clear the tree fall detection result in the cache folder.
  - Stress Detection: Clear the stress detection result in the cache folder.
  - Drainage Thread Clearance: Clear the drainage thread creepage distance detection result in the cache folder.
  - Phase Spacing: Clear the phase spacing detection result in the cache folder.

- Sag: Clear the sag analysis result in the cache folder.
- Images: Clear the image files in the cache folder.
- **Power Line and Shield Line Distance**: Clear the power line and shield line distance result in the cache folder.
- Clear Attribute: Clear the attribute information of the point cloud.
  - Clear Danger Attributes: Clear the danger attributes in the point cloud files.
  - **Clear Tree Segmentation**: Clear the individual tree segmentation result of the point cloud. And delete the segmentation result file saved in the cache folder.
- **Threads Number**: Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.

Note: When this function is executed from a different working condition page, the corresponding data is cleared.

# **Generate Image**

# Summary

Generate images based on the detection results of danger points and the results of individual tree segmentation, including front views, top views, cross-section views of danger points, and tree height distribution and tree density distribution. The function interface is shown in the figure below. This function can process multiple data at the same time. Click to add the data to be processed. Click to remove the selected data. Click is to clear the data list.

# Usage

Click Report > Image

Data File Log				
D:/Data/SectionData/6-/	(#6_#/).LiData			-
D:/Data/SectionData/5-6	(#5_#6).LiData			-B-
D:/Data/SectionData/4-5	o(#4_#5).LiData			
D:/Data/SectionData/2-3	(#2_#3).LiData			
D:/Data/SectionData/1-2	(#1_#2).LiData			-
D:/Data/SectionData/0-1	(#0_#1).LiData			
D:/Data/SectionData/3-4	(#5_#4).LIData			
				1
				2
image Type   Image Para ] Clearance Danger ] Tree Growth ] Tree Height Image	meter Resampling Parame Scissors Crossing Tree Fall	ter Wat.	er	
II ee hei Sit Image				

Front View	w Width:	1000 px			Provide the second seco	
Ten View II				Front View Height:	450 px	•
TOD ALEW M	Vidth:	1000 px	\$	Top View Height:	350 рх	ŧ
Profile Th	hickness:	10.00 m	•	Point Size:	1	
Prefix of	Tower:			Suffix of Tower:		
🗌 True Co	olor	8	76	🗌 Use EDL Effect		
Resampl	ling					
X Size: 0	. 50			*		
Y Size: 0	. 50			\$		
Z Size: 0	. 10			*		

#### **Settings**

- Image Type: Select the type of danger points need to be rendered in the image.
  - Clearance Danger: Render the clearance danger point detection result in the image.
  - Scissors Crossing: Render the scissors crossing point detection result in the image.
  - Water: Render the water body detection result in the image.
  - Tree Growth: Render the tree growth detection result in the image.
  - Tree Fall: Render the tree fall detection result in the image.
  - **Tree Height Image**: Unchecked by default. If this option is checked, the height distribution map of trees in the file will be drawn.
  - **Tree Density Image**: Unchecked by default. If this option is checked, the density distribution map of trees in the file will be drawn.
- Image Parameter:
  - **Scale Factor (default value is "1.0")**: Checked by default. The ratio of the image width to the height scale. Used to control the degree of deformation of the image height.
  - Color Setting: Unchecked by default. User can set the color for different classes of point cloud in the generated image. If the option is unchecked, the image is drawn according to the colors of the point cloud displayed in the window; otherwise the image is generated according to the customized colors. The software can record the user's current settings and automatically restore the settings when opened again.
  - Front View Width (pixels) (default is "1000"): The width of the front view.
  - Front View Height (pixels) (default is "450"): Height of the front view.
  - Top View Width (pixels) (default is "1000"): The width of the top view.
  - Top View Height (pixels) (default is "350"): Height of the top view.
  - Profile Thickness (m) (default is "1"): Thickness of point cloud profile when generating danger point

image. The software can record the user's current settings and automatically restore the settings when opened again.

- **Point Size (default is "1")**: The point size of image. The software can record the user's current settings and automatically restore the settings when opened again.
- **Prefix of Tower (optional)**: In the generated front view and top view images, the prefix of the tower label. Prefix is empty by default.
- **Suffix of Tower (optional)**: In the generated front view and top view images, the suffix of the tower label. Suffix is empty by default.
- True Color: Generate images based on true color of point clouds.
- Use EDL Effect: Generating images using EDL enhancement effects.
- **Resampling Parameter**: Point cloud resampling parameter settings. Used to control image generation quality. The software can record the user's current settings and automatically restore the settings when opened again.
  - **Resampling**: Unchecked by default. Set whether to resample the point cloud.
  - Grid size X, Y, Z (meters) (default is "0.5, 0.5, 0.1"): Construct a three-dimensional voxel of X YZ, one point is reserved in each voxel.
- Threads Number (default value is "6"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.
- Default Value: Restore the default parameter settings.

Note: The tree height image and tree density image are generated based on the individual tree segmentation results. Users can use tree growth analysis, tree fall analysis or individual tree segmentation tool to perform the individual tree segmentation.

Note: When this function is executed from a different working condition page, images are generated based on the corresponding data.

# **International Report**

# Summary

The international report is the general version report. It can generate the report based on different data type and detection type. The interface of "generate report" function is shown as follow. This function can process multiple data simultaneously. Click to add the data to be processed. Click to remove the selected data. Click to clear the data list.

lats File Log		Based on Point Cloud	O Based on Va	ntor Data	Based on Simulation I	luta
D/Data/SectionData/3-6(#3_6)(L)Data D/Data/SectionData/3-6(#3_6)(L)Data D/Data/SectionData/3-2(#4_6)(L)Data D/Data/SectionData/3-2(#4_6)(L)Data D/Data/SectionData/3-1(#6_6)(L)Data D/Data/SectionData/3-4(#3_64)(L)Data D/Data/SectionData/3-4(#3_64)(L)Data	10	Detection Type C flearance Danger Generate Report	Sciencers Crossing	□ Tr** Fall	🗌 Ires incod	
	Assessor Cospany:	Annexor Company: Line Rome:		flertrical Bureaut Voltare Lovel:	10kV	
		Collection Date:	2024/04/19		Multiple days	
	Point Cloud Coordinate	WGS 84 / UTDZ zone 500		v		
	-	Target Coordinate:	VGS 84		~	
		Report Fath:	D./Dutu/			
	Other Display in Degrees(1a	ritude and Longitude)				
						Start

### Settings

- **Data Type**: Select the data type to be processed. The data type includes point cloud based data, vector based data, and data based on working conditions simulation. The software can record the user's current settings and automatically restore the settings when opened again.
  - Based on Point Cloud: Extract the powerline data from the original point cloud data.
  - **Based on Vector Data**: Extract the powerline data from the vector file, and other classes objects from original point cloud data.
  - **Based on Simulation Data**: Extract the powerline data from the simulation file, and other classes objects from original point cloud data.
- **Detection Type**: User can select multiple options. Set the detection type, and generate corresponding reports.
  - Clearance Danger: Clear the clearance danger point detection result in the cache folder.
  - Scissors Crossing: Clear the scissors crossing point detection result in the cache folder.
  - Tree Fall: Clear the tree fall detection result in the cache folder.
  - Tree Growth: Clear the tree growth detection result in the cache folder.
- Generate Report: Set the parameters for report generation.
  - Assessor Company: The company which generates the report.
  - Electrical Bureau: The name of power supply bureau or company.
  - Line Name: Line name.
  - Voltage Level: Cannot be changed by user.
  - Collection Date: The date on which point cloud was collected.
  - Point Cloud Coordinate: The coordinate system used in the point cloud data.
  - Target Coordinate: The coordinate system used in the report.
- **Report Path**: The output path of the report.
- Other:
  - **Display in Degrees(Latitude and Longitude)**: The coordinates are displayed in longitude, latitude, or radians.
- Simulation File: If user choose to generate the report based on the simulated working conditions data, it is required to set the simulation file (\*.LiSim file).

Note: Data type and detection type are combined to use. If user wants to generate the clearance danger and scissors crossing points report based on the point cloud data, they need to choose "Data Based on Point Cloud" in the data type, and "Clearance Danger" and "Scissors Crossing" in the detection type. Then set the other parameters, and Click "Start" to generate the report.

# **Vector Realtime Condition**

To handle and analyze power line channel based on point cloud data and vector data and to generate analysis report. Specific functions are as below:

Point Cloud	Distributing	Betwork Inspect	tion Point Cl	oud Realti	ne Condit	ion Vec	tor East	ine Condition	Simlat	ion Conditio	n Completie	in Acceptanc	o Pin	a Inspac	tion P	lugins	
Project	Mark	Information	Clip/Classify	Classify	20	30	HC	Start/End	Danner	) H Sciscore	Batch	Trae		Clear		Report	
Configuration	Tower	-	support and a start of the star	Tools -	Profile	Profile	Order	Starty 200	Points	Crossing	Processing	Growth	Fall				Report
Configuration	Tower	Collection	Clip/Clas	sify	Profil	e Classifi	ation	Vector Edi		Realtime An	alysis	Early War	ning			Repor	14

- Add Data
- Settings
- Mark Tower
- Information
- Clip and Classify
- Classification Tools
- Profile Tools
- Vector Editing
- Danger Points Detection
- Scissors Cross Analysis
- Batch Processing
- Tree Growth Analysis
- Tree Fall Analysis
- Clear
- Generate Image
- Generate Report
- Multiple Directory Report

# **Vector Editing**

### Summary

- Wector editing is mainly used to vectorize and edit insulator, power line, shield line, drainage thread,
- Scissors crossing line, tower and simple tower mode.

### Usage

Click *Vector Editing > Start/End* button, a vector editor toolbar will pop up. Click the button again to end editing. Vector Editor is as below:

Start/End         Shortcut         File -         Vertex         Update == Check           Start/End         Shortcut         Select -         Undo         Redo         Clip           X Delete -         Starty         Layer         Merge         Cancel Clip	Hang Insulator	Batch	Single Multiple	Batch	I <sup>4</sup> Shield Line → Vector Line → Wothers →	Simple Tower Model	☆ Place → Single ¥ Batch
	Vector Ed	iting					
File Editor							
• Editor							
Shortcut Settings							
Layer Settings							
Insulator Vectorization							
Power Line Vectorization							
Shield Line Vectorization							
Drainage Thread Vectorization							
Tower Vectorization							
Simple Model							

Note: Please classify point cloud data into power line and tower before using vector editor.

### **File Editor**

Save Files	Ctrl+O Ctrl+S	P Hang Insulator
Export	•	Power Line

- **Open Files**: Open vector files(\*.shp \*.tow \*.txt).
- Save Files: Interface is as below. Tick the vector layer to be saved. Double click to rename the file. Select output path and click OK to save the file. The file is saved to vector folder in working directory by default.

✓ Layer	File Name	5	Suffix
1 🗹 Insulator	Insulator	.txt	
2 🗹 Power Line	Power Line	.shp	
3 🗹 Shield Line	Shield Line	.shp	
4 🗹 Drainage Thread	Drainage Thread	.shp	
5 🗹 Scissors Crossing Up	Scissors Crossing Up	.shp	
6 🗹 Scissors Crossing Down	Scissors Crossing Down	.shp	
7 🗹 Tower	Tower	.tow	
8 🗹 General Vector Line	General Vector Line	.shp	
utput Path: D:/data/			
		OK	Cancel

- **Export**: Export vector file, including power line and tower.
  - **Power Line**: Export vector power line file in .dxf format.
  - Tower: Export vector tower file in .shp format.

#### Editor



- Select:
  - Window Selection: Left click to draw a rectangle and entities within the rectangle will be selected.
  - Select Layers: Click and check the corresponding layer in pop-up window. All entities on this layer will be selected.
  - Deselect All: Cancel all selection.
- Delete:
  - Delete Entity: Delete selected entity.
  - Delete Layers: Delete entity on selected layer.
- Vertex: Edit node on entity. Left click to select entity and then drag node to other place.
- Update: Refresh scene.
- Undo: Go back to last edition. This tool is not available while editing.
- Redo: Redo last edition. This tool is not available while editing.
- Clip: Crop point clouds for easy browsing and operation.
- **Merge**: Merge point cloud and vector lines. Discretize vector lines within the scene and merge them into point cloud data. Parameter settings reference Merge point cloud and vector data function.
- Cancel Clip: Cancel the cropping point cloud operation.

#### Check

As shown in the following figure, check whether the insulators, power lines, shield lines, drainage threads, scissors crossing up lines, and scissors crossing down lines in the scene are correct; It can be checked separately or multiple options can be selected for batch inspection.

A Datch (	Neck Aector Tive		
Line Type:	ing Vp;Scissors Crossi	ng Down -	🗹 Select All
		OK	Cancel

# **Shortcut Settings**

Set shortcut keys for commonly-used functions in vectorization module.

	Operation Name	Shortcut		*
1	Open Files	Ctrl+O		
2	Save Files	Ctrl+S		=
3	Export Power Line			
4	Export Tower			
5	Window Selection			
6	Select Layers			
7	Deselect All			
8	Delete Entity	Del		
9	Delete Layers			
10	Vertex Editing			
11	Update Scene			
12	Undo	Ctrl+Z		
13	Redo	Ctrl+Y		
Cle	ar Current Clear All			
		OK	Cancel	

- Clear Current: Clear current shortcut key settings.
- Clear All: Clear all shortcut key settings.

Note: Some shortcut keys have been used for specific operation, please set other shortcut keys.

### **Layer Settings**

Set the display status, color, line width, and line type of data for insulators, power lines, shield lines, drainage threads, scissors crossing lines, towers, conventional vector lines, simple towers, simple tower cross arms, and simple tower insulators.

	Layer Name	✓ how/Hide	Color	Line Wi	dth	Line Typ	e	1
l	Insulator	V		5pix	ंड	SolidLine	.*	
2	Powerline	V		2pix	्र	SolidLine		
;	Shield Line	2		2pix	+	SolidLine	÷	
ų	Drainage Thr	<b>V</b>		2pix		SolidLine	÷	
8	Scissors Cros	V		2pix	ंड	SolidLine		
;	Scissors Cros	V		2pix	्र	SolidLine		
•	Tower			4pix	+	SolidLine		
	Cananal Manaa					e altarta a	_	1

- Show/Hide: Show/Hide the vector in layers.
- Color: Color of vector data in layers.
- Line Width (Pixel, 2 by default): Width of vector data in layers.
- Line Type (Solid line by default): Line type of polyline in layers, such as solid line, dash line, dotted line.
- Show Simple Tower Text: Control the explicit and implicit state of simple tower text.
- Show Simple Tower Arm Text: Control the display and concealment status of text on simple tower crossbars.
- Show Simple Tower Insulator Text: Control the explicit and implicit state of text on simple tower insulators.
- Snap Distance(pixels)(default value is "9"): Set the buffering capture distance in 3D views when clicking with the mouse, measured in screen pixels, to facilitate user interaction.

# **Insulator Vectorization**

Insulator Vectorization Toolbar is as below, including Hang Insulator, Modify Insulator, Auto Hang Insulator.



#### **Hang Insulator**

Vectorize insulator. Click Hang Insulator button and a window will pop up. The operation steps are as below:

Tips					
1. Please set corre	ect tower	r type.			
2. Please select the of conductor and the select the se	he hangin insulator	ng point (t) r).	he i	nterse	ction
3.Modify the last	insulate	or.			
4. The parameter of straight line tow	f insulat er.	tor length	is	apply	to
Tower Parameter —					
Clip Tower					
Buffer Size:		10.00 m			
Current Tower Ind	ex:	28			4
Insulator Paramet	er				
Insulator Length:	3.00 m		÷		
Translate X:	0.10 m	1	-		壶
	0.10 m		-		4
Translate I:			1.5		-

- **Clip Tower**: Uncheck by default. If check this function for editing convenience, then the point cloud file will be clipped into several separate files by tower mark and buffer size.
- Buffer Size (meter, 10 by default): The half length of the XY plane of the cutting bounding box is used to control the size of the cutting area.
- Current Tower Index: Index of tower being edited.
- Insulator Length (meter, 3 by default): Insulator length.
- Translate X (meter, 0.1 by default): Set translation distance along X-axis of the last drawn insulator.
- Translate Y (meter, 0.1 by default): Set translation distance along Y-axis of the last drawn insulator.
- Translate Z (meter, 0.1 by default): Set translation distance along Z-axis of the last drawn insulator.

1. Set tower type and enter tower index corresponding to towers in viewer.

- 2. Use length measurement tool to measure the length of insulator and set average length as insulator length.
- 3. Left click to pick up hang point(point connecting insulator and power line). For tension tower, insulator is vectorized as point; for straight line tower, insulator is vectorized as line.
- 4. Vectorize next insulator, or right click to exit insulator vectorization.

#### **Modify Insulator**

Edit position of selected insulator, the operation steps are as below:

- Modi	y Insulator	
Trans	late	
x (m):	0.1	
<b>y</b> (m):	0.1	- +
z(m):	0.1	- +

- Translate X (meter, 0.1 by default): Set translation distance along X-axis of the selected drawn insulator.
- Translate Y (meter, 0.1 by default): Set translation distance along Y-axis of the selected drawn insulator.
- Translate Z (meter, 0.1 by default): Set translation distance along Z-axis of the selected drawn insulator.
- 1. Click *Modify Insulator* button, then click and select the insulator to be edited. Set edit parameters in the pop up window.
- 2. Click the right mouse button to hide the dialog and continue to modify the next insulator.
- 3. After the modification is completed, right-click again to exit the function.

### **Auto Hang Insulator**

To automatically hang insulators, wires and insulators needed to be classified first.

	12
n 🗘	Clustering Threshold:
n -	Lustering Threshold:

Note: For the distribution network point cloud data with a detected line voltage level of 10kV, only clustering threshold are required, and all insulators are vectorized are points.

Note: please add in corresponding tower file(\*.LiTower) before using insulator vectorization tools.

# **Power Line Vectorization**

Power Line Vectorization Toolbar is as below, including Fitting Power Line Based On Insulators, Fitting Power Line Based On Point Cloud and Split Power Line.

Batch	Single Mu	ltiple	Batch	<ul> <li>✓ Shield Line •</li> <li>✓ Vector Line •</li> <li>✓ Others •</li> </ul>	Simple Tower Model
ting				😅 Split Power L	ine
	_ □	×	Result	Based On Sa	g •

#### **Fitting Single Power Line Based On Insulators**

Vectorize each power line by insulators. The operation steps are as below:

- 1. Left click to pick up insulator hang points on small numbered tower, or right click to end fitting power line by insulator.
- 2. If hang points on large numbered tower match them correctly, take step3. If match fails or goes wrong, press "Z" and left click to pick up corresponding insulator hang point on large numbered tower.
- 3. Left click to pick up the middle point on the power line.
- 4. Finish fitting. And repeat former steps.

### **Batch Fitting Power Lines Based On Insulators**

For multiple power line spans, users can click Batch Fitting button to batch fit power lines. Set start tower index and end tower index in the pop up window. Then click to vectorize power lines. The interface automatically exits when vectorization completed.

📌 Batch Vectorizat	tion	×
Start Tower Index:	1	\$
End Tower Index:	226	\$
	Start	Cancel

- Start Tower Index: Set start tower index.
- End Tower Index: Set end tower index.

### Fitting Single Power Line Based On Point Cloud

Manually pick up three points on the power line and vectorize the power line. The operation steps are as below:

- 1. Left click to pick up power line end point, or right click to end fitting power line by three points.
- 2. Left click to pick up another end point or right click to go back to step1.
- 3. Left click to pick up middle point of the power line or right click to go back to step2.
- 4. Finish fitting. And repeat former steps.

### Fitting Multiple Power Lines Based On Point Cloud

🚅 For each power line span, pick up two end points(e.g. Pick up center point for each tower). Power lines between the two towers will be fit automatically. The operation steps are as below:

- 1. Left click to pick up top center point of the tower1 or right click to end fitting multiple power lines by two points.
- 2. Left click to pick up top center point of the tower2 or right click to go back to step1.
- 3. Right click to finish fitting. And repeat former steps.

#### **Batch Fitting Power Lines Based On Point Cloud**

For the data in the scene, batch fit the power lines between the towers.

Start Tower Index:	1	\$
End Tower Index:	226	\$
Insulator Length:	3.00m	\$
Slice Thickness:	1.00m	\$
Cluster Radius:	0.50m	\$

- Start Tower Index: Set start tower index.
- End Tower Index: Set end tower index.
- Insulator Length(meters) ("3.0" by default): Set insulator length.
- Slice Thickness(meters) ("1.0" by default): Set slice thickness.
- Cluster Radius(meters) ("0.5" by default): Set cluster radius.

#### **Split Power Line**

Split and translate vectorized power lines selected in the viewer.

	1.00 m	-
Split Number:	2	
Power Line Position(Viewing from the minor tower to the major tower):	PO PO	
Spl	it	
	Line	
Keep Uriginal fower .		
Keep Original Fower . Vertical Line Direction	: 1.00 m	
Keep Uriginal Fower Vertical Line Direction Elevation Direction:	: 1.00 m 0.00 m	÷

- Split Power Line: Split selected power lines into multiple power lines following the settings.
  - Slant Distance(meter, 1m by default): The distance between two adjacent vectorized power lines after splitting.
  - Split Number(2 by default): Power line split number. There are four options: 2, 4, 6, and 8.
  - Power Line Position: Power line position before being split, from minor tower to major tower.
  - Split: Perform split power line operation.
- Translate Power Line: Translate selected power lines following the settings.
  - Keep Original Power Line: Uncheck by default, and original power line will not be kept. Otherwise the opposite.
  - Vertical Line Direction(meter, 1m by default): Translation distance along vertical line direction.
  - Elevation Direction(meter, 0m by default): Translation distance along Z direction.
  - Translate: Perform translation power line operation.
- Select All: Select all vectorized power lines in the viewer.
- Deselect All: Cancel selection of all selected power lines.

# **Shield Line Vectorization**

Shield Line Vectorization Toolbar is as below, including Three Points Fitting Single Shield Line and Batch Fitting Shield Lines.



### **Three Points Fitting Single Shield Line**

Manually pick up three points on shield line and vectorize shield line. The operation steps are as below:

- 1. Left click to pick up shield line end point, or right click to end fitting shield line by three points.
- 2. Left click to pick up another end point or right click to go back to step1.
- 3. Left click to pick up middle point of the shield line or right click to go back to step2.
- 4. Finish fitting. And repeat former steps.

#### **Batch Fitting Shield Lines**

A For multiple shield line spans, users can click Batch Fitting button to batch fit shield lines.

# **Drainage Thread Vectorization**

Drainage Thread Vectorization toolbar is as below, including Three Points Fitting Single Drainage Thread.

▽ Drainage Thread →		
V	Three Points Fitting	Single Drainage Thread

# Three Points Fitting Single Drainage Thread

Manually pick up three points from a single drainage thread and vectorize the drainage thread. The operation steps are as below:

- 1. Left click to pick up end point of the drainage thread, or right click to end fitting.
- 2. Left click to pick up another end point of the drainage thread, or right click to get back to step1.
- 3. Left click to pick up a middle point of the drainage thread, or right click to get back to step2.
- 4. Finish fitting and repeat former steps.

# **Tower Vectorization**

Tower Vectorization Toolbar is as below, including Auto Generate Tower Model, Create Tower From Five Points, Create Crossing Arm, Delete Crossing Arm, Create Attachment, Delete Attachment, Modify Tower, Load Tower Template, Save Tower Template and Place Tower.



### **Create Tower From Five Points**

When creating tower model, users can show/hide specific tower type by class setting.

Display	Class ID	Description	Color
	2	Ground	
	5	High Vegetation	
	16	Conductor	
	17	Structure	
	18	Scissors Crossing Up	
(mail)	10222	ol: Line	
V	20	Shield Wire	
₩ Dangerous Point Setti	ng	Shield Wire	
♥ )angerous Point Setti ♥ Clearance Danger	ng	Shield Wire	

1. Left click to pick up corner point1 on tower bottom or right click to end creating tower by five points.

2. Left click to pick up corner point2 on tower bottom or right click to go back to step1.

3. Left click to pick up corner point3 on tower bottom or right click to go back to step2.

4. Left click to pick up corner point4 on tower bottom or right click to go back to step3.

5. Left click to pick up tower top point or right click to go back to step4.

6. Right click and a right-click menu will pop up. Click "Finish Tower Drawing" to finish creating tower model.

Repeat the former steps to create next tower model. Or click "Draw Cross Arm" to create cross arm. Generated tower model is as below:



#### **Create Crossing Arm**

Create crossing arm to current tower model.

- 1. Left click to select a current tower model to create crossing arm.
- 2. Left click to pick up end point1 of crossing arm or right click to go back to current point.
- 3. Left click to pick up end point2 of crossing arm.
- 4. Repeat step2 to add other crossing arms.
- 5. Right click and a right-click menu will pop up. Click "Finish Create Crossing Arm" to finish Create Crossing Arm. Repeat the former steps to create crossing arms for next tower model. Or click "Draw Attachment" to create cross arm attachment points.

Generated crossing arm is as below:



#### **Create Attachment**

Click Create Attachment and a window will pop up as below. Set attachment length, 1 meter by default. Click to apply.

Attac	hment Length	23
Length	1	 Apply

After setting the length of the hanging point, click Apply to mount the hanging points of different lengths.

- Length (meter, 1m by default): Length of the hanging point.
- 1. Left click to select the tower to create attachment point.
- 2. Left click to create an attachment point.
- 3. Repeat step2 to add other attachment point.
- 4. Right click to end editing current attachment point and repeat step1 to add attachment for next tower.

Generated attachment is as below:



### **Modify Tower**

Modify tower description information, pan and rotation parameter. This can be saved as tower template Mo file subsequently.

- 1. Left click to select the tower model to be modified.
- 2. Modify parameters in the pop-up window and save.

escription	Apply
Translate	
x (m) 0	Apply
y(m) 0	Apply
z (m.) 0	Apply
Rotate	(Ann) w
.( ) 0	Аррту

- **Description**: Modify the description, click Apply to save change.
- Translation X(meter, 0 by default): Translation along X-axis, click Apply to save change.
- Translation Y(meter, 0 by default): Translation along Y-axis, click Apply to save change.
- Translation Z(meter, 0 by default): Translation along Z-axis, click Apply to save change.
- Rotation Z(degree, 0 by default): Rotate by Z-axis, click Apply to save change.
- 3. Right click to end modifying current tower and repeat step1 to modify other tower.

Load Tower Template Load Tower Template(\*.tow), the drop down menu is only available when tower template file is loaded X.,

Load Tower Template(\*.tow), the drop down menu is only available when tower template file is loaded in.

# **Save Tower Template**

Save vectorized tower with description information as tower template.

#### **Place Tower**

Firstly, load in a tower template, then place the template at specific position.

- 1. Left click to pick up tower top point to place template.
- 2. Select tower template in the tower type drop-down list in the pop-up window. Click "Yes" and place the template to that position.

22		
Tower Ty	pe 🛛	*
ſ		
10	OK	Cancel

• Tower Type: Select tower type in the lists from owner template.

3. Right click to end operation.

# Simple Model

The simple tower model toolbar, as shown in the following figure, includes the functions of drawing a simple tower model, placing, hanging a single wire, and batch hanging wires.



Note: When using the Tower Model Tool, the corresponding tower file (\*. LiTower) must be loaded first.

#### **Draw Simple Tower Model**

Build a simple tower model. The functional interface is shown in the following figure. Click to open the simple tower model file. Click to save the simple tower model file.

L C.	Name: 1		÷	🛛 🗹 Rotate Sce
lori	zontal Buffer: 20.00	m 🗘 V	ertical Buffe	er: 100.00m
Cowe	r Arm Insulato	r		
lowe	r Height: 30.00m			
Ce	nter Point	E	and Point ——	
X:	0.000	\$ Х	: 0.000	÷
¥ :	0.000	÷ Y	: 0.000	\$
-	0.000	‡ Z	0.000	\$
2:		1.1.4.4.4.4.4.4.4.4.4.4.4.4.4.4.4.4.4.4		1.444

- **Tower Name**: Select the corresponding tower name.
- Rotate Scene: Uncheck, rotate horizontally; Check, 3D rotation.
- Clip(uncheck by default): If checked, the scene data will be clip based on the size of the buffer zone, with the tower point as the center, for easy operation; If unchecked, no clipping will be performed.
  - Horizontal Buffer: Set the horizontal display range.
  - Vertical Buffer: Set the vertical display range.
- Tower: Draw the tower body.
  - Tower Height: Set the height of the tower.
  - Center Point: Set the center point position.

- End Point: Set the position of the end point in the main direction of the tower.
- **Adjust**: After checking, existing model parameters can be adjusted, including height, center point, and end point.
- Add: Click to add the main body of the tower.
- Delete: Click to delete the current model and delete its related cross arms and insulators.

ver Name: 1   Clip		•	🗸 Rotate Sc
iorizontal Buf	fer: 20.00m	Vertical Buffer	: 100.00m
lower Arm	Insulator		
rm Index:			
Arm Height:	10.00m 🗘	Arm Width:	0.00m ‡
Left Length:	3.00m 🗘	Right Length:	3.00m ‡

- Arm: Draw the cross arm of the tower.
  - Arm Index: Cross arm number, automatically generated after clicking add.
  - Arm Height: Set the height of the cross arm relative to the lowest point of the tower body.
  - Arm Width: Set the width of the cross arm, which only exists for tension towers.
  - Left Length: Set the left length.
  - Right Length: Set the right length.
  - Add Middle Phase: After checking, you can set the middle phase parameters of the cross arm.
  - **Horizontal Offset**: Set the horizontal offset value of the middle phase (negative value on the left and positive value on the right, distinguished by minor to major towers).
  - Vertical Offset: Set the vertical offset of the middle phase.
  - Adjust: After checking, the cross arm model with the current number can be adjusted.
  - Add: Click to add the cross arm model.
  - **Delete**: Click to delete the cross arm model with the current number and link to delete its related insulators.

er Name: 12			🔸 🗹 Rotate So
Clip			
rizontal Buffer:	20.00m 🗘	Vertical Bui	fer: 100.00m
ower Arm Ins	ulator		
sulator Index:			
sulator Index:	3.00m ‡	Vertical A	ngle: -10.00° ‡
sulator Index: Insulator Length: Azimuth Angle:	3.00m ‡	Vertical Au	ngle: -10.00° ‡
sulator Index: Insulator Length: Azimuth Angle: Adjust	3.00m ‡ 2.00° ‡ B	Vertical An	ngle: -10.00° ‡ Batch Delete :

- Insulator: Draw insulators.
  - Insulator Index: Insulator number, automatically added.
  - Insulator Length: Set the length of the insulator.
  - Vertical Angle: Set the insulator angle, which only exists for tension towers.
  - Azimuth Angle: Set the azimuth angle and only add the middle phase to this parameter.
  - Adjust: After checking, you can adjust the parameters of the insulator with the current number.
  - Batch Add: Batch add insulators.
  - Batch Delete: Batch delete insulators.
  - Batch Adjust: Batch adjust insulators.
    - Same Arm: Adjust the selected insulator to correspond to the insulator under the cross arm.
    - Same Major/Minor Side: Adjust the selected insulators to correspond to the same side of the tower with the same size.
    - All: Adjust all insulators.

#### Place

 $\overset{\bullet}{\underbrace{\boxtimes}}$  Place the simple tower model at the designated tower name location.

imple Tower Model F	ile:	
ower Name:	1	 Place

- Simple Tower Model File: Set the file path for similar simple tower models.
- Tower Name: Set the name of the tower to be placed.

Note: Ensure that both towers are both tension towers or straight line towers.

#### Single

Suspend a single wire for the current simple tower model.

Based Or	n Sag	🔵 Based On Line Type	
Parameters	2		
Sag Value:	10.00m		÷

- Base On Sag: Hang the wire according to the sag value.
  - Sag Value: Set the sag value.

🔵 Based On Sa	g 💿 Based On Li	ne Type	
Parameters —			
Line Type:	ACSR-720/50		
Safety Factor:	2.50	\$	

- Base On Line Type: Suspend wires based on wire type and safety factor.
  - Line Type: Select the current wire type and use the built-in wire type library.
  - Safety Factor: Set a safety factor, generally not less than 2.5.
- 1. Click the left mouse button to select the suspension point for the insulator of the small tower.
- 2. When the number of insulator layers and the number of hanging points on each layer of the small and large towers are consistent, the hanging points on the large tower can be automatically matched.
- Matching successful, wire hanging completed. If it fails, you need to click the left mouse button to select the insulator hanging point corresponding to the large tower.
- 4. The drawing is completed.

Note: There is a difference between the entry and exit points for tension towers. The starting hanging point needs to select the outgoing tower point, and the ending hanging point needs to select the incoming tower point.

#### Batch

Batch suspension of wires for the current simple tower model.

Batch suspension of wires for the current simple tower model.

oromo	ed Un :	Sag			O Base	d Un Li	ne Type	
Minor	Tower	Index	Major	Tower	Index	S	ag(m)	÷
								1

- Base On Sag: Click to add individual segment data (set small and large tower numbers and sag values).
   Click to remove the selected segment. Click to clear the data list. Click to open the sag file. Click to save the sag file.
  - Sag File: Set the sag file path in \*. csv format, recording the tower number and wire sag value for each level. The file is divided into three columns, separated by "," with the first column representing the starting tower number; The second column represents the end tower number; The third column represents the sag value. The following is an example of the sag file section:

```
Starting tower number, ending tower number, sag 28,29,2.5
29,30,4.0
```

🔵 Based On Sag		Based	l On Line Type		
Parameters					
Start Tower Index:	1	\$	End Tower Index:	221	÷
Line Type:	ACSR-720/50	*	Safety Factor:	2.50	:

- Base On Line Type:
  - Start Tower Index: Set the starting tower number.

- End Tower Index: Set the end tower number.
- Line Type: Select the current wire type and use the built-in wire type library.
- **Safety Factor**: Set a safety factor, generally not less than 2.5.

# **Simulation Condition**

To handle and analyze power line channel based on point cloud data and simulated data and then generate analysis report. Specific functions are as below:



- Add Data
- Settings
- Mark Tower
- Information
- Clip and Classify
- Classification Tools
- Profile Tools
- Vector Editing
- Danger Points Detection
- Scissors Crossing Analysis
- Batch Processing
- Comprehensive Working Conditions Simulation
- Tree Growth Analysis
- Tree Fall Analysis
- Current Carrying Capacity Analysis
- Allowable Stress Analysis
- Scissors Crossing Double Line Simulation Analysis
- Clear
- Generate Image
- Generate Report
- Multiple Directory Report

Note: Vector data used in this module must be vectorized by insulators.

# **Comprehensive Working Conditions Simulation**

#### Summary

Comprehensive working condition simulation analysis can simulate and analyze the power line status in different wind, high temperature and ice cover conditions. According to the type of tower, it can be divided into continuous segment and isolated segment. The continuous segment refers to the tension section composed of several straight line towers. The isolated segment is an independent segment with a tension tower tower at both ends, which is analyzed using the isolated gear method. The interface of comprehensive working condition simulation analysis is shown in the figure below. Click to add the vector data to be processed. Click to remove the selected vector data(remove the first record of the list if no data is selected). Click to clear the vector data list.

### Usage

Click Early Warning Analysis > Simulation

Vector File Log	ang conducto cinalation		
			4
Common Settings Co	ndition Parameters 🗌 Simulati	on Parameters	
Power Line	🔿 Shield Line	🔿 Drainage Thread	
Voltage Level:	10kV	~	
Line Type:	LGJ-240/30	~ I	D +
Section Line Type			0.535
neulatar Bila			
nsulator file.			
hatpat Ciculation 21			
utput Simulation Filo	2.		
		Stort	Rui +

#### Settings

• Power Line(Shield Line, Drainage Thread): Select to processing line classification.

- Voltage Level: Select the voltage level in the drop-down list. The default value is the voltage level in the settings step.
- Line Type: Select the line type from the drop-down list, or user can enter key words to search. If there is no desired record in the list, user can add a new type of line with "Add Line Type" function. The software can record the user's current settings and automatically restore the settings when opened again.
  - Line Specifications: View the corresponding specifications of the current power line type.
  - Add New Line Type: Add a new type of power line.
- Line Type File: Select piecewise line type file. Simulate the working conditions in different segments with different power lines.
- Scanning Conditions: Conditions when the data were collected. The software can record the user's current settings and automatically restore the settings when opened again.
  - Wire Temperature (Celsius): Wire temperature during the scanning.
  - Ice Thickness (mm): The thickness of ice one the wire during the scanning.
  - Wind Speed (m/s): Wind speed during the scanning.
- **Simulation Conditions**: Simulated operating conditions. The software can record the user's current settings and automatically restore the settings when opened again.
  - Wire Temperature (Celsius): The temperature of the wire under simulated conditions.
  - Ice thickness (mm): The thickness of ice under simulated conditions.
  - Wind speed (m/s): Wind speed under simulated conditions.
- Section Condition Parameters: Select piecewise condition file. Import parameters from the working condition file.
- Start Tower Index: Set the index of the starting tower.
- End Tower Index: Set the index of the ending tower.
- Wind Deflection Process:
  - **Wind Deflection Process**: This option is unchecked by default. If this option is checked, the software will interpolate the maximum wind deflection angle according to the interpolation angle to simulate the swing of the wire during the wind deflection. If this option is unchecked, the software will simulate the maximum wind deflection on both sides of the wire.
  - Interpolation Angle (degrees) (default is "5"): Angle used to interpolate the maximum wind deflection angle.
- Insulator File: Set the input vector file for the insulators.
- Output Shp File: Select the path of the simulated Shp file to be output after the analysis.
- Output Simulation File: Select the path of the simulation file to be output after the analysis.

Note: To execute this function, user needs to set the type of the transmission tower in Mark Tower. If the power line in continuous segments are incomplete, the simulation analysis cannot be done, and the power line in the output file will be missing as well.

# **Current Carrying Capacity Analysis**

# Background

The current carrying capacity and temperature of the power line are important parameters for operation and design. At present, there are two main methods for increasing the current carrying capacity of high-voltage overhead transmission lines: static capacity increase and temperature calculation. Based on the thermal balance equation, the design code of China gives the formula for calculating the allowable current carrying capacity of overhead transmission line conductors. It is the most commonly used formula for calculating the current carrying capacity in china. In practical applications, the calculation direction opposite to the above is more applicable in the design steps of the power transmission project, that is, given the maximum allowable carrying capacity, the amount to be calculated is the temperature or temperature rise of the power line. Reference of the algorithm: (Lin et al., 2012)

# Summary

The carrying capacity analysis function is mainly used to calculate the temperature rise of the power line under a certain ambient temperature and carrying capacity. The function interface is shown in the figure below.

#### Usage

Click Early Warning Analysis > Current Carrying Capacity

Log							
2 7 2 7 3 1							
Farameter Settings							
Power Line Type: LGJ-240	/30						•
Electrical Parameter				-Environment Par	ameter		
DC Resistance at 20°C:	0.11810	.A. 	Ω/km	Emissivity:	0.90	- <u>×</u> - <u>×</u>	
Internal Diameters:	7.20000	φ. 	mm	Endothermy:	0.90	*	
External Diameters:	21.60000		mm	Sun Irradiance:	1000.00	A V	₩/m²
	275.9600	10	mm <sup>2</sup>	Wind Sneed	0.50	A	m/s
Cross-sectional Area:			0.030322	"Ind opeed.	0.50	1.401	
Cross-sectional Area: Current Frequency:	50.00	* *	Hz	TCR at 20° C:	0.004040	A V	°C⁻1
Cross-sectional Area: Current Frequency: Initial Parameter	50.00		Hz	TCR at 20° C:	0.004040		°C-1
Cross-sectional Area: Current Frequency: Initial Parameter Ambient Temperature:	50.00	40.00	Hz	TCR at 20° C:	0.004040	*	°C-1
Cross-sectional Area: Current Frequency: Initial Parameter Ambient Temperature: Input Carrying Capacity:	50.00	40.00 0.000	Hz	TCR st 20° C:	0.004040		°C-1
Cross-sectional Area: Current Frequency: Initial Parameter Ambient Temperature: Input Carrying Capacity: Power Line Temperature Sin	50.00 mulated:	40.00 0.000	Hz	TCR at 20° C:	0.004040	÷.	°C-1
Cross-sectional Area: Current Frequency: Initial Parameter Ambient Temperature: Input Carrying Capacity: Power Line Temperature Sin	50.00	40.00 0.000	Hz	TCR st 20° C:	0.004040	÷	°C-1

### Settings

- Parameter Settings:
  - Power Line Type("LGJ-240/30" by default): Select the power line type. After selecting any power line type, the electrical parameters below will change accordingly. Currently, only cored power line types are supported, such as "steel core aluminum stranded conductor" LGJ-300 / 40, where "300" represents the diameter of the power line and "40" represents the diameter of the steel core.
  - **Electrical Parameter**: Parameters related to the power line. Among them, "DC resistance at 20°C", "inner diameter of the power line", "outer diameter of the power line", and "calculated cross-sectional area" will be automatically read from the file according to the selected power line type, without adjustment.
  - Current Frequency (Hz) (default value is "50.0"): Current frequency of AC resistance.
  - **Environment Parameter**: Environment-related parameters. Need to adjust according to the actual situation. The "radiation heat dissipation coefficient" and "strand surface heat absorption coefficient" are both 0.9, and no adjustment is required.
  - Sun Irradiance (W/m^2) (default value is "1000"): Heat from the sun absorbed per square meter of

the power line.

- Wind Speed (m/s) (default value is "0.5"): Wind speed of the environment where the power line is located.
- Resistance at 20<sup>°</sup>C (per degree Celsius) (default value is "0.004040"): DC resistance of the power line at 20<sup>°</sup>C.
- Initial Parameter:
  - **Ambient Temperature (Celsius) (default is "40")**: The actual temperature of the environment where the wire is power line.
  - Input Carrying Capacity(Ampere): The current passing through the power line.
  - **Power Line Temperature Simulated(Celsius)**: Output the actual power line temperature simulated under the above environmental conditions.

```
@inproceedings{
    author={Lin},
    title={The Calculation of Current Carrying Capacity and Temperature of High Voltage Overhead Lines},
    booktitle={SOUTHERN POWER SYSTEM TECHNOLOGY, 6(4):23-27},
    year={2012},
}
```

# **Allowable Stress Analysis**

# Summary

Based on the result of working conditions simulation, detect and analyze if the stress at the lowest point of the sag exceeds the allowable stress. The interface of allowable stress analysis is shown in the figure below.

# Usage

Click Early Warning Analysis > Allowable Stress

TOE				
				ŕ
.mulation File:				
mulation File: afety Factor:	2.5			(

### Settings

- Safety Factor (default value is "2.5"): Power line safety factor.
- Simulation File: Set the input simulation file (\*.LiSim file)

Note: After the stress detection, user can view the result in the Allowable Stress Analysis List.

# **Scissors Crossing Double Line Simulation Analysis**

#### Summary

Based on the result of working conditions simulation, analyze the distance between current line and crossing line. Click to add the vector data to be processed. Click to remove the selected vector data(remove the first record of the list if no data is selected). Click

### Usage

Click Early Warning Analysis > Scissors Crossing Double Line Simulation Analysis

Data File Log				
				4
				1
Analysis Analysis Parameter	Generate Report	🗹 Report		
Buffer Size: 0.50m	-			•
Crossing Line Type	Crossing Line File	Current Line Type	Current Line File	<b>(</b>
			122 E	

# Settings

• Analysis Parameter:

Click to add the current line and crossing line. Click i to modify selected line. Click to remove selected line. Click to clear line list.

• Buffer Size: Adjust channel width.

Crossing Line Option	
◉ Scissors Crossing Up	🔘 Scissors Crossing Down
File Path:	· · · · · ·
Current Line Option	
🖲 Shield Line	○ Power Line
File Path:	

- Line Settings:
  - **Crossing Line Option**: Select the crossing type and the working conditions simulation file for crossing lines. Crossing types include scissors crossing up and scissors crossing down.
  - **Current Line Option**: Select the current line type and the current line working conditions simulation file. Line Type include shield line and power line.
- Report(check by default): Check to generate an analysis report based on the analysis result file. If not checked, no report will be generated.
  - Assessor Company: The company which generates the report.
  - Electrical Transmission Bureau / Company: The name of power supply bureau or company.
  - Line Name: Line name.
  - Collection Date: The date on which point cloud was collected.
  - Target Coordinate: The coordinate system used in the report.
  - **Report Path**: The output path of the report.
- Threads Num(default value is "4"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.

# **Completion Acceptance**

Completion Acceptance is suitable for completion analysis of power line and tower. Based on point cloud data, vector data and working condition simulation data, this module analyzes different components of the line and generates analysis report. The specific functions are as below:

Point Cloud	Distributin:	Network Inspec	tion Point C	lond Bealti	ne Conditi	on Vec	tor lealt	ine Condition	Sinul	ation Con	lition Co	upletion	Acceptance	Pine I	nspection Plugins		
Project	Mark	Information	Clip/Classify	Classify	2D 2D	30 3D	HC Class	Start/End	Sag	Phase	St. Drainage	다. Spacer	Rotation	Insulator	Power Line And Shield	Protect	۲ Other
Configuration	Tower	-		Tools .	Profile	Profile	Order			Spacing	Thread		Angle		Line Distance	Angle	
Configuration	Tower	Collection	Clip/Clas	ssify	Profil	e Classific	ation	Vector Edi						Completi	on Analysis		

- Add Data
- Settings
- Mark Tower
- Clip and Classify
- Classification Tools
- Profile Tools
- Vector Editing
- Sag Analysis
- Phase Spacing Analysis
- Drainage Thread Clearance Analysis
- Spacer Analysis
- Tension Tower Rotation Analysis
- Insulator Inclination Analysis
- Distance Between Conductor And Shield Wire
- Protect Angle Analysis
- Anchor Bolt
- Lighting Protector Inclination
- Earth Electrode Line
- Danger Point Sag
- Wind Turbine Tower Inclination
- Merge Report

# Sag Analysis

### Summary

Analysis sag, line length etc based on vector file or simulation file input. The result data can be saved as(\*.csv \*.xls)and generate report. Click to add data, click to remove data selected, click to clear data list.

# Usage

Click Completion Analysis > Sag

D:/work/workfile/data/test/data/20-21(20_21).LiData D:/work/workfile/data/test/data/19-20(19_20).LiData	-fb-
unction Option	
🛛 Sag Analysis 🖂 Generate Report	
Sag Analysis Generate Report	
☐ Adjust Sag With Point Cloud ☐ Calculate Dis ☐ Sag Deviation	tance To Ground
Observed Temperature: 20.00 °C 🖨 Observed Wind Speed:	0.00 m/s 🜲
Power Line File:	1
Shield Line File:	(1.1.1)
Drainage Thread File:	
Output Path: /work/workfile/data/test/cache/SagAnaly	sis/
	~
Output File Format: csv	
#### **Parameters**

- Sag Analysis(checked by default): Checked to calculate sag etc.
  - Adjust Sag With Point Cloud(unchecked by default): Adjust sag based on point cloud.
  - Distance to Ground(unchecked by default): Calculate distance to ground.
  - Sag Deviation(unchecked by default): Calculate Sag Deviation.
  - Observed Temperature: Temperature when scanning.
  - Observed Wind Speed(m/s): Wind speed when scanning.
  - **Powerline File**: Set input file for powerline sag analysis, file format:shp.
  - Shield Line File: Set input file for ground conductor sag analysis, file format:shp.
  - Conductor File: Set input file for conductor sag analysis, file format:shp.
  - **Output Path**: cache/SagAnalysis/ by default.
  - Output Format(csv by default): support csv and xls.
- Generate Report(checked be default): Generate report.
  - Assessor Company: Assessor company.
  - Electrical Transmission Bureau/Company: Electrical transmission bureau/company.
  - Line Name: Line name.
  - Target Coordinate: Target Coordinate System.
  - **Report path**: Path to store result files.
- **Threads Num(4 by default)**: Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.

Note: Input data includes vector file and simulation file\*.LiSim.And the vector file should be shapefile(.shp) created by vectorization, not simulation.

## **Phase Spacing Analysis**

#### Summary

This function is used to calculate and analyze the distances between power lines, and then generate the analysis report. The phase spacing will change if the distance is too long or too short; the temperature is too high; or the line is broken. Click to add the data to be processed. Click to remove the selected data. Click is to clear the data list.

#### Usage

Click Completion Analysis > Phase Spacing

D:/work/workfile/data/test/data/20-21(20_21).LiData D:/work/workfile/data/test/data/19-20(19_20).LiData motion Option ] Phase Spacing Analysis	File	og	
unction Option          Phase Spacing Analysis       Generate Report         hase Spacing Analysis       Generate Report         Profile Thickness:       5.00m         Cluster Threshold:       3.50m         Calculate Horizontal Distance Of Double Circuit Line         Based on Shp File	vork/wor vork/wor	file/data/test/data/20-21(20_21).LiData file/data/test/data/19-20(19_20).LiData	+
Profile Thickness: 5.00m Cluster Threshold: 3.50m Calculate Horizontal Distance Of Double Circuit Line Based on Shp File	cion Opti 1ase Spac e Spacing	n ng Analysis 🗹 Generate Report Analysis Generate Report	
Cluster Threshold: 3.50m Calculate Horizontal Distance Of Double Circuit Line Based on Shp File	file Thi	kness: 5.00m	•
Calculate Horizontal Distance Of Double Circuit Line	ster Thr	shold: 3.50m	*
Based on Shp File	Calculat	Horizontal Distance Of Double Circuit Line	5 B
	Based on	Shp File	
Shp File: 🗸 🗸	File:	×	

#### Settings

- **Phase Spacing Analysis**: This option is checked by default. If it is checked, the software will perform phase spacing analysis; if not, the function will not be executed.
  - **Profile Thickness (meters) (default value is "5.0")**: The thickness of the cross profile of the power line which is used to extract the point cloud for calculating. The software can record the currently setting and when the user open this function again, the setting will be kept.
  - **Cluster Threshold (meters) (default value is "3.5")**: The maximum spatial separation distance when the point cloud data is clustered. Power line points smaller than the threshold will be clustered into a cluster. The software can record the currently setting and when the user open this function again, the setting will be kept.
  - **Calculate Horizontal Distance of Double Circuit Line**: Not selected by default. When selected, if the power line is a double loop, the horizontal distance between the left and right sides will be calculated.
  - **Based On Shp File**: Not selected by default. When selected, a power line vector file can be added, and the vector is used as the basis for calculating the distance between phases. Suitable for special sections of certain line situations.
- **Generate Report**: This option is checked by default. If this option is checked the analysis report will be generated; if the option is unchecked, the analysis report will not be generated.
  - Assessor Company: The company which generates the report.
  - Electrical Transmission Bureau/Company: The name of power supply bureau or company.
  - Line Name: Line name.
  - Target Coordinate: The coordinate system used in the report.
  - Report Path: The output path of the report.
- **Threads Num(default value is "4")**: Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.

Note: After the detection, the software will export the detection result file for each segment. User can check the accuracy of the analysis in phase spacing analysis list. Each row contains a phase spacing. And the name, coordinates of the target point, and the point cloud it belongs to will be recorded in different columns.

# **Drainage Thread Clearance Analysis**

#### Summary

This function is used to calculate and analyze the clearance distances between the drainage threads and the transmission towers, and generate the analysis report. When the clearance distance between the drainage thread and the transmission tower is too small, it will become very dangerous. Before executing this function, user needs to classify the drainage thread and transmission tower in the point cloud. This function can process multiple data simultaneously. Click — to add the data to be processed. Click — to remove the selected file. Click / to clear the data list.

#### Usage

Click Completion Analysis > Drainage Thread.

Data File Log				
D:/work/workfile/data/test D:/work/workfile/data/test	/data/20-21(20_21 /data/19-20(19_20	)).LiData )).LiData		÷
				1
<mark>)s: Please classify the drainag</mark> Drainage Thread Analysis Drainage Thread Parameter	e thread points first Generate Report	🗹 Generate Report		
Cluster Threshold: 2	m	Standard Distance:	10000	
			3.0	m
🗌 Based on Shp File			3.0	m
Based on Shp File			3.0	m
Based on Shp File Shp File: Distance to Tower Body			3.0	m

- **Drainage Thread Analysis**: This option is checked by default. If this option is checked, the software will perform drainage thread clearance analysis. If this option is unchecked, the analysis will not be done.
  - Cluster Threshold(meter)(default value is "2.0"): The maximum distance for the point cloud data clustering. If the distance between two points is less than this value, they will be considered as on the same drainage thread. Thus, user should input a value that the distances between most of the points on the same drainage thread are less than. When the clustering splits the same drainage thread into several ones, user needs to increase this value. When more than one drainage threads are clustered as one, user needs to decrease this value.
  - Standard Distance(meter)(default value is "3.0"): The standard distance from the drainage thread to the transmission tower. It is disqualified if the distance from the drainage thread to the transmission tower is less than this value. The software can record the currently setting and when the user open this function again, the setting will be kept.
  - **Shp File**: This option is unchecked by default. If this option is checked, the position information of the drainage threads will be extracted from the input shp file. If this option is unchecked, the position information of the drainage thread will be extracted from the point cloud. The software can record the currently setting and when the user open this function again, the setting will be kept.
  - **Distance to Tower Body**: This option is unchecked by default. If this option is checked, the clearance distance from the drainage thread to the tower body (without the cross arms) will be calculated. If this option is unchecked, the clearance distance from the drainage thread to the tower body (the cross arms included) will be calculated.
- **Generate Report**: This option is checked by default. If this option is checked the analysis report will be generated; if the option is unchecked, the analysis report will not be generated.
  - Report Name: The title of the report.
  - Assessor Company: The company which generates the report.
  - Electrical Transmission Bureau/Company: The name of power supply bureau or company.
  - Line Name: Line name.
  - Target Coordinate: The coordinate system used in the report.
  - Report Path: The output path of the report.
- **Threads Num(default value is "4")**: Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.

# **Spacer Analysis**

#### Summary

#### Usage

Click Completion Analysis > Spacer.

	1
Spacer Analyis 🛛 Generate Report	
Spacer Class: 26-Spacer	•
Profile Thickness: 5.00	m 🖈
Cluster Threshold: 3.50	n 🖈
System Error: 0.00	

- **Spacer Analysis**: This option is checked by default. If it is checked, the software will perform spacers analysis; if not, the function will not be executed.
  - Spacer Class(default value is "26"): The class number of the spacers in the input point cloud.
  - **Profile Thickness(meters)(default value is "5.0")**: The thickness of the cross profile which is used to extract the point cloud for calculating. The software can record the currently setting and when the user open this function again, the setting will be kept.
  - **Cluster Threshold(meters)(default value is "3.5")**: The maximum spatial separation distance when point cloud data is clustered. Point clouds smaller than this threshold will be clustered into a cluster. The software can record the currently setting and when the user open this function again, the setting will be kept.
  - **System Error(meters)(default value is "0")**: Affected by the accuracy of the point cloud and the classification, there will be errors in the result of the spacer length. This system error value will help to correct the result by being added to the result.
- **Generate Report**: This option is checked by default. If this option is checked the analysis report will be generated; if the option is unchecked, the analysis report will not be generated.
  - Report Name: The title of the report.
  - Assessor Company: The company which generates the report.
  - Electrical Transmission Bureau/Company: The name of power supply bureau or company.
  - Line Name: Line name.
  - Target Coordinate: The coordinate system used in the report.
  - **Report Path**: The output path of the report.
- **Threads Num(default value is "4")**: Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.

## **Tension Tower Rotation Angle Analysis**

#### Summary

Used to calculate the tension tower rotation angle, and then generate the analysis report. The interface of this function is shown as follow. This function can process multiple data simultaneously. Click to add the data to be processed, click — to remove the selected file, click / to clear the data list.

#### Usage

#### Click Completion Analysis > Rotation Angle

Data File Log				
D:/work/workfile/ D:/work/workfile/	data/test/data/19-20(1 data/test/data/18-19(1	19_20).LiData 18_19).LiData		4
Function Option Rotation Angle .	malysis	🗹 Generate Report	*	/
Assessor Company:		Electrical Transmission Bureau/Company:	-	
Line Name:	11			
Carget Coordinate:	WGS 84		•	
Report Path:	D:/work/workfile/dat	a/test/AnalysisReport/		
				0220100

- Rotation Angle Analysis: This option is checked by default. If it is checked, the software will perform tension tower rotation analysis; if not, the function will not be executed.
- Generate Report: This option is checked by default. If this option is checked the analysis report will be generated; if the option is unchecked, the analysis report will not be generated.
  - Assessor Company: The company which generates the report.
  - Electrical Transmission Bureau/Company: The name of power supply bureau or company.
  - Line Name: Line name.
  - Target Coordinate: The coordinate system used in the report.
  - Report Path: The output path of the report.

## **Insulator Analysis**

#### Summary

This function is used to calculate the inclination information of insulators in power lines and generate analysis reports. This function requires classification of insulators in advance. The function interface is shown in the figure below. This function can process multiple data at the same time. Click to add pending data, click to remove the selected data, click to clear data list.

#### Usage

Click Completion Analysis > Insulator

Data File Log				
D:/work/workfile/o D:/work/workfile/o	data/test/data/ data/test/data/	20-21(20_21 19-20(19_20	).LiData )).LiData	4
				1
Analysis farameter	Generate Re	port		
Insulator Class:	27-Insulator			•
Cluster Threshold:	3.50			<b>\$</b> m

- Insulator Class(default value is "27"): Class number of insulators in point cloud data.
- Cluster Threshold(meters)(default value is "3.5"): The maximum spatial spacing distance for the clustering of insulator point cloud data, and insulators less than the threshold will be clustered into a cluster.

- **Generate Report**: This option is checked by default. If this option is checked the analysis report will be generated; if the option is unchecked, the analysis report will not be generated.
  - Assessor Company: The company which generates the report.
  - Electrical Transmission Bureau/Company: The name of power supply bureau or company.
  - Line Name: Line name.
  - Target Coordinate: The coordinate system used in the report.
  - Report Path: The output path of the report.
- **Threads Num(default value is "4")**: Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.

# **Power Line And Shield Line Distance Analysis**

#### Summary

This function is used to automatically analyze and calculate the distance between power line and shield line and generate analysis report. The function interface is shown in the figure below. This function can process multiple data at the same time.Click to add the data to be processed, click to remove selected data, click to clear data list.

#### Usage

Click Completion Analysis > Power line and shield line distance

Data File Log			
D:/work/workfile/d: D:/work/workfile/d:	ata/test/data/20-21(; ata/test/data/19-20(	20_21).LiData 19_20).LiData	
Analysis	Correcto Proved	🗹 Report	
Knalysis farameter □ Celculate In Th	e Middle Of Section		
Profile Thickness:	0.50m		\$
] Based on Vector o	r Simulation Data		****
ower Line File:			559
Yower Line File:			 -

- Calculate In The Middle Of Section: Not selected by default. Check it to calculate the pitch in the middle of the pitch, uncheck it to calculate the pitch in the entire range.
- **Profile Thickness(default value is 0.5m)**: It is used to set the thickness of the spacing slice of the guide wire and to calculate the spacing slice.
- **Generate Report**: This option is checked by default. If this option is checked the analysis report will be generated; if the option is unchecked, the analysis report will not be generated.
  - Assessor Company: The company which generates the report.
  - Electrical Transmission Bureau/Company: The name of power supply bureau or company.
  - Line Name: Line name.
  - Target Coordinate: The coordinate system used in the report.
  - **Report Path**: The output path of the report.
- **Threads Num(default value is "4")**: Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.

## **Protect Angle Analysis**

#### Summary

This function is used to analyze the protection Angle of transmission tower and generate analysis report. When using this function, you must ensure that the center of the tower is selected accurately.The function interface is shown in the figure below. This function can process multiple data at the same time. Click to add pending data, click to remove the selected data, click to clear data list.

#### Usage

Click Completion Analysis > Protect Angle

FILL TOS		
D:/work/workfile/ D:/work/workfile/	data/test/data/19-20(19_20).LiData data/test/data/18-19(18_19).LiData	
		1
laasa alassifu Tom	ar painte in advance	
Parameter Gener	ate Report	
Profile Thickness:	5.00m	\$
•••••	2.00m	\$
Filter Width:		
filter Width∶		
filter Width∶		

- **Profile Thickness(meters)(default value is "5.0")**: The section thickness of the tower along the line direction is used to extract the tower point cloud. When the point cloud is dense, the value can be reduced appropriately. The value ranges from 2 to 5m.
- Filter Width(default value is "2.00m"): Point cloud filtering width.
- **Generate Report**: This option is checked by default. If this option is checked the analysis report will be generated; if the option is unchecked, the analysis report will not be generated.
  - Assessor Company: The company which generates the report.
  - Electrical Transmission Bureau/Company: The name of power supply bureau or company.
  - Line Name: Line Name.
  - Target Coordinate: The coordinate system used in the report.
  - Report Path: The output path of the report.
- Threads Num(default value is"4"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.

# **Measure Anchor Bolt Information**

## Summary

This function is used to measure foot screw information during infrastructure acceptance and generate analysis reports. The functional interface is shown in the following figure.

## Usage

Click Completion Analysis > Other > Anchor Bolt

	Point Name	Х	Y	Z	^
1	Anchor Bolt1	Null	Null	Null	
2	Anchor Bolt2	Null	Null	Null	
3	Anchor Bolt3	Null	Null	Null	
4	Anchor Bolt4	Null	Null	Null	
5	Anchor Bolt5	Null	Null	Null	
6	Anchor Bolt6	Null	Null	Null	
7	Anchor Bolt7	Null	Null	Null	
8	Anchor Bolt8	Null	Null	Null	~
es	ult				

Select the position of the foot spiral.



/ Clear the result list record.

Save the foot spiral measurement results.

# **Lighting Protector Inclination Analysis**

#### Summary

The function is used to analyze the tilt of the Lighting Protector and generate analysis report. Ensure the data has been classified. The function interface is shown in the following figure, this function can process multiple data at the same time, Click to add data to be process, click to remove selected data, click is to clear data list.

#### Usage

Click Completion Analysis > Other > Lighting Protector Inclination

Data File Log		
D:/work/workfile/data/test/dat D:/work/workfile/data/test/dat	a/20-21(20_21).LiData a/19-20(19_20).LiData	
Parameter Generate Report Lighting Protector Class:	17-Structure	i
LayerHeight:	0.30m	
Lighting Protector Min Radius:	1.50m	•
Standard Ratio:	0. 500%	(
reads Num (1-32) · 4	Default Value Start	Exit

### **Parameter Settings**

• Lighting Protector Class: Category number of the arrester in the point cloud data.

- Layer height(The default value is "0.3m"): For the horizontal slice thickness of the arrester, the smaller the thickness is, the more precise the calculation is, and the higher the requirement for the density of the point cloud is. In the case of sparse point clouds, the value can be appropriately increased.
- Lighting Protector Min Radius(The default value is "1.50m"): The minimum radius of the arrester is used to obtain point cloud data.
- Standard ratio(The default value is "0.5%"): According to the standard ratio provided by the specification.
- **Generate report**: Selected by default. If this parameter is selected, an analysis report is generated based on the analysis result file. If unchecked, no report will be generated.
  - Assessor Company: The company that generated the report.
  - Electrical Transmission Bureau/Company: The name of the power supply bureau.
  - Line Name: Line name.
  - Target Coordinate: The coordinate system used in the report.
  - Report Path: Report output path.
- Threads Num(The default value is "4"): Set the number of threads. 1-32 threads can be supported. The software can record the user's current settings and automatically restore the Settings when it is turned on again.

# Earth Electrode Line And Drainage Thread Distance Analysis

#### Summary

This function is mainly used to automatically analyze and calculate the distance between the grounding electrode wire and the drainage wire, and generate an analysis report. The functional interface is shown in the following figure, which can process multiple data simultaneously. Click—to add pending data, click—to remove the selected data, click is to clear the data list.

#### Usage

Click Completion Analysis > Other > Earth Electrode Line

D:/work/workfile/dat D:/work/workfile/dat	a/test/data/20-21(20_21).LiData a/test/data/19-20(19_20).LiData	÷
Function Option Analysis	🗹 Report	
Analysis Parameters	Generate Report	
Drainage Thread:	28-Drainage Thread	•
Earth Electrode Line:	29-Reserved29	•
Standard Distance:	4. 70m	۲
reads Num (1-32): 4	1 Star	+ Exit

#### **Parameter settings**

- Analysis: Selected by default. If selected, calculate the distance between the grounding electrode wire and the drainage wire; If not selected, it will not be calculated.
- Drainage Thread(default to "28"): Set the category of drainage lines.
- Earth Electrode Line(default to "29"): Set the category of grounding electrode wire.

- Standard Distance(meters)(default to "4.7"): Set the standard distance between the grounding electrode wire and the drainage wire.
- **Generate report**: Selected by default. If this parameter is selected, an analysis report is generated based on the analysis result file. If unchecked, no report will be generated.
  - Assessor Company: The company that generated the report.
  - Electrical Transmission Bureau/Company: The name of the power supply bureau.
  - Line Name: Line name.
  - Target Coordinate: The coordinate system used in the report.
  - Report Path: Report output path.
- Threads Num(The default value is "4"): Set the number of threads. 1-32 threads can be supported. The software can record the user's current settings and automatically restore the Settings when it is turned on again.

# **Danger Point Sag Analysis**

#### Summary

This function is used to automatically analyze and calculate the sag of dangerous points. The functional interface is shown in the following figure, which can process multiple data simultaneously. Click to add pending data, click to remove the selected data, click to clear the data list.

#### Usage

Click Completion Analysis > Other > Danger Point Sag

lata File Log	
D:/work/workfile/data/test/data/20-21(20_21).LiData D:/work/workfile/data/test/data/19-20(19_20).LiData	
	1
ag Analysis Data Type • Based on Point Cloud () Based on Vector Data () Based on Simu	ulation Data
ag Analysis Data Type Based on Point Cloud () Based on Vector Data () Based on Simu Power Line File:	ulation Data
ag Analysis Data Type	lation Data
ag Analysis Data Type	1 ation Data

#### **Parameter settings**

- **Data Type**: The default selection is based on point cloud data. If selected, obtain the dangerous point analysis results based on point cloud data to calculate the sag of dangerous points.
- Based on Point Cloud: Used to obtain dangerous point analysis results based on point cloud data.

- Based on Vector Data: Used to obtain the results of hazard point analysis based on vector data.
- **Based on Simulation Data**: Used to obtain the analysis results of hazardous points based on working condition simulation data.
- **Power Line File**: Set the input file for power line sag analysis, supporting vectorized files and operating condition simulation files, with formats of . *shp and* . shp, respectively LiSim.
- **Drainage Line File**: Set the input file for drainage line sag analysis, supporting vectorized files and working condition simulation files, with formats of . *shp and* . shp, respectively LiSim.
- **Output Path**: Set the analysis result file output path, which defaults to "cache/DangerPointSagAnalysis/" in the working directory.
- **Thread Num(default value is "4")**: Set the number of running threads for the function, which can support 1-32 threads. The software can record the user's current settings.

## Wind Turbine Tower Inclination Analysis

#### Summary

This function is mainly used to automatically analyze and calculate the inclination of the wind turbine tower, and generate analysis reports. The function but to the function of the second se tower, and generate analysis reports. The functional interface is shown in the following figure, which can process multiple data simultaneously. Click -to add pending data, click -to remove the selected data, click dto clear the data list.

#### Usage

Click Completion Analysis > Other > Wind Turbine Tower Inclination

Data File Log				
D:/work/workfile/da D:/work/workfile/da	ta/test/data/20-21 ta/test/data/19-20	(20_21).LiData (19_20).LiData		÷
				1
Junction Option				
🛛 Analysis		🗹 Report		
Analysis Parameters	Generate Report			
Cower Classfication:	17-Structure			•
Cower Width:	20.00m			
Layer Height:	0.50m			4
Standard Value:	0.30%			\$
				-
1 W (1 - 20) / A		Default Value	Stort	Frit

#### **Parameter settings**

- **Analysis**: Selected by default. Select to analyze the inclination of the wind turbine tower; If not selected, do not analyze.
- Tower Classification(default to "18"): Set the category of the wind turbine tower.
- Tower Width(meters)(default to "20"): Set the tower width to set the range of sampling points. The software can record the user's current settings.
- Layer Height(meters) (default to "0.5"): Set the tower analysis layer height to extract the point cloud data to be calculated. The software can record the user's current settings.
- **Standard Value(default to "0.3")**: Set the wind turbine tower inclination normative ratio to determine whether the tower inclination exceeds the specification. The software can record the user's current settings.
- **Generate report**: Selected by default. If this parameter is selected, an analysis report is generated based on the analysis result file. If unchecked, no report will be generated.
  - Assessor Company: The company that generated the report.
  - Electrical Transmission Bureau/Company: The name of the power supply bureau.
  - Line Name: Line name.
  - Target Coordinate: The coordinate system used in the report.
  - **Report Path**: Report output path.
- Threads Num(The default value is "4"): Set the number of threads. 1-32 threads can be supported. The software can record the user's current settings and automatically restore the Settings when it is turned on again.

## **Merge Report**

#### Summary

This feature is used to merge reports. The functional interface is shown in the following figure, which can process multiple data simultaneously. Click to add the data to be processed, click to remove the selected data, click is to clear the data list.

#### Usage

Click Completion Analysis > Other > Merge Report

LiPowerline Report	×
Word Document	
ragging to sort (Nums: 5)	
D:/test1.docx	
D:/test3.docx	
	· · · · · · · ·
utput Path D./	Chaora
alput Tatk 2.7	
	Start
	0%

#### **Parameter settings**

• Output Path: Set the path for saving merged files.

Note: This feature is mainly used to concatenate multiple Word documents.

## **Fine Inspection**

#### Summary

To generate fine trajectory based on tower marker points and point cloud data. This module includes project configuration, mark tower, trajectory planning, and image data processing.



## Usage

Click the "Fine Inspection" tab to open the menu, and click the "Start/End" button to expand the trajectory planning related function menu, as shown in the figure below.

Start/End	Open     Split       Save     Merge       Auto Save	► Undo Redo Delete Trajectory	Cip Mark Part Automatic From Tower Point - Generated - Mode	Safety	Edit + Add	Simulation + Batch +	🤏 Display
Trajectory	File	Vector Editor	Trajectory		Waypoint	Tools	Setting

- Fine Inspection Menu
- File Menu
- Project Configuration
- Trajectory Menu
- Waypoint
- Tools Menu
- Setting
- Defect Recognition

## **Fine Inspection Menu**

Switch to fine inspection page, There are four functions: "Project Configuration", "Mark Tower", "Trajectory", "Image". As shown below.



- **Project Configuration**: Add inspection configuration and camera setting in addition to the basic configuration. Inspection configuration is used to configure part point list and trajectory generation parameters for different types of towers. Camera setting manages camera parameters by opening and saving camera parameter file. The specific operation will be explained later in the text.
- Mark Tower: Basic function for marking tower location and editing tower name and type.
- Start/End: Turn on and off the trajectory planning function.
- Defect Recognition: Split, rename, mark defects, and export reports for UAV inspection pictures.

Click "Start/End" button, Expand the trajectory planning related function menu, including "File", "Vector Editing", "Trajectory", "Waypoint", "Tools and Setting", as shown below.

Start/End	Copen Split	► Undo Redo Relete Trajectory	Clip Mark Part Automatic From Safety Tower Point - Generated - Model -	Edit +> Add	Simulation + Batch +	🤧 Display 🤖 Shortcut
Trajectory	File	Vector Editor	Trajectory	Waypoint	Tools	Setting

- File: Open, save, auto save, split and merge trajectory files.
- Vector Edit: Trajectory planning operation undo and redo operation, trajectory deletion.
- **Trajectory**: Operation related to trajectory generation, including clipping tower, marking part points, automatic generation, model generating trajectory and safety.
- **Waypoint**: Waypoint editing related functions, including modifying waypoints, adding waypoints and deleting waypoints.
- **Tools**: Simulation includes flight simulation and flight time calculation. Batch includes statistics, batch check, export to CSV and batch attribute modification, conversion to other formats, and conversion to DJI Pilot.
- Setting: Display settings and shortcut key settings.

# **File Operation**

The fine inspection file menu is shown in the following figure, including functions such as "Open", "Save", "Auto Save", "Split", and "Merge".



#### Open



open the .json format trajectory file.

#### Save

Save the .json format trajectory file. By default, it is saved as the trajectory .json file in the fine inspection folder under the working directory.

#### **Auto Save**

Save the .json format file. By default, it is saved as the trajectory .json file in the fine inspection folder under the working directory.

A Auto Save Trajectory	rite	
Auto Save		
Time Interval: 3.0 min	S.	\$
		1010a

- Auto Save(Check by default): If checked, the trajectory file will be automatically saved every time interval.
- Time Interval(3.0 minute by default): Set the time interval value.
- Default: Modify all parameters to default values.

#### Split

Split the trajectory file in .json format according to the selected waypoint.

#### Merge



Merge .json format trajectory files.

		4
🗹 Delete Duplicate Part Points 🛛 🗌 Us	e Unified Tower Infor	mation
☑ Delete Duplicate Part Points   □ Us Dutput File: D:/data/MergedTrajectory.json	e Unified Tower Infor	mation

- Delete Duplicate Part Points(Check by default): If checked, delete duplicate part points.
- Use Unified Tower Information(Uncheck by default): If checked, use the tower information of the first part point uniformly.
- Output File: Set the path for saving trajectory.

# **Vector Editor Operation**

The fine inspection vector editor menu is shown in the following figure, including functions such as "Undo", "Redo" and "Delete Trajectory".



#### Undo

Undo the trajectory modifications.

#### Redo

Redo the route modifications.

#### **Delete Trajectory**



# **Project Configuration**

Project configuration is the first step in trajectory planning. Trajectory planning can only be carried out after the configuration parameters and the points of different tower components are determined. Click Project Configuration -> Inspection Configuration, as shown in the figure below.

	<b>1</b>					
Irs	ajectory Base Setting	1				
an	era Distance:	3.000		 ] n Height Above Tower:	8.000	
bs	tacle Ayoid Distance	2.50		() n		
	Need Enter and Leave	Way Points		Start Side	Right	
1	Need Way Points Thro	ugh Tover		Priority Side:	Big Side	
O'A	ver Type Setting					
1	Show Phase	13 41 1				
0.8	er Type Hane: AU Io	ible Circuit Li	near Tower			
	Part Name In	nage Number	ical Camera Ang	Horizontal Ca	amera Angle(°)	^
1	Left Circuit Lo.	1	0.0000	0.0	0000	
z	Left Circuit Lo.	1	0.0000	0.0	0000	
3	Left Circuit Lo-	1	0.0000	0.0	0000	
4	Left Circuit Mi.	1	0.0000	0.0	0000	
	Left Circuit Mi"	1	0.0000	0.0	0000	
2	Left Circuit Mi…	1	0.0000	0.0	0000	
6	Left Circuit Up.	1	0.0000	0.0	0000	
5 7		1	0.0000	0.0	0000	
о 6 7 3	Left Circuit Up"					×

#### **Trajectory Base Setting**

- Camera Distance: The distance from the waypoint to the point of the tower component.
- Obstacle Avoid Distance: The minimum safe distance between the trajectory and the wire of the tower.
- Height Above Tower: The height of the UAV from the top of the tower.
- Need Enter and Leave Way Points: Check if you need the entry point and exit point. The entry point and exit point will be slightly higher than the top of the tower, located on the left and right of the tower.
- Need Way Points Through Tower: Check if the tower point is needed.
- **Start Side**: It is mainly divided into the right side of the line and the left side of the line, which is the take-off side of the UAV.
- **Priority Side**: Mainly includes default, small side and big side. For scanning the hanging point of the tension tower insulator, generally the small side is selected.

## **Tower Type Setting**

The software has built-in 9 tower type trajectory configuration lists, each configuration has defined component point names and parameters, which can be selected according to the tower type. The 9 tower types are shown below.

- 1. AC Double Circuit Linear Tower
- 2, AC Double Circuit Tension Tower(Right Jumper)
- 3, AC Single Circuit Guyed Linear Tower
- 4, AC Single Circuit Linear Tower(Middle Phase I Type Insulator)

- 5, AC Single Circuit Linear Tower(Middle Phase V Type Insulator)
- 6, AC Single Circuit Tension Tower(Left Arm Double Jumper)
- 7, AC Single Circuit Tension Tower(Right Arm Double Jumper)
- 8, DC Single Circuit Linear Tower(V Type Insulator)
- 9, DC Single Circuit Tension Tower

Tov	er Type Settin	×8		
	shov Phase			
Toy.	ar Type Bane:	AC Double Circuit Linear Tower		-
Γ	ontal Camera	AC Double Circuit Linear Tower AC Double Circuit Tension Tower(Hight Jumper) AC Single Circuit Grand Linear Tower		
13	0.0000	AC Single Circuit Linear Tower Widdle Fhase I Type Insulator) AC Single Circuit Linear Tower Widdle Fhase V Type Insulator)		
14	0.0000	AD Single Grouit Vension Tover(Leit Arm Houble Jumper) AD Single Grouit Tension Tover(Right Arm Double Jumper) DD Single Grouit Linear Tover(W Type Insulator)		
15	0.0000	DC Single Circuit Tension Toyer Whome	т туре тноиаког	TOWER LING

• Show Phase: If uncheck, only the part name, image number, vertical camera angle and horizontal camera angle will be displayed. After ticking, the parameters of circuit type, phase, big or small side, ironware type and insulator type will be displayed.

4 😁								
 Drajectory Base Setting:								
Camera Distance: 3.0	00		0 m Height a	Above Tover	8, 000			\$
Ubstacle Aroid Distance: 2.5	0		: m					
🕗 Beed Enter and Leave Vay 1	eints		Start S	ide:	Ri ght			1
2 Feed Way Points Through 7	wer		Priority	y Side:	Big Side			1
ontal Camera Angle(")	Circuit Type	Phase	Big Or Small Side	Irom	ware Type	Insulator Type	^	
over Type Name: AC Double C	irovit Linear Tower					· + -	- #	0
ontal Camera Angle(")	Circuit Type	Phase	Big Or Small Side	Irom	ware Type	Insulator Type	Ŷ	
13 0.0000	Right Circuit	Upper	194	І Тур	e Insulator	Whole String	_	H
14 0.0000	Right Circuit	Upper	199	І Тур	e Insulator	Conductor End		
15 0.0000	Right Circuit	Middle	(4)	І Тур	e Insulator	Tower End		-
16 0.0000	Right Circuit	Middle	240	І Тур	e Insulator	Whole String		
17 0.0000	Right Circuit	Middle	90 C	І Тур	e Insulator	Conductor End		12
18 0.0000	Right Circuit	Lower	1852	І Тур	e Insulator	Tower End		
19 0.0000	Right Circuit	Lower		І Тур	e Insulator	Whole String		T
20 0.0000	Right Circuit	Lower		І Тур	e Insulator	Conductor End	Y	
<							>	

• Add New Setting Table: If you do not find the configuration table of the tower type you need, you can click the plus sign on the right to customize and add a new tower configuration table, as shown below.

4 😂								
rajectory Base Settin	ng:							
amera Distance:	3.000		🗘 m Height	Above Tower	8.000			:
bstacle Avoid Distanc	e: 2.50		: m					
Beed Enter and Leav	e Vey Foints		Start	Side:	Ri ght			-
Feed Way Points The	ough Tower		Priori	ty Side:	Big Side			
13 0.0000	piete cheste	Add Nev Setting	Fable			>	e le sring	1.0
13 0.0000	Distant Charles	Add Nev Setting	LUDIC				le Sring	-
		New Towar Fime Name	New Tower Fimel					
14 0.0000	Right Circuit	New Tower Type Name:	New Tower TypeO Other Tower Type				actor End	
14 0.0000 15 0.0000	Right Circuit Right Circuit	New Tower Type Name: Fart Name List: Single Circuit	New Tower TypeO Other Tower Type	O louble Ci	rouit		actor End	
14         0.0000           15         0.0000           16         0.0000	Right Circuit Right Circuit Right Circuit Right Circuit	New Tower Type Name: Fart Name List: Single Circuit	New Tower TypeO Other Tower Type	O Double Ci	rouit	•	ver End le String	
14         0.0000           15         0.0000           16         0.0000           17         0.0000	Right Circuit Right Circuit Right Circuit Right Circuit Right Circuit	New Tower Type Name: Fart Name List: Single Circuit	New Tower TypeO Other Tower Type	) Double Ci	r cuit OK	- Cancel	ver End le String uctor End	
14         0.0000           15         0.0000           16         0.0000           17         0.0000           18         0.0000	Right Circuit Right Circuit Right Circuit Right Circuit Right Circuit Right Circuit	New Tower Type Name: Fart Name List: Single Circuit Lower	Bew Tower TypeO Other Tower Type	) Iouble Ci	reuit OX Insulator	Cancel	e stor End ver End le String uctor End	
14         0.0000           15         0.0000           16         0.0000           17         0.0000           18         0.0000           19         0.0000	Right Gravi Right Gravi Right Gravi Right Circuit Right Circuit Right Circuit	Few Tower Type Name: Fart Name List: Single Circuit Lower Lower	Bew Tower TypeO Other Tower Type - -	) Jouble Ci T Type T Type	reuit OX Insulator	Cancel	Lector End Lestring Lector End Lestring Lower End Incle String	

- Delete Tower Type Setting: Click the minus button to delete the tower type configuration.
- Change Tower Type Setting Order: Click the green arrow button to change the configuration order of the tower types.

4 😫										
Trajectory Base :	Setting:									
Canera Distance:	3.000			‡ a	n Height Above Tover	8.000				:
Obstacle Aroid I	istance: 2.50			: .	n					
- Keed Enter an	d Leave Vay Foints				Start Side:	Right				-
🗹 Feed Way Poin	ts Through Tower				Priority Side:	Big Side			2	-
ower Type Wane:	AC Double Circuit Line	ear Tower		AC Double	Circuit Linear Tower			•		9
lover Type Name:	AC Double Circuit Line	ear Tower		AC Double	Circuit Linear Tower		_	• •	141	1
ontal Camera	a Angle(") Circ	uit Type	AC	Double Circuit 1	Tension Tower(Right J	umper)	_	sulator Type	^	
13 0.0000	Rig	ht Circuit		AC Single Circ	uit Guyed Linear Tow	er	12	Vhole String		4
14 <b>0</b> .0000	Rig	ht Circuit	AC Single	Circuit Linear To	ower(Middle Phase I 1	ype insulator)		ductor End		
15 0.0000	Rig	ht Circuit	AC Single	Circuit Linear To	wer(Middle Phase V	Type Insulator)		Tower End		-
16 0.0000	Rig	ht Circuit	AC Singl	e Circuit Tensio	n Tower(Left Arm Dou	ible Jumper)		/hole String		
17 <b>0</b> .0000	Rig	ht Circuit	AC Single	Circuit Tension	Tower(Right Arm Do	uble Jumper)	2	inductor End		
18 0.0000	Rig	ht Circuit	DC	Single Circuit Li	near Tower(V Type In	sulator)		Tower End		
19 0.0000	Rig	ht Circuit		DC Single (	Circuit Tension Tower			/hole String		1
20 0.0000 «	Rig	ht Circuit				OX 0	sncel	inductor End	~	

• **Tower Image Preview**: Preview tower type image, 《 and 》 flip through images forward and backward.

w 👞			Calera Settings			
1 🗾						
irajectory dase setting. Samera Distance	3.000		n Heisht éhove Fover	a 000		2
bstecle Aroid Distance:	2.50		: n	1		
Beed Enter and Leave	Vay Foints		Sturt Side:	Ri ght		
/ Feed Way Points Throu	igh Tower		Priority Side:	Big Side		-
ower Type Wane: AC Dou	ble Circuit Linear Tower				• ] 🗗 📼 [	
over type wane. At but	nie circuit Einear Tower		Net			
onial Camera Angle	) Circuit Type	Phas	- Det Onv	vare type	Insulator Type	
	Right Check		PR3	- Inscialor	whiche string	58
14 0.0000	Right Circuit	Upp -	ype	- Insulator	Conductor End	
15 0.0000	Right Circuit	Midd	Ур	a Insulator	Tower End	
16 0.0000	Right Circuit	Midd	ype	e Insulator	Whole String	
0.0000	Right Circuit	Midd	уре	e Insulator	Conductor End	0
18 0.0000	Right Circuit	Lowe	ур	e Insulator	Tower End	
19 0.0000	Right Circuit	Lowe	Ø N ype	e Insulator	Whole String	1
20 0.0000	Right Circuit	Lowe	урч	nsulator	Conductor End	~

• **Part Name List Editing**: The plus and minus signs on the left can add and delete components, and the up and down arrows can adjust the order of the components.

LLI	ing Classify and	Detect Parameters	Inspection Configure	ation Camera Settin	ıgs	
ų	2		_			
fra	jectory Base Settin	.g:				
am	era Distance:	3.000	:	m Height Above Tower:	8.000	÷ .
ıbs	tacle Avoid Distanc	e: 2.50	\$	m		
2	Need Enter and Leav	e Way Points		Start Side:	Right	
Z	Need Way Points Thr	ough Tower		Priority Side:	Big Side	
'ow	er Type Name: AC Do	ouble Circuit Line	ar Tower		•	8
	Part Name I		700 101 808 00			d harden harden
	Fallingine	mage Number	Vertical Camera An	ale(°) H	Iorizontal Camera Angle(°)	^
4	Left Circuit Mi"	mage Number 1	Vertical Camera An 0.0000	gle(°) ⊦	lorizontal Camera Angle(°) 0.0000	^ +
4 5	Left Circuit Mi"	mage Number 1 1	Vertical Camera An 0.0000 0.0000	gle(°) F	lorizontal Camera Angle(°) 0.0000 0.0000	
4 5 6	Left Circuit Mi Left Circuit Mi Left Circuit Mi	mage Number 1 1 1	Vertical Camera An 0.0000 0.0000 0.0000	gle(°) F	lorizontal Camera Angle(*) 0.0000 0.0000 0.0000	
4 5 6 7	Left Circuit Mi <sup>**</sup> Left Circuit Mi <sup>**</sup> Left Circuit Mi <sup>**</sup> Left Circuit Vp <sup>**</sup>	mage Number 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Vertical Camera An 0.0000 0.0000 0.0000 0.0000	gle(°) H	Horizontal Camera Angle(*) 0.0000 0.0000 0.0000 0.0000	
4 5 6 7	Left Circuit Mi** Left Circuit Mi** Left Circuit Mi** Left Circuit Vp** Left Circuit Vp**	mage Number 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Vertical Camera An 0.0000 0.0000 0.0000 0.0000 0.0000	gle(°) F	Horizontal Camera Angle(*)           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000	
4 5 7 8 9	Left Cirouit Mi** Left Cirouit Mi** Left Cirouit Mi** Left Cirouit Vp** Left Cirouit Vp** Left Cirouit Vp*	mage Number 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Vertical Camera An 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	gle(°) H	Iorizontal Camera Angle(*)           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000	
4 5 7 8 9	Left Cirouit Mi** Left Cirouit Mi** Left Cirouit Mi** Left Cirouit Vp** Left Cirouit Vp** Left Cirouit Vp** Left Cirouit Vp*	mage Number 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Vertical Camera An 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 -30.0000	gle(°) F	Iorizontal Camera Angle(*)           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000	

## **Camera Settings**

Multiple types of UAV gimbal cameras are provided by default in the camera settings. The red row indicates the currently used camera, and the right-click button can be used to set the current camera.

N (ma 1.0)				
6 📫 🗖	Ph. 9 (Ph. 4			
Camera Name	DFOV(*)	ige Width(pr	Image Height(pixel)	
Phantom 4 RTK(3:2)	84.00	5472	3648	
Mavic 2 Advanced Visible Light Camera	84.00	8000	6000	
Mavic 2 Advanced Infrared Camera	57.73	640	512	
ZENMUSE H20 Zoom Camera	68.60	5184	3868	
ZENMUSE H20 Wide Angle Camera	82.90	4056	3040	
ZENMUSE H20T	40.60	640	512	
XMISSON	75.00	5472	3648	
ZENMUSE P1	63.50	8192	5460	
ZENMUSE Z30 Zoom Camera	70.96	1920	1080	
ZERNUSE XT 5 Thermal Inaging Cam	31.08	640	512	
2 EVO II Infrared Camera	42.00	640	512	
3 HUIYAN Gen 1 Fixed Focus Visible Lig	79.00	8000	6000	
4 HOIYAN Fixed Focus Infrared Camera(…	42.00	640	512	
5 HUIYAN Wixed Wocus Infrared Camera(	61.00	640	512	
6 HUIYAN Gen 2 Zoon Visible Light Ca…	85.00	8192	6144	
7 M30 Zoom Camera	21.70	8000	6000	~



#### Load default settings.

Open the camera configuration file.

Save the camera configuration file.

# **Trajectory Operation**

#### Usage

The trajectory menu is as shown in the following figure, including clip tower, mark part point, automatic generated, model generation trajectory and safety.



#### **Clip Tower**

Clip tower is mainly to display the tower of the trajectory planning independently for easy trajectory editing.

Clip Tower		₽×
Tower Name:	3#	*
🔽 Rotate Scene		
Horizontal Buffer:	10.00m	÷
Vertical Buffer:	100.00m	\$



- Tower Name: Select the corresponding tower name.
- Rotate Scene: Uncheck, horizontal rotation; check, 3D rotation.
- Horizontal Buffer: Set the horizontal display range.
- Vertical Buffer: Set the vertical display range.

#### **Mark Part Point**

The part point menu of fine inspection is shown in the following figure, including mark part point, delete part point, clear part point, channel perspective, part point recognition, automatic waypoint generation and hide XYZ columns.

En	ver Settings								Towar Inaga	FF eview	
Cu	rent Jower Type: AC Single Circuit Li	near Tover	(Mi da	ile Phase I	C T 3	ype Insu	lato	r) - (<			
	Part Name	x		Ŷ		z		Status	-	1	
1	Left Phase Insulator Conductor End	0.000	:	0.000	+	0.000	1.1	Not Set			-
z	Left Phase Insulator Whole String	0.000	\$	0.000		0.000	0	Not Set		8	1
3	Left Phase Insulator Tower End	0.000	:	0.000	1	0.000	0	Not Set	-		-
4	Left Phase Shield Line	0.000	-	0.000	- +	0.000	-	Not Set			-
5	Middle Phase Insulator Tower End	0.000	-	0.000		0. 000		Not Set		223	
6	Middle Phase Insulator Whole String	0.000	:	0.000	•	0.000	3	Not Set			
7	Middle Phase Insulator Conductor End	0.000	:	0.000	-	O. DOO	2	Not Set			
8	Right Phase Shield Line	0.000	Ĵ	0.000	4	0, 000	3	Not Set		rx 1	
9	Right Phase Insulator Tower End	0.000		00000	*	0.000	÷	Not Set			
10	Right Phase Insulator Whole String	0.000	:	0.000	*	0, 000	÷	Not Set			
11	Right Phase Insulator Conductor End	0.000	÷	0.000	-	O. DOO	-	Not Set			PAR A
12	Small Side Tunnel	0.000		0.000	1	0.000	2	Not Set			
13	Big Side Tunnel	0.000		6.000	-	0.000	-	Not Set		1	1

Note: Before marking part points, it is necessary to mark tower and set the tower type.

## **Tower Settings**

The list of tower types is shown below. There are 9 kinds of conventional tower types built into the software. If you need to add other tower types, add them in Project Configuration->Inspection Configuration.
Curr	ent Tower Name: 1							- 1 owe	r image frevi	en
Curr	ent Tower Type: AC Single Circuit Lin	near Tower()	<b>t</b> i dá	lle Phase	I T <sub>2</sub>	me Insul	ato:	) - <<	1)	
	Part Name	x		Y		z		Status		M
1	Left Phase Insulator Conductor End	0.000	-	0.000	+	0.000	÷	Not Set		
2	Left Phase Insulator Whole String	0.000	1	0.000	Ĵ	0.000	Ĵ	Not Set		
3	Left Phase Insulator Tower End	0.000	-	0.000	÷	0.000	-	Not Set		
4	Left Phase Shield Line	0.000	ž	0.000	÷.	0.000	÷	Not Set	1000	MM -
5	Middle Phase Insulator Tower End	0.000	4	0.000	÷.	0.000	\$	Not Set		<b>CX</b> 3
6 1	Middle Phase Insulator Whole String	0.000	1	0.000	\$	0.000	\$	Not Set		
7 N	liddle Phase Insulator Conductor End	0.000	;	0.000	ļ	0.000	-	Not Set		
8	Right Phase Shield Line	0.000	÷	0.000	÷	0.000	-	Not Set		
9	Right Phase Insulator Tower End	0.000	4	0.000	+	0.000	÷	Not Set	ß	2002Q
10	Right Phase Insulator Whole String	0.000	1	0.000	\$	0.000	\$	Not Set	R	
11	Right Phase Insulator Conductor End	0.000	*	0.000	÷.,	0.000	-	Not Set	E.	
12	Small Side Tunnel	0.000	÷	0.000	÷	0.000	÷	Not Set	đ	
13	Big Side Tunnel	0.000	ţ	0.000	÷	0.000	¢	Not Set	1	V V

## **Mark Part Point**

After selecting the tower type, there will be a corresponding list of part point. Select the corresponding part point on the point cloud according to the order of the traction of the tractio part point on the point cloud according to the order of the list. The status of marked part point is "Has Been Set", and the status of unmarked part point is "Not Set". If there are part point that do not need to be marked, you can skip them directly and select the following part point for marking. After marking all part point, click the marking button again to finish the marking function. The list of part point and the results of part point marking are shown in the following figure.

	and the second	* * 0 0	Mark Part Point 			(B) - 1 -	T		×
			Part Name	X	Y	z z	j tango/	Status	^
		11	Left Circuit Middle P	273494.011	3522422.1)	33. 265	1	Has Been Set	
	and the second	12	Left Circuit Middle P	275484: 371	3522422. BI	33-520.	:	Has Been Set	
		13	Left Circuit Up Phase	273485.701	3522417. 7/ .	36.919	1	Has Been Set	
CASH'S STAND		14	Left Circuit Up Phase	273485.87: 3	8522418. dl C	36.989	1	Has Been Set	
al and the second		15	Left Circuit Up Phase	273485 89) 🕽	3522418.51	37.076	:	Has Been Set	
		16	Left Circuit Up Phase	273495.077	2522421, 2/ ]	37.190	1	Has Been Set	
		17	Left Circuit Up Phase	273485.30	\$522422.1	37.140	1	Has Been Set	
	A CONTRACTOR OF THE OWNER	18	Left Circuit Up Phase	273486.14	8522422. 61	37.040		Has Been Set	
		19	Left Circuit Tunnel	273487.63	2522421, 41 🕽	41.225		Has Been Set	
	and the second	20	Right Circuit Tunnel	273490.011	\$572421.51	41. 349		Has Been Set	
		21	Right Circuit Up Phas	273491.91(	3522418, 41	361780		Has Been Set	
		22	Right Circuit Up Phas	173491.93: 🕻	\$522419, 4: 1	38.944		Has Been Set	
		23	Right Circuit Up Phas	273#91,94 :	3522420, 37	37.107		Has Been Set	
	Sector Sector	24	Right Circuit Up Jum	0.000	0.000 2	0.:000	đ	Not Set	~
A 14 14 14 14 14 14 14 14 14 14 14 14 14					1		_		

## **Delete Part Point**

Select the part point in the list and click the button to delete the part point.

Select the part point in the list and click the button to delete the part point.

Clear

Click the button to clear all marked part point.

#### **Channel Perspective**

Click the button to display the tower from the perspective of the channel.

#### **Automatic Waypoint Generation**

After clicking the button, corresponding waypoints will be automatically generated when generating part point.



- Take Photo(Checked by default): If checked, the waypoint will include photo information.
- Safety Analysis(Unchecked by default): If checked, the safety of the trajectory will be analyzed.
- Camera Type: Set current camera type. The current camera type is set by default through Project Configuration->Camera Settings.
- Edit Waypoint: Switch to edit waypoint function.
- Shooting Distance(m, default value is "5.0"): Set the distance from the waypoint to the part point. •
- Waypoint Speed(m/s, default value is "3.0"): Set the waypoint speed.

#### Hide XYZ Columns

If checked, hide the XYZ columns of the table; If uncheck, display the XYZ columns of the table. 

If checked, hide the XYZ columns of the table; If uncheck, display the XYZ columns of the table.

#### **Tower Image Preview**

Display a preview image of the corresponding current tower type. If clicked ">>", the tower image preview dialog box will be displayed; If clicked "<<", hide="" the="" tower="" type="" image="" preview="" dialog="" box.="" click or (>) to flip through images forward or backward.

#### **Generate Image**

Generate tower preview images based on tower point cloud and "Has Been Set" part point.

Tower Name:	2	
Part Point:	: Tower End -	🔽 Select All
Tower Range:	20.00m	;
Point Size:	1	

- Tower Name: Select the current tower name.
- Part Point: Check the part points that need to generate image information.
- Select All: Check or uncheck all part points.
- Tower Range(m, default value is "20.0"): Set the extraction point cloud range for the current tower. By adjusting the range, fully display the tower and part points.
- Point Size(default value is "1"): Set the size of a single point in the point cloud in the image.

#### **Automatic Generation**

Automatic generation is to generate trajectory according to the inspection configuration. The drop-down menu also includes functions such as "Generate", "Generate Straightly", "Generate Sequentially", "Powerline Trajectory", "Distribution Network Trajectory", "Generate Channel Trajectory", "Generate Point Cloud Data Collection Trajectory", "Generate Tower Trajectory(Surround Method)", etc.

Au Ger	tomatic herated -	From Model	A Safety	Kelit → Add	Simulati Batch +
3	Generat	e			
20	Generat	e Straight	tly		
20	Generat	e Sequen	tially		
3	Powerlin	e Traject	ory		
8	Distribut	tion Netw	ork Traje	ctory	•
3	Generat	e Channel	Trajecto	ry	
3	Generat	e Point Cl	oud Data	Collection Trajecto	ory
3	Generat	e Tower T	rajectory	(Surround Method	l)

## **Automatic Generated**

Automatically generate refined inspection trajectory for towers based on inspection configuration. After clicking the button, set the camera type and waypoint speed, and click "Apply" to automatically generate the trajectory.



- Camera Type: Select camera type for taking photos. Add a new camera type in the camera configuration.
- Waypoint Speed(m, default value is "3.0"): Set waypoint speed.

#### Generate

Automatically generated based on inspection configuration and shortest path principle.

18	
10.00m	
10.00m	
2.50m	
Left	-
Phantom 4 RTK(4:3)	
3.00m/s	;
May Points	
gh Tower	
	18 10.00m 10.00m 2.50m Left Phantom 4 RTK(4:3) 3.00m/s Vay Points gh Tower

- Tower Index to Generate: The tower index needs to generate the trajectory.
- Camera Distance(m, default value is "10"): The shooting distance from the waypoint to the part point.
- Height Above Tower(m, default value is "10"): Height above tower.
- Obstacle Avoid Distance(m, default value is "2.5"): Distance for obstacle avoidance detection.
- Start Side(default value is "Left"): Waypoint shooting starting side.
- Camera Type: Select camera type for taking photos. Add a new camera type in the camera configuration.
- Waypoint Speed(m/s, default value is "3.0"): Set waypoint speed.
- Need Enter and Leave Way Points(Checked by default): Add two auxiliary points for exiting the tower and entering the tower.
- Need Way Points Through Tower(Checked by default): Add auxiliary points for passing the tower.

#### **Generate Straightly**

Generate flight trajectories directly by connecting parts points in order. There may be a possibility of the

trajectory passing through the tower, and auxiliary waypoints need to be manually added.

Tower Index to Generate:	1		*
Camera Distance:	2.00m		\$
Height Above Tower:	10.00m		\$
Obstacle Avoid Distance:	2.50m		\$
Start Side:	Left		*
Camera Type:	Phantom 4 RTK(4:3)		*
Waypoint Speed:	3.00m/s		\$
🗹 Need Enter and Leave N	ay Points		
🗹 Need Way Points Throug	h Tower		
		(nn] m	Cancol

- Tower Index to Generate: The tower index needs to generate the trajectory.
- Camera Distance(m, default value is "10"): The shooting distance from the waypoint to the part point.
- Height Above Tower(m, default value is "10"): Height above tower.
- Obstacle Avoid Distance(m, default value is "2.5"): Distance for obstacle avoidance detection.
- Start Side(default is "Left"): Waypoint shooting starting side.
- Camera Type: Select camera type for taking photos. Add a new camera type in the camera configuration.
- Waypoint Speed(m/s, default value is "3.0"): Set waypoint speed.
- Need Enter and Leave Way Points(Checked by default): Add two auxiliary points for exiting the tower and entering the tower.
- Need Way Points Through Tower(Checked by default): Add auxiliary points for passing the tower.

#### **Generate Sequentially**

Automatically generate trajectory based on inspection configuration and part point order.

Tower Index to Generate:	1		*
Camera Distance:	2.00m		\$
Height Above Tower:	10.00m		÷
Obstacle Avoid Distance:	2.50m		\$
Start Side:	Left		*
Camera Type:	Phantom 4 RTK(4:3)		*
Waypoint Speed:	3.00m/s		\$
☑ Need Enter and Leave ₩ ☑ Need Way Points Throug	ay Points h Tower		
		Apply	Cancel

- Tower Index to Generate: The tower index needs to generate the trajectory.
- Camera Distance(m, default value is "10"): The shooting distance from the waypoint to the part point.
- Height Above Tower(m, default value is "10"): Height above tower.
- Obstacle Avoid Distance(m, default value is "2.5"): Distance for obstacle avoidance detection.
- Start Side(default is "Left"): Waypoint shooting starting side.
- Camera Type: Select camera type for taking photos. Add a new camera type in the camera configuration.

- Waypoint Speed(m/s, default value is "3.0"): Set waypoint speed.
- Need Enter and Leave Way Points(Checked by default): Add two auxiliary points for exiting the tower and entering the tower.
- Need Way Points Through Tower(Checked by default): Add auxiliary points for passing the tower.

## **Batch Power Line Trajectory Generating**

Batch generation of power line inspection trajectory(Add point cloud data or vector data to generate trajectory in batches).

D:/work/workfile/data/test/data/19-20).LiData D:/work/workfile/data/test/data/18-19(18_19).LiData D:/work/workfile/data/test/data/18-19(18_19).LiData Data Type Eased on Foint Cloud				
D:/work/workfile/date/test/data/18-19(18_19).LiData	D:/work/workfile/o	data/test/data/19-20(19_20).LiData		1.0
Data Type Data Type Default Pitoh Angle: Default Pitoh Angle: Default Pitoh Angle: Default Pitoh Angle: Default Pitoh Angle: Default Pitoh Angle: Default Pitoh Angle: Default Default Pitoh Angle: Default Pitoh Angle: Default Default Pitoh Angle: Default D	D:/work/workfile/	data/test/data/18-19(18_19).LiData		
Jata Type            P Assed on Point Cloud             P Assed on Point Cloud          Parameters          Camera Type:         Phantom 4 RTE(4:3)         Weylap Batio:         0.10         2         Safe Distance:         4.00m         2         Paypoint Interval:         5.19m         2         Parameters         Paypoint Speed:         3.00m/s         2         Enter And Leave Vay Points         Hfset Distance:         3.00m				6
ata Type         Based on Foint Cloud       Based on Vector Data         arumeters         amera Type:       Phantom 4 RTE(4:3)         verlap Ratio:       0.10         100       1         Pitch Angle:       -45.0°         Compensation Distance:       0.00n         aypoint Interval:       5.19m         3.00m/s       1         Proverline Segment Distance:       4.00n         Inter And Leave Vay Points       Feight Above Tower:         ffset Distance:       3.00m				
ata Type				-
ata Tope b Fased on Point Cloud Based on Vector Data ar ameters amera Type: Phantom 4 RTE(4:3) • Weypoint Direction: Default • rerlap Katio: 0.10 • Compensation Direction: Default • Fitch Angle: • • • • • • • • • • • • • • • • • • •				
ata Type b Sased on Point Cloud Based on Vector Data ar ameters amera Type: Phantom 4 RTE(4:3) • Weypoint Direction: Default • rerlap Ratio: 0.10 • Pitch Angle: •45.0° • afe Distance: 4.00m • Compensation Distance: 0.00m • sypoint Interval: 5.19m • sypoint Speed: 3.00m/s • Enter And Leave Vay Peints :fset Distance: 3.00n • Enter And Leave Vay Peints				
ata Type				
P Fased on Foint Cloud       3 ased on Vector Data         ar aneters         amera Type:       Phantom 4 RTE(4:3)         verlap Fatio:       0.10         0.10       0         afe Distance:       4.00m         aypoint Interval:       5.19m         3.00m/s       0         Enter And Lawe Vay Peints       Fieight Above Tower:         Fiset Distance:       3.00m	ata Type —			
ar ameters amera Type: Phantom 4 RTI(4:3) * Weypoint Direction: Defailt * verlap Ratio: 0.10 ‡ Pitch Angle: -45.0° ± afe Distance: 4.00m ‡ Compensation Distance: 0.00m ± aypoint Interval: 5.19m ± aypoint Speed: 3.00m/s ± Pitch Angle: -45.0° ± Compensation Distance: 0.00m ± Fowerline Segment Distance: 4.00m ± Pitch Angle: -45.0° ± Compensation Distance: 0.00m ± Fowerline Segment Distance: 10.00m ± Fister Distance: 3.00m ±	Jased on Point (	loud 🔿 Based on	Vector Data	
amera Type:       Phantom 4 RTF(4:3)       •       Weypoint Direction:       Default         werlap Ratio:       0.10       1       Fitch Angle:       45.0°       45				
werlap Eatio:       0.10       1         afe Distance:       4.00m       1         aypoint Interval:       5.19m       1         awroint Speed:       3.00m/s       1         Pinter And Leave Vay Points	arameters			
afe Distance: 4.00m    Compensation Distance: 0.00m  aypoint Interval: 5.19m  aypoint Speed: 3.00m/s  Enter And Leave Vay Points  Effect Distance: 3.00n  Enter And Leave Vay	'arameters 'amera Type:	Phantom 4 RTE(4:3) -	Wsypoint Direction:	Default
aypoint Interval: 5.19m C Powerline Segment Distance: 4.00m Augustin Speed: 3.00m/s C Segment Distance: 4.00m C Segment Di	'arameters amera Type: verlap Ratio:	Phantom 4 RTE(4:3) -	Weypeint Direction: Fitch Angle:	Default -45.0°
avroint Speed: 3.00m/s C Penter And Leave Vay Points Efset Distance: 3.00n C Keight Above Tower: 10.00m	'arameters 'amera Type: Werlap Ratio: 'afe Distance:	Phantom 4 RTE(4.3) - 0.10 - 4.00m -	Weypoint Direction: Fitch Angle: Compensation Distance:	Default -45.0° 0.00n
Effet Distance: 3.00n I Keight Above Tower: 10.00m	'arameters 'amera Type: Werlap Ratio: 'afe Distance: 'aypoint Interval:	Phantom 4 RTE(4.3)         -           D. 10         2           4.00m         2           5.19m         2	Weypoint Direction: Fitch Angle: Compensation Distance: Fowerline Segment Distance:	Defeult -45.0° 0.00n 4.00n
ffset Distance: 3.00m C Beight Above Tower: 10.00m	'arametera amera Type: verlap Batio: afe Distance: aypoint Interval: aypoint Speed:	Phantom 4 RTE(4:3)         -           D. 10         2           4. 00m         2           5. 19m         2           3. 00m/s         2	Weypoint Direction: Fitch Angle: Compensation Distance: Fowerline Segment Distance:	Default -45.0° 0.00n 4.00n
Reserved Control Reserved	'ar ameters 'amera Type: Werlap Ratio: 'aypoint Interval: 'aypoint Speed: '] Enter And Leave	Phantom 4 RTE(4:3)	Weypoint Direction: Pitch Angle: Compensation Distance: Fowerline Segment Distance:	Default -45.0° 0.00n 4.00n
	arameters amera Type: verlap Eatio: afe Distance: aypoint Interval: aypoint Speed: Tenter And Leave ffset Distance: 3	Phantom 4 RTE(4:3)     -       0.10     0       4.00m     0       5.19m     0       3.00m/s     0       Yay Points     0	Weypoint Direction: Pitch Angle: Compensation Distance: Fowerline Segment Distance: Keight Above Tower: 10.00m	Default -45.0° 0.00n 4.00n



- Data Type:
  - **Based on Point Cloud**: Generating trajectory based on point cloud.
  - Based on Vector Data: Generating trajectory based on vector data.
- Parameters:
  - **Camera Type**: Select camera type for taking photos. Add a new camera type in the camera configuration.
  - **Waypoint Direction**: Set the position of the waypoint relative to the power line. When selecting "Default", the waypoint of the left phase is on the left side of power line, and the waypoint of the right phase is on the right side of power line. When selecting "Left Side" or "Right Side", the waypoint is located on the left and right sides of the power line.
  - Overlap Ratio(default value is "0.1"): Set the overlap ratio of adjacent photos.
  - Pitch Angle(-90~0)(°, default value is "-45.0"): Set the depression angle of the shooting waypoint.
  - Safe Distance(m, default value is "4.0"): Set safe distance and power line obstacle avoidance detection.
  - **Compensation Distance(m, default value is "0.0")**: Set compensation distance. The vector line is located at the bottom of the power line point data. Used to compensate for the distance between vector lines and point clouds.Only used for vector data.
  - **Waypoint Interval(m, default value is "0.5")**: Set the distance between the waypoints and perform the safety inspection between the waypoints. Automatically calculate the Waypoint interval when setting the overlap ratio.
  - **Powerline Segment Distance(m, default value is "4.0")**: Set the clustering threshold and cluster the point cloud points.Only used for point cloud data.
  - Waypoint Speed(m/s, default value is "3.0"): Set waypoint speed.
- Enter And Leave Way Points: Add two auxiliary points for entering the tower and leaving the tower.
  - Offset Distance(m, default value is "3.0"): Set horizontal offset distance.
  - Height Above Tower(m, default value is "10.0"): Set height above tower.
- **Output Path**: Set the output path of the trajectory.
- Default Value: Click "Default Value" to restore the initial parameters.

• Run: Click "Run" to start the calculation.

## Merge/Split Trajectory Files

Merge and split shield line and power line trajectory.

Trajectory Files Log		
		- 1
		-
		1
		39
Options		
🖲 Merge	🔘 Split	
Marga Paramatars		
Renieur Warssiste Caust: 200	0 * II II. J.: C	
maximum waypoints count. 200 17 Worgo By Sogtion	u + merge mode. Sequential m	erge *
werge by section		
✓ Merged By File Count  2	Copy Trajectory Fil	e
tput Path: D:/work/workfile	/data/test/PowerLineInspection/	4.4(4)
	Start	Exit
	Start	Exit
Merge/Split Trajectory Fil	Start	Exit
Merge/Split Trajectory Fil Trajectory Files Log	Start	Exit
Merge/Split Trajectory Fil Trajectory Files Log	Start [	Exit
Merge/Split Trajectory Fil Trajectory Files Log	Start	Exit
Merge/Split Trajectory Fil Trajectory Files Log	Les	Exit
Merge/Split Trajectory Fil Trajectory Files Log	Start	Exit
Merge/Split Trajectory Fil Trajectory Files Log	les	Exit
Merge/Split Trajectory Fil Trajectory Files Log	Les	Exit
Merge/Split Trajectory Fil Trajectory Files Log	Les	Exit
Merge/Split Trajectory Fil Trajectory Files <u>Log</u>	Les	Exit
Merge/Split Trajectory Fil Trajectory Files Log	Les	Exit
Merge/Split Trajectory Fil Trajectory Files Log	Les	Exit
Merge/Split Trajectory Fil Trajectory Files Log	Les	Exit
Merge/Split Trajectory Fil Trajectory Files Log	Les	Exit
Merge/Split Trajectory Fil Trajectory Files Log	Les	
Merge/Split Trajectory Fil Trajectory Files Log Options Merge	Les • Split	Exit
Merge/Split Trajectory Fil Trajectory Files Log Options Merge Split Parameters	les © Split	Exit
Merge/Split Trajectory Fil Trajectory Files Log Detions Merge Split Parameters Split Count: 2	Start [	Exit
Merge/Split Trajectory Fil Trajectory Files Log Options Merge Split Parameters Split Count: 2	Start	Exit
Merge/Split Trajectory Fil Trajectory Files Log Options Options Split Parameters Split Count: 2 trput Path: D:/work/workfile	Start	

- Option: Check the "Merge" and "Split" options.
- Merge Parameters: Customize the maximum count of waypoints based on the maximum waypoints supported by the UAV. The merge mode supports two types: sequential merge and interval reverse merge. The merging function by section supports merging by the number of files. For example, if set to 2, two trajectories can be merged, and the waypoint count of merged trajectory cannot exceed the maximum count. If it exceeds, the merge will be abandoned. If "Copy Trajectory File" is checked, copy and output trajectory that do not meet the merging requirements.
- Split Parameters: Default 2, customizable.
- **Output Path**: Specify the path to save the file results.

## **Generate Distribution Network Trajectory**

Generate inspection trajectory suitable for distribution networks (Distribution network trajectory mode are divided into mode 1, mode 2 and mode 3 and mode 4. The four different modes generate distribution network trajectory).

#### Mode 1

Generate 3 photo waypoints for each tower based on the tower marking points.

Mode: Mode 1		*
Parameter:		
Start Tower Index:	1	\$
End Tower Index:	10	÷
Camera Type:	Phantom 4 RTK(4:3	) -
Focal Length Multiple:	1.0	\$
Camera Distance:	5.00m	÷
Waypoint Speed:	3.00m/s	÷
ajectory File: Traject	ory3.json	



- Mode(default is "Mode 1"): Three photos of a single tower (from the left, right, and top of the tower).
- Start Tower Index: Set the starting tower index.
- End Tower Index: Set end tower index.
- Camera Type: Select camera type for taking photos. Add a new camera type in the camera configuration.
- Focal Length Multiple: Set camera focal length.
- Waypoint Speed(m/s, default value is "3.0"): Set waypoint speed.
- Camera Distance(m, default value is "8.0"): The shooting distance from the waypoint to the part point.

#### Mode 2

Take 13 photos of each tower on the trajectory, including the tower marking point, tower base, and major side channel.

Mode: Mode 2		
Parameter:		
Start Tower Index:	1	÷
End Tower Index:	10	÷
Camera Type:	Phantom 4 RTK(4:3)	*
Focal Length Multiple:	1.0	*
Camera Distance:	5.00m	÷
Safe Distance:	3.00m	÷
Waypoint Speed:	3.00m/s	÷
ajectory File: Traject	ory3. json	



- **Mode 2**: Thirteen photos of a single tower. (Eight photos taken from the four directions of the tower at two heights, two photos taken from the tower base, and three photos taken from the major side.)
- Safe Distance(m, default value is "3.0"): Set safe distance and conduct obstacle avoidance detection.

Note: To avoid collisions with towers during UAV return, the automatically generated trajectory needs to check if the starting point is higher than the tower. After generating the trajectory, it is recommended to analyze the safety.

#### Mode 3

Take 6 photos of each tower on the trajectory, including tower marking point, tower body, and major and minor side channel.

Mode: Mode 3		•
Parameter:		
Start Tower Index:	1	¢
End Tower Index:	10	\$
Camera Type:	Phantom 4 RTK	(4:3) +
Focal Length Multiple:	1.0	:
Camera Distance:	5.00m	\$
Waypoint Speed:	3.00m/s	\$
Vertical Compensation Distance:	-0.50m	\$
🗹 Add Enter And Leave Waypoints	5.00m	¢
aiectory File: VineInspection/Tra	iectory ison	



- **Mode 3**: Six photos of a single tower. (overall view of the tower, minor side, major side, left and right of the tower head, and top view of the tower head.)
- Vertical Compensation Distance(m, default value is "-0.5"): Adjust the height of the target points for photography on the left and right sides of the tower head. Positive value, the target point moves up. Negative value, the target point moves down.
- Enter And Leave Waypoints(check by default): Add two auxiliary points for entering and leaving the tower.

#### Mode 4

Take 8 photos of each tower on the trajectory, including tower head, cross arm, insulator, major and minor side channel.

Mode: Mode 4		*
Parameter:		
Start Tower Index:	1	\$
End Tower Index:	10	\$
Camera Type:	Phantom 4 RTK(4:3)	) -
Focal Length Multiple:	1.0	÷
Camera Distance:	5.00m	÷
Waypoint Speed:	3.00m/s	÷
Vertical Compensation Distance:	-0.50m	\$
Insulator Shooting Angle:	-30.00°	\$
Cross Arm Shooting Angle:	-45.00°	\$
🗹 Add Enter And Leave Waypoints	5.00m	÷
ajectory File: FineInspection/Tra	ajectory.json	+ * *



- **Mode 4**: Eight photos of a single tower. (overall view of the tower, cross arm, insulator, top view of the tower head, minor side and major side.)
- Insulator Shooting Angle(°, default value is "-30.0"): Set the shooting angle of the insulator.
- Cross Arm Shooting Angle(°, default value is "-45.0"): Set the shooting angle of the cross arm.

#### **Generate Distribution Network Trajectory Model**

Generate distribution network trajectory model based on the distribution network trajectory.

<b>Tower mark should be at</b> ☑ Select Waypoint Index —	t the top	center of	tower.
Minor Side Channel: 1 Major Side Channel: 3			•
ingle Tower Trajectory File	: tion/Traje	ectory4.json	
frajectory Model:	n/Trajecto	oryModel.dtm	
		Generate	Cancel

- Minor Side Channel: Select the waypoint number for minor side channel of the trajectory, and if not available, do not select it.
- Major Side Channel: Select the waypoint number for major side channel of the trajectory, and if not available, do not select it.
- Single Tower Trajectory File: Choose a single tower trajectory.
- Trajectory Model: Set the trajectory model path. The model file format is . dtm.

#### **Generate Distribution Network Trajectory From Model**

Batch generate distribution network trajectory files from models.

Parameters —		
Start Tower Index	:: 0	\$
End Tower Index:	4	\$
🗌 Generate Singl	e Tower Trajectory	
Trajectory Model:	neInspection/TrajectoryModel.dtm	4.454
Trajectory Model:   Output Path:	neInspection/TrajectoryModel.dtm	

- Start Tower Index: Set the starting tower index.
- End Tower Index: Set the end tower index.
- Generate Single Tower Trajectory: If checked, generate corresponding single tower trajectory based on the starting and ending towers; If unchecked, generate a single trajectory.
- Trajectory Model: Select trajectory model file.
- **Trajectory File**: If "Generate Single Tower Trajectory" is checked, set distribution network trajectory folder; If "Generate Single Tower Trajectory" is unchecked, set distribution network trajectory path.

### Generate Distribution Network Tower Trajectory(Surround Method)

Automatically generate a circular trajectory with the tower marker point as the center. Take multidirectional and multi height photos of the tower.

Cower Name:	4				
Camera Type:	Phantom 4 RT	K(4:3)		*	
ocal Length Multiple:	1.0 3.00m/s Left Side			¢	
/aypoint Speed:				;	
Start Side:					
Add Enter And Leave Waypoints	5.00m				
Delete Dangerous Waypoints	2.00m			÷	
- Upper Layer		Lower Layer			
Surrounding Radius:	5.00m 🗘	Surrounding Radius:	6.00m	*	
Camera Angle:	-30.00° 🗘	Camera Angle:	-15.00°	*	
Vertical Compensation Distance:	-0.50m 🗘	Vertical Compensation Distance:	-5.00m	*	
Photo Waypoints Number:	30 ‡	Photo Waypoints Number:	30	* *	
				_	



- Tower Name: Select the current tower name.
- Camera Type: Select camera type for taking photos. Add a new camera type in the camera configuration.
- Focal Length Multiple: Set camera focal length.
- Waypoint Speed(m/s, default value is "3.0"): Set waypoint speed.
- Start Side(default value is "Left Side"): Waypoint shooting starting side.
- Add Enter And Leave Waypoints: Add two auxiliary points for entering and leaving the tower.
- **Delete Dangerous Waypoints**: Delete dangerous waypoints based on obstacle avoidance distance and point cloud data.
- Upper Layer
  - Surround Radius(m, default value is "5.0"): Horizontal distance from waypoint to tower marking point.
  - Camera Angle(°, default value is "-30.0"): Pitch angle from waypoint to target point.
  - Vertical Compensation Distance(m, default value is "-0.5"): Adjust the height of the target points for photography on the tower head. Positive value, the target point moves up. Negative value, the target point moves down.
  - **Photo Waypoint Number(default value is "30")**: Generate a circular trajectory uniformly based on the "Photo Waypoint Number" in the current layer.
- Lower Layer: If checked, generate a two-layer circular trajectory.
  - Surround Radius(m, default value is "6.0"): Horizontal distance from waypoint to tower marking point.
  - Camera Angle(°, default value is "--15.0"): Pitch angle from waypoint to target point.
  - Vertical Compensation Distance(m, default value is "-7.0"): Adjust the height of the target points for photography on the tower head. Positive value, the target point moves up. Negative value, the target point moves down.
  - **Photo Waypoint Number(default value is "30")**: Generate a circular trajectory uniformly based on the "Photo Waypoint Number" in the current layer.
- Default Value: Click "Default Value" to restore the initial parameters.

## **Generate Channel Trajectory**

Generate the channel inspection trajectory above the line.

Generate the channel inspection trajectory above the line.

Camera Type:	Phantom 4 RTK(4:3)	e
feight Above Tower:	10.00m	
Camera Angle:	-45.00°	
Yaypoint Speed:	3.00m/s	
Method By Tower		
🔵 By Fixed Spacin	g 50.00m	÷
Start Tower Name:	1	*
End Tower Name:	3	+
rajectory File:	Apply	Cancel
Trajectory File:	Apply	Cancel

- Camera Type: Select camera type for taking photos. Add a new camera type in the camera configuration.
- Height Above Tower(m, default value is "10.0"): Distance of passage point height above tower.
- Camera Angle(°, default value is "-45.0"): Set the depression angle of the shooting waypoint.
- Waypoint Speed(m/s, default value is "3.0"): Set waypoint speed.
- By Tower: Whether to generate the channel trajectory according to the tower information.
- By Fixed Spacing(m, default value is "50.0"): Whether to generate the channel trajectory according to the fixed spacing? According to the fixed spacing, input the parameter distance at every interval to generate a trajectory.
- Start Tower Name: Set the name of the starting tower and generate a trajectory from the tower.
- End Tower Name: Set the name of the end tower and generate a trajectory to the tower.

## **Generate Point Cloud Data Collection Trajectory**

Base on point cloud data, generate unmanned aerial vehicle (UAV) trajectory for airborne LiDAR

equipment during field point cloud data collection .

Generate Point Cloud Date	a Collection Trajectory	×
Camera Type:	Phantom 4 RTK(4:3)	-
Reference Point Class:	Ground	-
Channel Width:	60.00m	\$
Relative Height of Waypoint:	50.00m	\$
Start Tower Index:	1	\$
End Tower Index:	3	\$
Waypoint Speed:	3.00m/s	\$
🗸 Single Side Trajectory	Left Side	
🔽 Insert Middle Waypoint	Start Point At The End Tower	
🗌 Remove Photo Information		
Trajectory File:		
	OK Canc	.1
		Jar V
	, <u>,</u>	
Class(es)		
27-impulator		
20-Shield Wire		
t9-Scissors Grossing Down	a man	
17-Structure		
16-Gonductor		
14Late		
e-ballding		

- Camera Type: Select camera type for taking photos. Add a new camera type in the camera configuration.
- Reference Point Class: Optional shield line, conductor, and ground.
- Channel width(m, default value is "60.0"): Set point cloud channel width.
- Relative Height of Waypoint(m, default value is "50.0"): The height of the waypoint relative to the reference point.
- Start Tower Index: Set the starting tower index, and generate the trajectory from the tower.
- End Tower Index: Set the the end tower index, and generate the trajectory to the tower.
- Waypoint Speed(m/s, default value is "3.0"): Set waypoint speed.
- **Single Side Trajectory**: If checked, you can choose the left and right sides; If unchecked, for both side trajectory.
- Insert Middle Waypoint: Add a waypoint in the middle of the tower.
- Start Point At The End Point: If checked, the starting and ending waypoints are both near the ending tower.
- Remove Photo Information: If checked, remove all camera information.

## Generate Tower Trajectory(Surround Method)

Lateral Automatically generate a panoramic shooting trajectory for the tower. The waypoints are located on the

• front, back, left, and right sides of the tower, and the number of waypoints on each side is determined by the vertical overlap rate. Each waypoint can take multiple photos, and the number of photos is

determined by the horizontal overlap rate and camera type.

	irround Method)	
Tower Name:	23	
Start Side:	Left Side	-
Camera Type:	Phantom 4 RTK(4:3)	
Focal Length Multiple:	1.0	:
Horizontal Overlap Ratio:	0.30	÷
Vertical Overlap Ratio:	0.30	4
Camera Distance:	4.00m	
Obstacle Avoid Distance:	2.50m	÷
Minimum Height To Tower Bottom:	3.00m	
Waypoint Speed:	3.00m/s	÷
Trajectory File: D:/data/23_Tow	erTrajectory.json	]
n c 1, y 1		
		4
		1
		4
		4
ss(ce) 28-Drainago Thread		
ss (cs) 28-Drai nage Thread 27-1 nsulator		
28-Orainago Thread 17-Insulator 29-Shield Wire		
os (có) 28-Drainago Thread 27-Insulator 29-Shield Wire 29-Shield Wire		
ss(ce) 28-Drainage Thread 27-Insulator 20-Shield Mire 17-Structure		

- Tower Name: Select the current tower name.
- Start Side(default value is "Left Side"): Waypoint shooting starting side.
- **Camera Type**: Select camera type for taking photos. Add a new camera type in the camera configuration.
- Focal Length Multiple: Set camera focal length.
- Horizontal Overlap Ratio(default value is "0.3"): Overlap rate of photos on the same side of the tower. It determines the number of photos on the current side.
- Vertical Overlap Ratio(default value is "0.3"): The overlap rate of waypoints on the same side of the tower. It determines the number of waypoints on the current side.
- Camera Distance(m, default value is "4.0"): The closest distance from the waypoint to the tower point cloud box.
- Obstacle Avoid Distance(m, default value is "2.5"): Distance for obstacle avoidance detection.
- Minimum Height To Tower Bottom(m, default value is "3.0"): Minimum height from waypoint to ground

point.

- Waypoint Speed(m/s, default value is "3.0"): Set waypoint speed.
- Default Value: Click "Default Value" to restore the initial parameters.

#### **From Model**

The "Generate Trajectory By Model" function can use existing trajectory model to batch generate trajectory. Trajectory model can be obtained through the "Generate Trajectory Model" function in the drop-down menu. When there are a large number of duplicate towers on the same line, it can greatly reduce the workload of users.

#### **Trajectory Model**

Select the planned trajectory, click "Generate Trajectory Model" from the drop-down menu, and click Generate. The file name will be named according to the tower types, the file format is .tm format. The default output path is the "Fine Inspection" folder.



#### Generate Trajectory By Mode

After the trajectory model is generated, it is necessary to mark the parts of the tower. Mark all the part points according to the inspection configuration of the same tower type, and ensure that the number and location of the part points are consistent with the trajectory model.

Tongion Toway (D:		
Tension Tower (M)	ight Jump)(49)	
		-

## Safety

The "Safety" function can check the obstacle avoidance distance between the trajectory and point cloud data, as well as the safe distance between waypoints. If distance is greater than "Obstacle Avoidance Distance", the list will be displayed in red, and the trajectory in the point cloud will also be displayed in red. Double-click the list item to locate the corresponding trajectory, adjust it by editing the trajectory or adding auxiliary waypoints, and then refresh.

	Way Point ID	istance(m) *	ontal Distan	ical Distanc	^
1	6-7	0.650	0.632	0.150	
2	7	0.650	0.632	0.150	
3	30-31	1.171	1.158	0.173	
4	22-23	1.248	0.241	1.225	
5	23	1.248	0.241	1.225	
6	49-50	1.484	1.484	0.009	
7	48-49	1.512	1.512	0.004	
8	46-47	2.016	1.673	1.125	
9	47	2.016	1.673	1.125	
10	3-4	2.162	0.415	2.121	
11	<mark>4</mark> -5	2.268	<mark>2.26</mark> 7	0.062	
12	8-9	2.340	2.320	0.303	
13	33-34	2.751	2.562	1.003	
14	26-27	2.849	0.603	2.785	
15	25-26	3.041	0.493	3.001	
16	16-17	3.066	1.243	2.803	
17	32-33	3.077	1.167	2.847	
		0.000	4.450		Y

inimum Interval:	[⊉. 00m		
Point ID	Distance(m)	rizontal Distance	ertical Distance
rajectory Bat	ween Waymoints		

- **Obstacle Avoidance Distance**: The minimum distance between the trajectory and the point cloud data.
- Only Check Waypoints: If checked, only analyze the safety of the waypoint.
- Export dangerous results in the safety table: Click if to export dangerous results.
- Fresh by Force: Perform a forced refresh after adjusting the waypoints.
- Fresh: Refresh after adjusting the waypoint.

# **Edit Waypoint**

## Summary

Waypoint functions mainly include modifying waypoints, adding waypoints and deleting waypoints. The operation is mainly performed after the trajectory is generated.

## Usage

Use the "Fine inspection" module, after generating the trajectory, Click *Waypoint > Edit*, and the mouse turns into a cross state. Click on any waypoint at this time, and a dialog box for adjusting and editing waypoints pops up. You can edit the position of navigation point, the angle of taking photos, the number of taking photos, etc.





## Settings

- **Previous Waypoint/Next Waypoint**: Quickly switch to the previous waypoint and the next waypoint for editing.
- **Camera List**: Switch the current camera and display the corresponding vertebrae. Cameras can be added and removed using the add/subtract button on the side. After adding a camera, the current camera will be set as the newly added camera. Other tools can be used to modify the camera.
- Add Camera: Adding camera is divided into selecting camera types and selecting part point. Multiple part point can be selected to support shooting multiple part point at one waypoint.

amera Type:	Phantom 4 RTK(4:3)	
art Point Name:	Previous Waypoint	- 🗹 Multi-Selec
Selected Part H	oint List	
		÷
		(1000)
		1
-		

- Person Perspective: Quickly locate the first-person view of the waypoint.
- Reset: After modifying the waypoint parameters, clicking the reset can restore the original parameters.
- **Overlay Display**: When multiple photos are taken at a waypoint, check the option to overlay and display the preview range.

- Adjust Parameters: Mainly adjust the parameter of waypoints.
  - **Drag Waypoint**: Holding down the left mouse button, drag a point in the point cloud view to adjust its position.
  - Safety Analysis: If checked, verify security
  - Allow Head Up: If checked, set the maximum angle for the camera to look up. Do not exceed the maximum angle.
  - **Pitch/Yaw**: Adjust the pitch angle and yaw angle by manually entering, clicking the up and down arrows, and dragging the slider.
  - **Distance**: The distance from the waypoint to be photographed is the value from the waypoint to the component point, and the distance from the auxiliary waypoint is the value from the waypoint to the marked tower point.
  - Focal Length Multiple: Set the focal length multiple.
  - Waypoint Speed: Set the waypoint speed.
  - Set Rotation Center: To re-select the rotation center of the navigation point, press Ctrl + left to select any point on the point cloud. If you want to specify the component point or the front and back navigation points, you can also use the select component point button.
- Auxiliary Grid: If check the "Drag Waypoint", this will display. Not selected by default, the auxiliary grid is displayed when selected.
- Grid Size(default value is "5.00m"): Side length of grid.
- Side Grid Count(default value is "10"): Number of side grids.
- Horizontal Grid: Display a grid that passes through the tower point and is parallel to the XY plane.
- Line Direction Grid: Display the grid passing through the tower point and parallel to the plane along the line.
- Vertical Line Direction Grid: Display the grid passing through the tower point and parallel to the horizontal line direction plane.
- **Show Auxiliary Line**: Selected by default. If selected, navigational guides are displayed. If unchecked, navigational guides are hidden.

# Tools

## Usage

Tools mainly include simulation and batch. Simulation includes flight simulation and time; batch includes statistics, batch safety checking, batch attribute modification, batch save as trajectory, batch modify part name, batch modify trajectory tower information, export to CSV format, export to DJI pilot.

	Simulat	ion 🔹	
	Batch		
	Тоо	ls	
Simul	ation 🔹	🦻 Display	
FI C Ti	ight Simul ime	ation	
Тс	ols	Setting	
Simulation + Batch +	🤏 Display 📺 Shortcut	Defect	Oper
http://www.statistics			
Batch Saf	ety Checking	5	
Batch Attr	ibute Modificat	ion	
Batch Sav	e As Trajectory		
Batch Mo	dity Part Name		
Xe Batch Mo	dity Irajectory	ower Informatio	on
Export to	CSV Format		
Export to	DJI Pilot		

## **Flight Simulation**

After loading the flight route file, you can simulate the flight by selecting either the first-person or third-person perspective in the flight simulation.

First Person Parameter	
🖲 First Person	
Custom Flight Speed 3.00m	/s ‡
Thind Develop Develop Area	
Third Person Parameter O Third Person Acceleration	Deceleration
Third Person Parameter Third Person Acceleration Front	Deceleration Back
Third Person Parameter Third Person Acceleration Front Left	Deceleration Back Right

## Time

Flight time calculation needs to load the route file, set the flighting speed and waypoint dwell time, and get the total flight time of the UAV after executing the route.

Ustom Flight Speed:	3.00m/s	*
Dwell Time:	5.00s/point	\$
Trajectory File:	+	
	1.1.1	

## Statistics

Statistics can export the parameter statistics table of the route, click "Run" to generate a csv format file. The file is saved in the project folder. The statistical table mainly counts the number of photos of the route, the number of auxiliary points, the number of manually added points and the number of waypoints, as shown in the figure below.

1	Trajectory Fil	les					
	D:/work/worl	kfile/data/tes	t/FineInspec	tion/Z18.json	tatistics os	v	
							1111
						Run	Cancel
	A	В	С	D	E	F	Cancel
#	A	B File Name	C Photo Number	D Auxiliary Way Points Number	E Manually Added Points	Run F Way Points Number	Cancel G Trajector y Length(m)
2	A Index 1	B File Name N1#	C Photo Number 38	D Auxiliary Way Points Number 5	E Manually Added Points 0	Run F Way Points Number 43	Cancel G Trajector y Length(m) 159.85
	A Index 1 2	B File Name N1# N2#	C Photo Number 38 38	D Auxiliary Way Points Number 5 5	E Manually Added Points 0 0	Run F Way Points Number 43 43	Cancel G Trajector y Length(m) 159.85 232.18

## **Batch Safety Checking**

Batch Safety checking is used to check whether the route documents meet the safety requirements.

Trajectory File Directory:	D:/work/workfile/d	•
Obstacle Avoidance Distance:	2.50m	
Minimum Interval Between Waypoin	ts: 1.00m	
Output CSV Path:		100

- Trajectory File Directory: Default fine inspection folder.
- Obstacle Avoidance Distance: The default is the same as the inspection configuration.
- Minimum Interval Between Waypoints: The minimum safe distance between waypoints is 1.00m by default.
- **Output CSV Path**: Default fine inspection folder.

After running, a TrajectoryBatchChecking.csv file will be generated, mainly checking for 5 common issues, where 1 indicates a problem and 0 indicates normal. When opened, it will appear as shown in the figure below.

	А	В	C	D	E	F	G	н
٦	Index	File Name	Trajectory Safe Distance is Danger	Distance Between Waypoints is Danger	Camera Angle is Danger	Do Not Have Waypoint	Have Unphotographe d KeyPoints	Have Multiple Camera Types
2	0	N1#.json	1	1	0	0	0	0
3	1	N2#.json	1	1	0	0	0	0
4								
5								
6								
-								

- **Trajectory Safe Distance Is Danger**: Safety distance is dangerous, obstacle avoidance distance does not meet the requirements.
- **Distance Between Waypoints Is Danger**: The distance between two adjacent waypoints is dangerous and does not meet the requirements.
- Camera Angle Is Danger: Camera angle is dangerous. The pitch angle of the camera point is positive.
- Do Not Have WayPoints: There are no waypoints.
- Have Unphotographed KeyPoint: Some part points are not photographed.
- Have Multiple Camera Types: The cameras used for taking photos on the same flight route are not consistent.

## **Batch Attribute Changing**

Batch attribute changing mainly includes key point change and way point change. Only the same tower type routes can be modified in batches.

Irajectory F	les		
D:/110kv line	e data/Fineli	nspection/N1#.json	
D:/110kv line	e data/Fineli	ispection/N2#.json	
'art Point	¥aypoint		] L
Gelect Part ⊻ Modify P	Nane List; art Nane	AC Single Circuit Linear Tover	
Index	0	Original Name of Part Point	New Name of Part Point
1	Left Circui	t Bottom Phase Small Side Insulat	ottom Phase Small Side Insulator Conductor End 🔹
2	Left Circui	t Bottom Phase Small Side Insulat	it Bottom Phase Small Side Insulator Hole String 🔹
3	Left Circui	t Bottom Phase Small Side Insulat	uit Bottom Phase Small Side Insulator Tower End 🔹
4	Left Circui	t Bottom Phase Big Side Insulator	rcuit Bottom Phase Big Side Insulator Tower End 🔹
5	Left Circui	t Bottom Phase Big Side Insulator	cuit Bottom Phase Big Side Insulator Hole String 🔹
6	Left Circui	t Bottom Phase Big Side Insulator	Bottom Phase Big Side Insulator Conductor End 🔹
7	Left Circui	t Middle Phase Small Side Insulat	/iddle Phase Small Side Insulator Conductor End 🔹
8	Left Circu	t Middle Phase Small Side Insulat	uit Middle Phase Small Side Insulator Hole String 🔹
9	Left Circu	t Middle Phase Small Side Insulat	uit Middle Phase Small Side Insulator Tower End *
10	Left Circui	t Middle Phase Big Side Insulator	ircuit Middle Phase Big Side Insulator Tower End 🔹
11	Left Circui	t Middle Phase Big Side Insulator	rouit Middle Phase Big Side Insulator Hole String

rajectory Files			
D:/110kv line data/Fin	nelnspe	ction/N1#.json	-
D:/110kv line data/Fir	nelnspe	ction/N2#.json	
art Point 🛛 Waypoi	nt		
✓ Modify Waypoint			
Vaypoints to be Nor	dified:	23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43,	>>
🗹 Fitch Angle:		0.00* 2	
🔽 Yaw Angle:		[0. 00° ‡]	
🗹 Photograph Dista	ince;	3.00n \$	
🗹 Camera Count:		0 *	
🔽 Camera Type:		Phantom 4 RTK(4:3)	
Focal Length Multip	ple:	1.0 0	
🗹 Waypoint Speed:		[3.00m/s \$	
Waypoint Compens	ation-		
UAV Type:	N200		*
X Compensation:	0.4000	)	
🗌 9 Compensation:	0.500	)	:
7 Commentions	0.000		ć

- Modify Waypoint:
  - **Waypoints to be Modified**: Click the button on the right to add and select the waypoints that need to be modified. Typically, you would select all of them.
  - **Pitch Angle**: The pitch angle of the waypoint, generally a negative value.
  - Yaw Angle: The yaw angle of the waypoint.
  - Photograph Distance: The distance at which photos are taken at the waypoint.
  - Camera Count: The number of photos taken at the waypoint.
  - Camera Type: Select the type of camera to be changed, a total of 14 types.
  - **Focal Length Multiple**: For selectable zoom camera types, you can set the zoom factor, with a setting range of 0.1 to 12.0, and one decimal place to be preserved. For a fixed-focus camera type, this value cannot be set.
  - **Waypoint Speed**: Flight speed at waypoints, with a setting range of 0.01 to 99.99, and two decimal places to be preserved.
- Waypoint Compensation: Check this option when converting drone routes for the M200 and M300 series.
  - UAV Type: Customize.
  - X Compensation: Default 0.4
  - Y Compensation: Default 0.5
  - Z Compensation: Default 0.6

Tip: This function is suitable for routes with the same tower type.

## **Batch Save As Trajectory**

Batch save as routes allows for waypoints to be saved in reverse order, removing photo information, changing waypoint speed, camera type, and zoom multiplier, as shown in the figure below.

		4
0-1		
Options	everse Order 🗌 Remove Photo Information	
Options	everse Order Remove Photo Information	:
Options Save Waypoints In R Waypoint Speed: Camera Type:	Neverse Order 3.00m/s Phantom 4 KTK(4:3)	÷
Options Save Waypoints In R Waypoint Speed: Camera Type: Focal Length Multiple:	everse Order Remove Photo Information 3.00m/s Phantom 4 RTK(4:3) 1.0	: :
Options Save Waypoints In R Waypoint Speed: Camera Type: Focal Length Multiple: utput Path: D:/work/wo	Neverse Order Remove Photo Information          3.00m/s         Phantom 4 RTK(4:3)         1.0         rkfile/data/test/FineInspection/BatohSaveAs/	: ; ;

## **Batch Modify Part Name**

Custom fields can be added, such as adding line names and voltage levels, and batch modifying component names, as shown in the following figure.

D	:/work/workfile/data/test/Fin	eInspection/Trajectory.json	
			-
			-
			1
10	Abination List	Decariation	1
1	Tower Name -	Use Corresponding Tow	+
2	Original Part Name -	Use Original Part Name	
3	Custom Field -		
			1
	ample: 1#Tower Head		
X			

**Batch Modify Trajectory Tower Information** 

If the tower information in the route file is misaligned, this tool can be used to correct and redefine the tower number and name, as shown in the following figure.

	New lower Name	4
		1
		-
otions		

- Options:
  - **Matching Mode**: If this option is selected "Matching By Tower Index", the matching will be done using the tower index recorded in the flight route file; If this option is selected "Matching By Tower Name", it will be done using the tower names recorded in the flight route file; otherwise, the 'Trajectory File' column is arranged in ascending order to the tower index recorded in the file, and the 'New Tower Index' column is arranged in ascending order, and then matched according to the order after arrangement.
  - **Use New Tower Name**: Check this option to use the new tower name as the flight route file name when saving the file; otherwise, use the original flight route file name.

#### **Export to CSV Format**

Exporting to CSV Format is to convert the route file into a CSV format table file, which can compare and quickly view the parameters of each waypoint. The file is saved in the project folder by default.

II ajectory	Files		
D:/work/w	vorkfile/data/t	test/FineInspection/Z18.json	
taut Path.	D. work work	rfila/data/taet/	 1

	A	В	C		D	E	F	G	Н	1	J		K	L	M	Ē.	N	0	P
1	Waypoint	]Canera	Li:Focal	Leng	aypoint	ELongitude	Latitude	Elevation	Pitch Angl	Yaw Angle	Distance	Part	Nane						
2					4	3 554.00998	37. 02.0715	47.725	-36, 42	71,96	11. 28	5							
3	83	Caneral	)	1	3	12.1, 99695	32. 619236	29, 737	3.84	65.27	3. 35	5 Left	Circuit	Botton	Phase	Small	Side In	nsulator (	Conducto:
4	14	Camera0	)	1	1	3 534.4088	11. 87.9036	30.09	0	71.90		B Left	Circuit	Bottom	Phase	Small	Side In	nsulator 1	Hole Str:
5	104	Camerad	)	1	1	3 \$1.1.49496	21.15696	30.219	0	71.96	6 3	3 Left	Circuit	Botton	Phase	Small	Side In	nsulator	fower Em
ő		i Camera0	)	1	4	500006,231 8	SL BLADER	30.14	0	71.96	1 4	3 Left	Circuit	Bottom	Phase	Big St	ide Insi	ulator Tor	ver End
7		Canera0	)	1	1	3 111.47530	25. Gett?	29,898	0	71.96	1 3	B Left	Circuit	Botton	Phase	Big Si	ide Insi	ulator Ho	le Strim
8	1	Camera0	)	1	1	553,0008	31.0249/8	29.655	0	71.96	i 1	Left	Circuit	Botton	Phase	Big Si	ide Inst	ulator Co	nductor
9	1	Camera0	)	1	4	3 7.24. 49646	22. #24923	33. 403	0	71.96	1 4	B Left	Circuit	Middle	Phase	Small.	Side In	nsulator (	Conducto:
10	9	Caneral	)	1	3	s the apple	31.354/30	33.471	0	71.96	1 3	left	Circuit	Middle	Phase	Small	Side L	nsulator	Hole Str
17	.10	Camerad	)	1	1	3 254.00589	71. 214943	33.539	0	71.96	1 3	Left	Circuit	Middle	Phase	Smell	Side In	nsulator '	Tower En
12	1	Caneral	)	1		s sna.eame	35.874965	33. 205	0	71.96	1	Left	Circuit	Middle	Phase	Big Si	ide Inst	ulator To	wer End
13	15	Camera0	)	1		3 154.50UNE	\$3.31.8968	33, 265	0	71.96	1 3	Left	Circuit	Middle	Phase	Big Si	de Insi	ulator Ho	Le String
14	13	Cameral	)	1	1	5 1ks 450/95	35 6147/3	33. 326	0	71.96	1 1	Left	Circuit	Middle	Phase	Big S:	ide Insi	ulator Co	aductor 1
15	14	Camera0	)	1	4	3 114.408087	NL THEM	36,919	0	71.96	1 4	B Left	Circuit	Up Pha	se Sma	11 Side	. Insula	ator Cond	actor En
16	18	Caneral	)	1	5	11.4 -10887	32. 334464	36.989	0	71.96	f	Left	Circuit	Up Pha	ise Sma	11 Side	. Insula	ator Hole	String
17	16	Camera0	)	1	1	The second	IL FERRE	37.076	0	71.96	1 2	3 Left	Circuit	Up Pha	se Sma	11 Side	. Insula	ator Towe:	r End
18	13	Cameral	)	1	1	3 124 49940	13.1048	37.19	0	71.96	1 3	B Left	Circuit	Up Pha	ise Big	Side 1	Insulati	or Tower I	End
19	18	Camera0	)	1	4	5 E2-6 (1948)	31.154985	37.41	~4.8	42, 93	3. 22	Left	Circuit	Up Pha	se Big	Side 1	Insulate	or Hole 5	tring
20	15	Camerad	)	. 1	1	3 124 39595	01.10.417.3	37.04	0	71.96	1 2	3 Left	Circuit	Up Pha	se Big	Side 1	Insulate	or Conduc	tor End
23	20	Caneral	)	1	1	104-49870	25, 354362	42.725	-30	71.96	F 1	Left	Circuit	Tunnel					
22	2:				1	3 1.54 (1946)	37. 30-6403	48, 725	-40.3	71.96	11. 87	7							
23	22	S.,			1	S Sig office	28, 124813	47.849	-48.47	-108.04	9.05	9							
24	23	Camerad	)	1	4	B like more	30, 11, 895	42.849	-30	-108.04	1 1	Righ	t Circui	t Tunne	1				
25	24	Caneral	)	1	1	3 214.40399	31. (149)4	36.981	0	-108.04	1 3	3 Righ	t Circui	t Up Ph	ase Bi	g Side	Insulat	tor Hole	String
26	- 24	i Camera0	)	1	1	3 228.00746	31. 324905	36. 982	0	-108.04	1 1	Righ	nt Circui	t Up Ph	ase Bi	g Side	Insula	tor Tower	End
27	26	Caneral	)	1		5 124 5500	31 31 8972	37.107	0	-108.04	1 3	Righ	t Circui	t Up Ph	ase Sa	all Sie	le Insul	lator Town	er End
28	27	Camera0	)	1	1	3 134-0127	01,104,90	36.944	0	-108.04	1	Righ	t Circui	t Up Ph	ase Sm	all Sie	le Insul	lator Hol	e String
29	25	Caneral		. 1	1	3141.00739	31, 355987	36.781	0	-108.04	1 1	Righ	t Circui	t Up Ph	ase Bi	g Side	Insula	tor Condu	ctor End
70	-	-			2		Br. erall.	nr. 77		101.0	1. d	1.77.1	1.77	1. T	-	11.77	• • •		1
1.04	< > >1	N1# -	+											1.4					

## **Export to DJI Pilot**

Convert to a drone route compatible with DJI Pilot app in KML or KMZ format. In advanced settings, you can set initial speed(10m/s by default), yaw angle mode (1 Smooth transition; 2 along the route direction) and waypoint turning mode (1 Fly in a straight line and stop at the waypoint; 2 Turn ahead and smooth through waypoints).

In a jectory Tites		
D:/work/workfile/d	ata/test/FineInspection/Z18.json	
1 m ·		1979: 1979: 11
w lype. Mavic SI		Advanced Setting
Initial Speed:	10.00m/s	Advanced Setting
Initial Speed: Heading Mode:	10.00m/s Smooth Transition(Default)	Advanced Setting
W Type, Mavid 31 Initial Speed: Heading Mode: Waypoint Turn Mode:	10.00m/s Smooth Transition(Default) Fly in a straight line and stop at the way	Advanced Setting ; ; point(Default) =
W 1ype: Mavic 31 Initial Speed: Meading Mode: Maypoint Turn Mode: Haypoint Turn Mode:	10.00m/s Smooth Transition(Default) Fly in a straight line and stop at the way /workfile/data/test/	Advanced Setting - point(Default) -

# Setting

Settings include display setting and shortcut key Settings.

## **Display Setting**

You can set the color, line width, and line type for each layer. Additionally, you can set the snap distance, preview window scale, step size, and preview window point size. You can also choose whether to draw the tower orientation.

	Layer Name	Show/Hide	Color Li	ne Width
1	Part Point		8pix	
2	Part Point Text		5pix	्य
3	Trajectory	$\checkmark$	2pix	
4	Way Point		Зріх	
5	Assist Point		2pix	
6	Trajectory Text	$\checkmark$	4pix	
7 %	aypoint And Part …		2pix	
Snap Distance(pixels): Step Settings:		9 ‡	Preview Window Scale:	1.00
		+++	Preview Window Point Size	5.00

## **Shortcut Setting**

Set the shortcut keys for common operations.

1       Open File         2       Save File         3       Split Trajectory File         4       Merge Trajectory Files         5       Undo         6       Redo         7       Delete Trajectory         8       Clip Tower         9       Add Part Point By Tower Type		Operation Name	Shortcut	^
<ul> <li>2 Save File</li> <li>3 Split Trajectory File</li> <li>4 Merge Trajectory Files</li> <li>5 Undo</li> <li>6 Redo</li> <li>7 Delete Trajectory</li> <li>8 Clip Tower</li> <li>9 Add Part Point By Tower Type</li> <li>10 Delete Design Point</li> </ul>	1	Open File		
3       Split Trajectory File         4       Merge Trajectory Files         5       Undo         6       Redo         7       Delete Trajectory         8       Clip Tower         9       Add Part Point By Tower Type	2	Save File		
4       Merge Trajectory Files         5       Undo         6       Redo         7       Delete Trajectory         8       Clip Tower         9       Add Part Point By Tower Type	3	Split Trajectory File		
5       Undo         6       Redo         7       Delete Trajectory         8       Clip Tower         9       Add Part Point By Tower Type         10       Delete Desite	4	Merge Trajectory Files		
6       Redo         7       Delete Trajectory         8       Clip Tower         9       Add Part Point By Tower Type         10       Delete Desite	5	Undo		
7 Delete Trajectory 8 Clip Tower 9 Add Part Point By Tower Type	6	Redo		
8 Clip Tower 9 Add Part Point By Tower Type	7	Delete Trajectory		
9 Add Part Point By Tower Type	8	Clip Tower		
10 D-1-4- D-4 D-1-4	9	Add Part Point By Tower Type		
	10	Dalasa Darias		~

- Clear Current: Clear the shortcut key settings for the currently selected item.
- Clean All: Clear the shortcut key settings for all items.
# **Defect Recognition**

### Summary

Defect recognition mainly includes place files by location, defect marking, auto recognition, and generate report.



### Place Files by Location (Split Pictures)

Split Pictures	Rename Pictures	Conductor or Shield Wire Pictures	Distr
Tower Index Fil	е Туре		
🖲 Json	⊖ kml	🔘 LiTower	
Picture Path:			
Tower Index File	Path:		
Output Path:			

- Picture Path: Specify the photo folder, the folder contains the pictures of the multi-base tower.
- Json Path: The route file is placed in the photo file, which is consistent with the photo path.
- **Output Path**: Specify the output folder, new files and archive photos will be created according to the tower number.

### Place Files by Location (Rename Pictures)

Split Pictures Rena	me Pictures	Conductor of	r Shield Wire Picture	s Distr
Naming Rule:	) Default	Short		
Towers:	• Single 7	lower 🔿 Ba	tch Towers 🔿 All	Towers
Image Order:	) By Captu	ure Time	🔿 By Name	
Match Mode:	) By Image	e Location	🔿 By Image Time	
Line Type:	• Single (	Circuit	🔿 Double Circui	t
Line Name:	test line			
Voltage Level:	500kV			
Assessor Company:	[			
Inspection Personnel:	-			
Threshold:	1.00 m			\$
Picture Path:				
Json Path:				
Tower Name Path:			Hnwant.ed!	New
Output Path:				
			OK	Cancel

- Naming Rule: The default short naming rule.
- **Towers**: The default is single tower, if rename the picture of a multi-base tower is needed, batch or all towers option can be selected.
- Image Order: The default is by capture time, can also be ordered by name.
- **Match Mode**: The default is image location, the photo location matches the waypoint location and the photo location, and the time taken is the waypoint sequence matches the photo time sequence.
- Line Type: The default is single circuit, which is selected according to the tower type.
- Line Name: Customize.
- Voltage Level: Customize.
- Assessor Company: Customize.
- Inspection Personnel: Customize.
- **Threshold**: The default is 1m, automatically match when the space position difference between the image and the waypoint is less than 1m.
- Picture Path: Specify the path of the photo directory.
- Json Path: Specify the flight path file, do not need to enter if the multi-tower is renamed.
- Tower Name Path: Specify the tower name path when double circuit line type is selected.
- Output Path: Specify the output directory.

### Place Files (Conductor and Shield Wire Pictures)

Solit Pictures	Rename Pictures	Conductor or Shield Wir	e Pictures	Distr
opric riccares	Kename 110 cures	oundation of philora #11		DISCI
Naming Rule:	Default Long Demo:220kV LineName	e TowerName LineType Dist	○ Shor ance Demo:Di	t stance
Line Name:				
Voltage Level: [				
Data Path:				444
Json Path:				•••
LiTower Path:				
Output Path:				
			1	20000 000

- Naming Rule: The default long naming rule and another short rule.
- Line Name: Customize.
- Voltage Level: Customize.
- Data Path: The organized path for conductor and ground wire photos.
- Json Path: Specify the route file.
- LiTower Path: Specify the LiTower file.
- **Output Path**: Specify the output path.

# Place Files (Distributing Network Pictures)

tures Conduc	tor or Shield Wire Pictures	Distributing Network Picture	es 📢
Naming Rule:	○ Default Demo: 1/DJI_0155.JPG	◯ Line Name Demo: #1/DJI_0155LineNam	∋#1.JPG
Line Name:			
Picture Path:			••
Json Path:			
LiTower Path:			••
Output Path:			
		OK	

- Naming Rule: The default naming rule and another rule with line name.
- Line Name: Customize.
- **Picture Path**: Distributing network pictures path.
- Json Path: Specify the route file.
- LiTower Path: Specify the LiTower file.
- **Output Path**: Specify the output path.

### **Place Files (Imitation Line Pictures)**

e Pictures	Distributing Network Pictures	Imitation Line Pictures	Log 🖣
Picture Path:			
LiTower Path:	ne process is slow and requ	ires patience to wait.	
Output Path:			
General Text:			Modify
Hold down Ctrl Click on the d	to select multiple cells. olumn name to select a column.	1	Clear Selection
Apply to modif Click OK to st	y text. Click Clear to clear se art renaming.	lected 1tems.	Preview
-		122	244

- **Picture Path**: Imitation line pictures path.
- LiTower Path: Specify the LiTower file.
- **Output Path**: Specify the output path.
- General Text: Edit text.

### **Edit Defect List**

Edit the defect groups and categories in the dialog.

~	Balancing Ring Inclination and Damage	^	-
~	Basis Other Defects		+
	Settlement		
~	Damage or Shedding		( <u></u>
~	Bird Stick Damage or Shedding		
~	Clamp Inclination and Damage		1
Y	Discharge Gap	,	

### **Defect Annotation**

First edit and select the defect category, click the "Start/End Annotation" to frame the defect area on the picture, a red frame will be displayed, then click "Save Defect File", and then click the "Export" button to export the defect picture.



**Generate Report** 

Click the "Generate Report" button to automatically generate a report.

### •Green Valley Image Verification Results

Date: v Flace: v

Tace: 0

Participants: 0

— v "Result"

The total number of defect recognition images this time is 1, including 1defective image and 0 normal images.

#### 1. Defect List

Турео	Detail	Junbero	<b>Bemark</b> o	
Balancin g <sup>.</sup> Ring .	Inclination and Damage	1.	1 <b>4</b> (	

#### 2、Defect Details



8 F

500kV-test-line=#33-Middle-Phase-Insulator-Tower-End\_Balancing-RingIndination-and-Damage-

# Measurement

To measure different components of the power line channel such as tower or conductors, based on point cloud data. And generate analysis report. Specific functions are as below:

Tower Inclination         Cross Arms Height Differen         Tower Nominal Height	ce	Open Working Directory
Measurement	F2	Tool Box
	王	Minimum Distance
	责	Minimum Crossing Distance
	Ŧ	Phase Distance
y	225	Measure Sag
×X	-	Sag
	F	Rotation Angle
	-	Deflection
	黛	Protect Angle
	1	Tower Diaphragm
	4	Curve Length
	3	Goto

- Tower Inclination
- Cross Arms Height Difference
- Tower Nominal Height
- Measure Minimum Distance
- Minimum Crossing Distance
- Phase Distance
- Measure Sag
- Sag
- Measure Rotation Angle
- Deflection
- Protect Angle
- Tower Diaphragm
- Curve Length
- Goto

# **Measure Cross Arms Height Difference**

#### Summary

By selecting the cross arm points on the transmission tower, calculate the height difference between the left and right cross arms. And save the measurement result to the specified directory.

### Usage

Click Measurement > Cross Arms Height Difference





Open the height difference of cross arms file.

# -

Save the height difference of cross arms file. The default output path is the tower analysis folder in the working directory. The default file name is "CrossArmsHeightDifference.txt".

Delete the selected record in the result list.



Clear the results in the result list.



Auto-Cross Arms Height Difference



D:/work/workfile/da	ata/test/data/18-19(18_19).LiData	-
		1
enerate Report		1
Assessor Company:	Electrical Transmission Bureau/Company:	1
Line Name:	11	
Target Coordinate:	₩GS 84 👻	
Report Path:	ork/workfile/data/test/AnalysisReport/	

### **Parameters**

Please refer to Report Parameters for details.

# **Measure Tower Nominal Height**

# Summary

Nominal height is the vertical distance from the tower cross arms (the lowest cross arms) to the construction base surface of the tower contended with the surface of the surface of the tower contended with the surface of the surface of the tower contended with the surface of the surface of the tower contended with the surface of the surfac construction base surface of the tower center pile (the longest tower leg footplate or the top surface of the foundation). By select the bottom cross arms point on the pylon, calculate the nominal height and save to the specified directory.

### Usage

Click Measurement > Tower Nominal Height.

🎢 Measure Tower Nominal	Height	
Tower Name	Nominal Height (m)	



### Open

Open the nominal height file.

#### Save

Save the nominal height file. The default location to save the result is the "NominalHeight.txt" file in the tower analysis folder in the working directory.

#### **Delete Selected Record**

Delete the selected record in the result file.

### **Clear Result**

Clear the result list.

### **Automatic Calculation**

Automatic calculation

# **Generate Report**



# **Measure Minimum Distance**

#### Summary

Support ground object point measurement and wire point measurement. For the feature point model, the minimum horizontal distance, minimum vertical distance and minimum clearance distance from the small tower and power line can be measured in real time. For the wire point model, the minimum horizontal distance from the small tower, the minimum clearance distance from vegetation and the vertical distance to the ground can be measured in real time. Select the ranging type, click the left mouse button in the view window, select any ground object point/wire point, and obtain the minimum distance from the point to the small pole tower and power line.

### Usage

#### Click Measurement > Minimum Distance





Note: Note: To use this function, the classification of the power line is required. If the tower file (.LiTower file) is not set, only the minimum distance to the power line will be displayed.

# **Measure Minimum Crossing Distance**

### Summary

This function is used to measure the minimum distance between the power line category and the crossing category in the current point cloud, as shown in the following figure.

### Usage

Click Measurement > Minimum Crossing Distance

Distance Type:	Clearance	
Powerline Category:	16-Conductor	+
Crossing Category:	19-Scissors Crossing Down	•
Result		_
Morizontal Distance:		
Vertical Distance:		

#### **Parameters**

- Distance Type (default value is "Clearance"): Set calculation distance types, including clearance, horizontal, and vertical.
- Power Line Category (default value is "Conductor"): Set the category of power lines.
- Crossing Category (default value is "Scissors Crossing Down"): Set cross category.

#### Result

- Horizontal Distance: The horizontal distance between two points at the minimum crossing distance.
- Vertical Distance: The vertical distance between two points with the minimum crossing distance.
- Clearance Distance: The clearance distance between two points with the minimum crossing distance.

#### **Steps**

1. After enabling the tool for measuring minimum crossing distance, select the distance category, power line category, and crossing category, and click calculate.

# **Measure Phase Spacing Distance**

### Summary

This function is similar to the "Phase Spacing Analysis" function. Phase spacing analysis is used to calculate the all the phase spacing of all the phases between each two transmission tower. While the measure phase spacing distance function can measure the phase spacing at any position in between each two transmission towers.



### Usage

#### Click Measurement > Phase Distance

Select any point on the power line, create a profile with this point, calculate the phase distance (the default profile distance is 10m, that is, 5m to the left and right of the selected point), and display the result on the user interface in real time.

- **Profile Thickness(meters)(default value is "5.0")**: The thickness of the cross profile of the power line which is used to extract the point cloud for calculating. The software can record the currently setting and when the user open this function again, the setting will be kept.
- Cluster Threshold(meters)(default value is "3.5"): The maximum spatial separation distance when the point cloud data is clustered. Power line points smaller than the threshold will be clustered into a cluster. The software can record the currently setting and when the user open this function again, the setting will be kept.
- Default: Default value will be set when click this button;





# **Measure Sag**

### Summary

This function is used to measure sag. Mainly used for measuring the sag of wires, ground wires, and drainage wires.

# Usage

Click Measurement > Measure Sag

Power Line	🔘 Earth Wire	🔵 Drainage
Profile Thickn	ess: 5.00m	:
Cluster Thresh	old: 3.50m	÷
Hang Thickness	0.10m	\$
Height Thresho	Ld: 0.50m	¢
Measurement Me	thod	
🔿 Single Poin	t 💿 Three Poi	nts
Point Selectio	n Mode	
🔿 Manual	Automatic	
Point Selectio	n Posítion	
🖲 w; dd] 🗸	O Lowest O N	ໂລະເຫັນຫ

**Parameters** 

- Line Type: Default is power line, select the target line type for calculation (power line/wire, ground wire, drain wire).
- **Profile Thickness(meters)(default value is "5.0")**: The thickness of the cross-section of the line is used to extract a single wire point cloud.
- Cluster Threshold (meters)(default value is "3.5"): When clustering point cloud data, the maximum spatial interval distance is used. Power line points below this threshold will be clustered together.
- Hang Thickness(meters)(default value is "0.1"): The thickness of the point cloud cross-section near the hanging point is used to extract the hanging point.
- Height Threshold (meters)(default value is "0.5"): Measure the maximum height difference of the line point cloud of the measured object. If the height difference of the slice is greater than this threshold, it is considered that there are hanging points or other types of point clouds in the slice.
- **Measurement Method**: Default to single point. When selecting a single point, simply select the measurement point to automatically calculate the sag of the measurement point. When selecting three points, you need to sequentially select the small side hanging point, the large side hanging point, and the measurement point to calculate the sag of the measurement point.
- **Point Selection Mode**: Default to manual. When selecting manual, calculate the sag of the manually selected point. When selecting automatic, it is necessary to select the automatic calculation position (middle point, lowest point, maximum sag point), and then calculate the sag of the selected position of the line corresponding to the selected point.
- Point Selection Position: The default is the midpoint. Select the location for automatic calculation.
  - Middle: The midpoint of the line.
  - Lowest: The lowest point of the line elevation.
  - Maximum: The maximum point of line sag.

#### **Steps**

 After enabling the sag measurement tool, select the line type of the object to be measured, adjust the parameters, and when the measurement method is single point, click on the point to be measured to automatically calculate the sag of the measurement point. When the measurement method is three points, click on and select the small side hanging point, large side hanging point, and measurement point in order to calculate the sag of the measurement point.

# Sag Analysis

### Summary

Analysis sag, line length etc based on vector file or simulation file input. The result data can be saved as(\*.csv \*.xls) and generate report. Click to add data. Click to remove data selected. Click to clear data list.

# Usage

Click Measurement> Sag

Dara Tire Log		
D:/work/workfile/data/test/data/20	-21(20_21).LiData	<b>+</b>
D, WOLK WOLKING GALA/LESQ GALA/ 15	-20(13_20).00818	
		1
Function Option		
🗹 Sag Analysis 🛛 🗹 🤇	Generate Report	
Sag Analysis Generate Report		
Adjust Sag With Point Cloud Sag Deviation	🗌 Calculate Distance	• To Ground
Observed Temperature: 20.00 °C	Observed Wind Speed: 0.0	Om/s 🗘
Power Line File:		
Shield Line File:		
Drainage Thread File:		
11		
Output Path: /work/workfil	.e/data/test/cache/SagAnalysis/	***
	~	
Output File Format: csv		

### **Parameters**

- Sag Analysis(check by default): Checked to calculate sag etc.
  - Adjust Sag With Point Cloud(unchecked by default): Adjust sag based on point cloud.
  - Distance to Ground(unchecked by default): Calculate distance to ground.
  - Sag Deviation(unchecked by default): Calculate Sag Deviation.
  - Observed Temperature: Temperature when scanning.
  - Observed Wind Speed(m/s): Wind speed when scanning.
  - **Powerline File**: Set input file for powerline sag analysis, file format:shp.
  - Shield Line File: Set input file for ground conductor sag analysis, file format:shp.
  - Conductor File: Set input file for conductor sag analysis, file format:shp.
  - Output Path: "cache/SagAnalysis/" by default.
  - Output Format(csv by default): Support csv and xls.
- Generate Report(checked be default): Generate report.
  - Assessor Company: Assessor company.
  - Electrical Transmission Bureau/Company: Electrical transmission bureau/company.
  - Line Name: Line name.
  - Target Coordinate: Target Coordinate System.
  - **Report Path**: Path to store result files.
- Threads Num(default value is "4"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.

Note: Input data includes vector file and simulation file \*.LiSim.And the vector file should be shape file(.shp) created by vectorization, not simulation.

# **Measure Rotation Angle**

### Summary

This function is used to measure the rotation angle of the tension tower, as is shown below.

### Usage

Click Measurement > Rotation Angle



#### Steps

- After starting the "Measure Rotation Angle" tool, select power line points on the left and right sides of the tension tower and tower points, and the result will be displayed in the scene in real-time. Rotation angle will be displayed in "degree" rather than "radian". The result is the angle less than 180 degrees.
- 2. Right-click to call the menu, and choose "Back One Point" in order to cancel the last point picking; choose "Clear Measurement" to cancel the point picking of all the points; and choose "Quit" to quit the measurement.

# **Measure Deflection**

### Summary

This function is used to measure deflection and the effect is shown below. Mainly used for measuring the bending degree of straight steel such as tower leg and tower body.

# Usage

Click Measurement > Deflection



### Steps

1. After the deflection tool is enabled, select three points P1, P2 and P3 on the point cloud in turn to complete the deflection measurement. Double-click the last point to select. The deflection value is calculated as the distance between p2 and P1p3.

# **Measure Protect Angle**

### Summary

This function is used to measure the protection angle. The protection angle is the angle between the shield wire cross arm to the first wire cross arm and the vertical direction. The tower needs to be classified before using this function. Results as shown below. It is mainly used to measure the bending degree of straight steel such as tower legs and tower body.

# Usage

Click Measurement > Protect Angle

) =	💼 H - 🥖			
	Tower Name	Protect Angle(°)	Phase	
1	19	-0.37	Left Phase	
2	19	-0.04	Right Phase	
3	20	-0.35	Left Phase	
4	20	-0.20	Right Phase	
5	21	-0.35	Left Phase	
	21	0.00	Piaht Dhaca	

### Steps

After the protection angle measurement tool is enabled, select the end of the shield wire cross arm and the end of the wire cross arm in turn, and then double-click to complete the measurement.

# **Result List**

### Auto Calculate Protect Angle

Protect Angle Ana	alysis			
Data File Log				
D:/work/workfile/ D:/work/workfile/	data/test/data/19-20( data/test/data/18-19(	19_20).LiDa 18_19).LiDa	ta ta	÷
				1
ease classify Tore Personator Corre	r points in edvence.			,
Frofile Inickness.	5.00m			
Filter Width.	2.00m			

#### **Parameter**

- **Profile Thickness(default value is "5.00m")**: The width of the point cloud slice along the specified direction.
- Filter Width(default value is "2.00m"): Point cloud filtering width.

Note: Please classify the tower points in advance.

Save the tower tilt file, the output file path will be displayed in log.

Delete the selected results list.

Clear the result list record.

# Generate Report

<ul> <li>Generate Report</li> </ul>				
Data File Log				
D:/work/workfile/da D:/work/workfile/da	ata/test/data/19 ata/test/data/18	-20(19_20).LiDa -19(18_19).LiDa	ta ta	÷
				1
				1
Generate Report				
Assessor Company:		Electrical Tran Bureau/Company:	smission	
Line Name:	11			
Target Coordinate:	WGS 84		•	•••
Report Path:	k/workfile/dat	a/test/Analysis	Report/	•
		2014		

### Parameters

Please refer to Report Parameters for details.

# **Measure Tower Diaphragm**

### Summary

By selecting the four vertices of the transverse plane on the tower, calculate the length of the four sides

Ť of the transverse plane and the angles of the four corners, and save the measurement results to the specified directory.

# Usage

Click Measurement > Tower Diaphragm

	Index	Х	Y	Z	^
1	A	0.000	0.000	0.000	
2	В	0.000	0.000	0.000	
3	С	0.000	0.000	0.000	
4	D	0.000	0.000	0.000	~
T	ower Name	• 🥖 🌋 AB (m	)	BC (m)	1
					-



### **Tower Points List**

 $\overrightarrow{\uparrow}$  Add top tower points.



Delete the selected tower points.



Modify the selected tower points.

Empty the tower points.



Start calculating the cross section of the tower.

### Compute

Compute the relevant parameters of the cross section of the tower based on the picked tower points, and display the calculation results in the result list.

### **Result List**



Open the tower cross section file.

Open the tower cross section file.

Save the file of the cross section of the tower. By default, save it as the '. txt' file of the cross section of the tower in the tower analysis folder in the working directory.

Delete the selected result list record.

Clear the result list record.

Automatically calculate the cross section of the tower.

### Auto Calculate Tower Diaphragm

#### Summary

Analyze and calculate the selected point cloud data of the tower, automatically obtain the parameters of the cross section of the tower, and save them to the result list. The functional interface is shown in the following figure, which can process multiple data simultaneously. Click to add pending data, click to remove the selected data and click is to clear the data list.



Data File Log				
D:/work/workfile, D:/work/workfile,	/data/test/c /data/test/c	lata/20-21(20_21).LiC lata/19-20(19_20).LiC	Pata Pata	÷
				1
Parameter				
Tower Body Class:	17-Struct	ire		
Slice Thickness:	0.50m			٤
Extract Range:	2.00m			

#### parameter

- Tower Body Class(default value is "17m"): The category number of insulators in point cloud data.
- Slice Thickness(default value is "0.50m"): The thickness of the cross-section along the two main horizontal directions of the tower is used to extract the initial value of the cross-sectional height. When the point cloud density is low, this value can be slightly increased. The software can record the user's current settings and automatically restore them when opened again.
- Extract Range(default value is "2.00m"): Extract the precise height range from the initial extracted crosssectional height. The software can record the user's current settings and automatically restore them when opened again.

#### **Tower Diaphragm Report**

Save the tower cross section file and generate a tower cross section report.

rower biapinagin	Report	
Data File Log		
D:/work/workfile/c D:/work/workfile/c	lata/test/data/19-20(19_20).LiData lata/test/data/18-19(18_19).LiData	+
		1000
		1
Generate Report		
Assessor Company:	Electrical Transmission Bureau/Company:	
Line Name:	11	
Target Coordinate	₩GS 84 ▼	
Report Path:	ork/workfile/data/test/AnalysisReport/	

### **Parameters**

Please refer to Report Parameters for details.

Note: This function requires tower classification of point cloud data first.

Note: The cross section of the tower refers to the separation surface between the tower legs and the tower body.

# **Curve Length**

### Summary

Draw a curve by selecting points on the point cloud in the scene, calculate the length of the curve, and save the curve information in the specified format.

# Usage

Click Measurement > Curve Length

77.	Ч	Z
re List	/ 🖬	
		Length(m)
ID		Length(m)
ID		Length(m)

# Point List

Create a new curve

Create a new curve.

Add points to the currently selected curve.

Delete the selected point.



Clear all points on the current curve.

### **Curve List**



🔤 Open curve file(.json).

Bave the curve file (. json) as the CurveMeasurement (.json) file in the cache/CurveMeasurement folder of the working directory by default.



Export the selected curve as a KML file.



Export the selected curve as a CSV file.



Delete the selected curve record.



Clear the curve list record.



Automatically calculate curve length.

### **Parameter**

- Show Only Current Curve: Not checked by default. If checked, only the currently selected curve in the curve list will be displayed in the scene.
- Show Label: Not checked by default. If checked, the ID and length of the curve will be displayed.

### **Calculate Curve Length**

#### Summary

Analyze and calculate the specified detection category of the selected point cloud data, automatically

Analyze and calculate the specified detection category of the selected point cloud data, automatically pick the curve and calculate the length, and save it to the result list. The functional interface is shown in the following figure, which can process multiple data simultaneously. Click to add pending data, click 

D:/work/workfile/data, D:/work/workfile/data,	/test/data/20- /test/data/19-;	21(20_21).LiD 20(19_20).LiD	ata ata	+
nimum Cluster Radius: [	0.50m 🗘	Curv	e Width: [	0. 50m

#### **Parameter**

- Minimum Cluster Radius(default value is "0.5m"): The radius value used for point cloud clustering.
- Curve Width(default value is "0.5m"): Extract the width of the curve.
- Detection Classification: The target category that participates in the calculation when automatically extracting curves.
- Select All: Not checked by default, if checked, all categories will be included in the detection category.

# Goto

### Summary

This function is used to redirect the current scene view to the input target coordinate position.

### Usage

Click Measurement > Goto

• Pr	ojection Coordinat	e 🔵 Geographic Coordinate
X:	0.000	
¥ :	0.000	
Z:	0.000	
Size:	1.00m	
✓ Sh	ow Points	📃 Remain Points

### **Set Parameter**

- **Coordinate reference**: The default is the projection coordinate system, which supports latitude and longitude geographic coordinates. Select the coordinate reference type used for coordinate jump.
- Size: After jumping to the target position, draw the radius size of the ball at that coordinate.
- Show Points: Checked by default, the ball will be drawn at the coordinate position after jumping; Uncheck and the ball will not be displayed.
- **Remain Points**: Not checked by default. If checked, the previously drawn ball will be retained when jumping coordinates continuously.
- Clear: Click to clear the coordinate jump ball drawn in the scene.
- **Goto**: After clicking, the scene jumps to the position corresponding to the input coordinates and draws a small ball according to the specified size.

### Steps

1. After enabling the jump tool, select the target coordinate reference system, enter the 3D coordinates, and click "Jump" to jump to the corresponding position.
# Toolbox

Toolbox contains point cloud processing, result finishing, and other tools, which is used to process and analyze the point cloud data. The toolbox includes the following tools.



#### • Point Cloud Processing

- Strip Clip
- Individual Tree Segmentation
- Convert LiData To Las
- Merge Point Cloud and Vector Data
- Export Mixed Color Point Cloud
- Classify Circuit by Tower Info
- Automatic Shield Line Classification
- Classify Noise by Vector Line
- Copy And Adjust Point Cloud Position
- Interactive Patch Line
- Classify By Category And Restatistics
- Smooth/Compress Point Cloud Data
- Result Finishing
  - Export Danger Points
  - Extract Danger Point Clouds
  - Extract Danger Trees
  - Tower Account
  - Section Map
  - Section Report
  - Merge Tower KML Files
  - Batch Rename Section Data Files
- Other Tools
  - Open Working Directory

### **Strip Clip**

#### Summary

Input a point cloud has not been segmented and the tower information, and this tool will clip the point cloud data into several parts along the power line. The function interface is shown in the figure below. This function can process multiple data at the same time. Click to add the data to be processed. Click — to remove the selected data. Click is to clear the data list.

#### Usage

Click Toolbox > Point Cloud Processing > Strip Clip

Strip Clip				
Data File Log				
				÷
				-
lip Parameter —				
Clip Parameter Channel Width:	60 v m	Segment Buffer:	10	n
Clip Parameter Channel Width: Start Tower Index:	60 ~ m	Segment Buffer: End Tower Index:	10 8	m
Clip Parameter Channel Width: Start Tower Index:	60 ~ m 0	Segment Buffer: End Tower Index: Sampling Radius:	10 8 0.01	m
Clip Parameter Channel Width: Start Tower Index: Resample Dutput File: C:/PH	60 v m 0 OJECT/StripClipBata LiI	Segment Buffer: End Tower Index: Sampling Radius: Nata	10 8 0.01	m m

### Settings

- Channel Width (meter) (default is "60"): Width extending to both sides of the power line. The software can record the user's current settings and automatically restore the settings when opened again.
- Segment Buffer (meter) (default value is "10"): Extension distance at both ends of the transmission tower.
- **Start Tower Index**: Towers with index numbers smaller than this value are not involved in the calculation. The default value is the minimum Index in the tower file.
- End Tower Index: Towers with index numbers larger than this value are not involved in the calculation. The

default value is the maximum Index in the tower file.

- **Resample**: If checked, input point cloud will be compressed.
- Sampling Radius (meter) (default value is "0.01"): Minimum interval for point cloud sampling.
- **Output File**: The output path of the result file.

### **Individual Tree Segmentation**

#### Summary

Perform individual tree segmentation for the input point cloud data. The function interface is shown in the figure below. This function can process multiple data at the same time. Click - to add the data to be processed. Click — to remove the selected data. Click  $\checkmark$  to clear the data list.

#### Usage

Click Toolbox > Point Cloud Processing > Individual Tree Segmentation

Data File Log		
D:/Data/data/29-30(29_30).LiData		
D:/Data/data/28-29(28_29).LiData		-
Sigma: 1.5	Height Above Ground: 1.0	m
areads Num (1-32): 4	Star	Exit

#### Settings

- **Sigma (default value is "1.5")**: Individual tree segmentation smoothing coefficient. If there are too many trees, increase the smoothing factor, otherwise, decrease the smoothing factor.
- Height Above Ground (meter) (default value is "1.0"): Point clouds above ground by distances greater than this value are used for individual tree segmentation, and less than this value will not be segmented.
- Threads Number (default value is "4"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.

Note: If the point cloud has been segmented, user must clear the result of individual tree segmentation before redoing the segmentation.

## **Convert Lidata To Las**

#### Summary

• • • The classify function can be used to convert Lidata files to las files. The noise categories can be • • • removed from the point cloud file. Meanwhile, the input data can be merged and output. The function interface is shown in the following figure. This function can process multiple data simultaneously. Click + to add data to be processed, click — to remove selected data, and click 🥖 to clear the data list.

### Usage

Click Toolbox > Point cloud Processing > Convert Lidata To Las

Data File Log		
	L'Data	
C:/PROJECT/data/0-1(0-1)	LIData	45
		-
		-
		1
Mode	○ #.1.'.1. 1'	
Single Line	O wartibre rive	
Uptions Remove Noise	🗹 Merge Point Cloud	
Specify Output Directory		
Output Path:		][
	Start	Exit

#### **Parameter Settings**

- Mode
  - Single Line (default mode): Once checked, this function is used to process single LiData file. You

should add single LiData file to the Data File List.

- **Multiple Line**:Once checked, this function is used to process multiple work directory. You should select the base directory of multiple working directory, then the target LiData files will be added to Data File List automatically.
- Options
  - Remove Noise: Once checked, the noise categories will be removed.
  - **Merge Point Cloud**: Once checked, this function will export an additional las file that merges the input point cloud.
- **Specify Output Directory**: If this option is checked, the output file will be generated in the specified directory. If it is not checked, output files will be generated in the peer directory of the input file.
- Num of thread(4 by default):Set the number of running threads of the function, which can support 1-32 threads. The software can record the user's current setting and automatically restore the setting when it is opened again.

### **Merge Point Cloud and Vector Data**

#### Summary

Merge the input point cloud and vector data, and generate the point cloud in the specified format. This function is used to improve the point cloud quality when the power line point cloud is thin or partially missing. The function interface is shown in the figure below. This function can process multiple data simultaneously. Click to add the data to be processed. Click to remove the selected data. Click to clear the data list.

#### Usage

Click Toolbox > Point Cloud Processing > Merge Point Cloud and Vector Data

Data File Log		
		÷
		1
🗌 Delete Original Poir	ts	
Line Width:	30.00 mm	<b>.</b>
Point Spacing:	0.010 m	<b>÷</b>
Discrete Point Number:	2	\$
🗌 Use Specified Class	1-UnClassified	7
Vector File:		
Output Path:	/PROJECT/	
Output File Format: 1	data	~
weads Num (1-32): 4		tart Frit

### Settings

• **Delete Original Points**: Unchecked by default. If this option is checked, the newly generated point cloud will not contain the power line class points in the original data; otherwise, the power line points in the original

data will be kept.

- Line Width (millimeter) (default value is "30"): The width of the power line generated from the vector data.
- **Point Spacing (meter) (default value is "0.01")**: The spacing of each two adjacent power line points generated from the vector data.
- **Discrete Points Number (default value is "10")**: The discrete points number generated for each point in the vector data. The larger this value is, the more dense the result point cloud will be.
- Use Specified Class: If checked, only the specified category is used for merging, and other categories are output normally.
- Vector File: Set the path of the vector file.
- **Output Path**: Set the path of output file.
- Output File Format: The output format of the result, supporting lidata and las format.
- Threads Number (default value is "4"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.

### **Export Mixed Color Point Cloud**

#### Summary

This function is used to generate the point cloud with color mixed by class and RGB color information of the ground objects. The function interface is shown in the figure below. This function can process multiple data at the same time. Click to add the data to be processed. Click to remove the selected data. Click is to clear the data list.

#### Usage

Click Toolbox > Point Cloud Processing > Export Mixed Color Point Cloud

Transmission in the second second		
D:/Data/data/29-30 D:/Data/data/28-29	)(29_30).LiData )(28_29).LiData	
-		
Output Path:	D:/Data/MixedColorPointCloud/	
Output Path: Classification:	D:/Data/MixedColorPointCloud/	[
Output Path: Classification: Output File Format:	D:/Data/MixedColorPointCloud/	

#### Settings

- Output Path: Set the path of the output file.
- **Classification**: The class(es) of the points that need to be export with the color of those class(es). In the result, the points with selected class(es) will be displayed in the color of those classes, and the other points will be displayed in RGB, when the data is set to Display by RGB.
- Output File Format: The output format of the result, supporting lidata and las format.
- Threads Number (default value is "4"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.

Note: The input data must have attribute of RGB color.

### **Classify Circuit by Tower Info**

#### Summary

Divide the conductors into left and right loops respectively. Each loop forms a class. The function interface is shown in the figure below. This function can process multiple data at the same time. Click to remove data list.

#### Usage

Click Toolbox > Point Cloud Processing > Classify Circuit by Tower Info

Data File Log	ower into		
			- <u>0</u> -1
			1
Paramatar			1
Parameter			
Parameter Left Circuit Class: Right Circuit Class:	16-Conductor		
Parameter Left Circuit Class: Right Circuit Class:	16-Conductor 16-Conductor		•

#### Parameter

- Left Circuit Class: Select the class index of left circuit.
- Right Circuit Class: Select the class index of right circuit.
- Num of thread(4 by default): Set the number of running threads of the function, which can support 1-32 threads. The software can record the user's current setting and automatically restore the setting when it is opened again.

## **Automatic Shield Line Classification**

#### Summary

This function needs to divide the shield lines into conductors in advance; after this function, the shield lines will be automatically separated. The function interface is shown in the figure below. This function can process multiple data at the same time.Click to add data. Click to remove selected data. Click

#### Usage

Click Toolbox > Point cloud Processing > Automatic Shield Line Classification

	Log				
					+
					1
s: Please clas	ssify the shiled lit	ne points into	the power line type fi	rst.	
i <mark>s: Please clas</mark> ayer Number:	ssify the shiled lit	ne points into	o <b>the power line type fr</b> Slice Thickness:	rst. 2.00m	
<mark>s:Please clas</mark> ayer Number: luster Thres	s <b>sify the shiled li</b> : 2 shold: 3.50m	ne points into	o <b>the power line type fr</b> Slice Thickness: Middle Phase Width	rst. 2.00m : 2.00m	

#### **Parameters**

- Layer Number: The number of layers of lines before classification.
- Slice thickness: The slice thickness of the wire cut along the transverse direction.
- Cluster Threshold(m)(3.5 by default): When the point cloud data is clustered, the maximum spatial separation distance, the power line points smaller than the threshold will be clustered into a cluster.
- Middle Phase width(m)(2 by default): The width of the mid-phase area.
- Num of thread(4 by default): Set the number of running threads of the function, which can support 1-32 threads. The software can record the user's current setting and automatically restore the setting when it is opened again.

### **Classify Noise by Vector Line**

#### Summary

This function can divide unclassified points into noise and conductors by vector lines. The function interface is shown in the figure below. This function can process multiple data at the same time.Click to add data. Click —to remove data selected. Click solution of the figure below.

### Usage

Click Toolbox > Point cloud Processing > Classify Noise by Vector Line

		-
		÷
		1
'arameter		
ector File Path:		1.4.4 1
rom Class:	O-Never Classified	*
owerline Diameter:	0. 75m	-
ilter Range:	3.00m	\$
Remove Higher No:	se	

#### **Parameters**

- Vector File Path:: The path of the vector line. The vector line is in shp format, including all the conductors of all cuts.
- From Class: Select the point cloud category that matches the vector file.
- **Powerline Diameter (m) (default is 0.75)**: The cross-sectional radius of the conductor can be input after measuring with a tool. The default is 0.75 meters.
- Filter range (m) (default value is "3.0"): The range for denoising the point cloud. Indicates how much noise is removed around the conductor.
- Remove Higher Noise: If checked, high-altitude noise points will be removed.
- Num of thread(4 by default): Set the number of running threads of the function, which can support 1-32 threads. The software can record the user's current setting and automatically restore the setting when it is opened again.

# **Copy and Adjust Point Cloud Position**

### Summary

### Usage

Click Toolbox > Point cloud Processing > Copy and Adjust Point Cloud Position.

Pura - 1 - 4	1.2	7	)				
[ranslat {: 0.100	ion Jm ‡		lotation Axis:	1	*	-	
Franslat (: 0.100 (: 0.100	ion Jm : Jm :		lotation Axis: Axis:	5. 00°	*	+	

#### Save File

Save the copied file.

### **Copy Model File**

Copy the model file.

#### **Remove Data**

Remove the selected data.

#### **Clear List**



#### **Parameter Settings**

- Translation: Perform translation on the copied point cloud.
- Rotation: Perform rotation on the copied point cloud.
- Model Point Cloud File: The model point cloud file to be copied.

#### Steps

- 1. Click on the model point cloud file to add the model point cloud file to be copied;
- 2. Click on an initial position point in the view, click on "Start Copy" to copy a data and add it to the list;
- 3. Adjust to the desired position through translation and rotation.

## **Interactive Patch Line**

#### Summary

This feature is mainly used to fill in partially sparse or broken power lines. Click — to remove the selected fitting result, click  $\checkmark$  to clear the fitting result list, click  $\subsetneq$  to clear the fitting result list.

### Usage

Click Toolbox > Point cloud Processing > Interactive Patch Line

Cinteractive Fatch	Line		
			T.
			1
			×
Line Type Straight Line		🔿 Parabola	
Line Type Straight Line Parameters Target Class:	16-Cond	O Parabola uctor	 -
Line Type Straight Line Parameters Target Class: Line Width:	16-Cond 30.00mm	O Parabola uctor	-
Line Type Straight Line Parameters Target Class: Line Width: Point Spacing:	16-Cond 30.00mm 0.01m	O Parabola uctor	+
Line Type Straight Line Parameters Target Class: Line Width: Point Spacing: Discrete Point Numbe	16-Cond 30.00mm 0.01m er: 2	O Parabola uctor	*
Line Type Straight Line Parameters Target Class: Line Width: Point Spacing: Discrete Point Numbe Translation	16-Cond 30.00mm 0.01m er: 2	O Parabola uctor Rotation	•
Line Type Straight Line Parameters Target Class: Line Width: Point Spacing: Discrete Point Numbe Translation X: 0.100m	16-Cond 30.00mm 0.01m er: 2	O Parabola uctor Rotation X Axis: 5.00°	•
Line Type Straight Line Parameters Target Class: Line Width: Point Spacing: Discrete Point Numbe Translation X: 0.100m U: 0.100m	16-Cond 30.00mm 0.01m er: 2	O Parabola uctor Rotation X Axis: 5.00° Y Axis: 5.00°	

#### **Fitting Result List**



Fit and fill the selected area based on calculation, and preview the discrete point effect in the scene after calculation is complete.

Clear the selected area.

Merge the point cloud and discrete points, and generate a point cloud file with the same name in the output directory.

#### **Parameter Settings**

- Line Type: The type of line to fit the selected area, which can be "Straight Line" or "Parabola" according to the actual power line.
- Target Category: The category of power line to be filled, default is conductor.
- Line Width: The width of the power line to be fit in the selected area, default is 30mm.
- Point Spacing: The spacing between discrete points for fitting the selected area, default is 0.01m.
- Discrete Point Number: The number of discrete points for fitting the selected area, default is 2.
- **Translation**: Translation parameters for the fitted result along the X/Y/Z coordinate axes.
- Rotation: Rotation parameters for the fitted result around the X/Y/Z coordinate axes.

#### Steps

- 1. Move the scene to the area needing patch line and select a closed polygon.
- 3. Adjust the position of the discrete fitted result through translation and rotation, then merge

## **Classify By Category And Restatistics**

#### Summary

The classify function can be used to convert the target classes to the specified class. The restatistics
 function can be used to recalculate the mean elevation and standard deviation, intensity mean and standard deviation of the point cloud data. The function interface is shown in the following figure. This function can process multiple data simultaneously. Click 
to add data to be processed, click to remove selected data, and click 
to clear the data list.

#### Usage

Classify By Category And Restatistics × Data File Log C:/PROJECT/data/0-1(0-1).LiData i Function Options Restatistics Classify Classification Parameters From Class: 7-Structure: 19-Scissors Crossing Down: 23-Other Line 🧹 🗹 Select All To Class: 1-UnClassified • Threads Num(1-32): 4 🛊 Start Exit

Click Toolbox > Point cloud Processing > Classify By Category And Restatistics

#### **Parameter Settings**

- Function Options
  - Classify (checked by default):Convert the target classes to the specified class.
  - Restatistics (checked by default):Recalculate the mean elevation and standard deviation, mean

intensity and standard deviation of the point cloud data.

- Classification Parameters
  - From Class: Target classes to be converted.
  - Select All: Once checked, all existing classes will be selected as the target classes.
  - **To Class**: Specified class that target classes will be converted to.
- Num of thread(4 by default):Set the number of running threads of the function, which can support 1-32 threads. The software can record the user's current setting and automatically restore the setting when it is opened again.

### **Smooth/Compress Point Cloud Data**

### Summary

its shape. The function interface is shown in the following figure. This function can process multiple data simultaneously. Click 🕂 to add data to be processed, click — to remove selected data, and click 🥖 to clear the data list.

### Usage

Click Toolbox > Point cloud Processing > Smooth/Compress Point Cloud Data

				÷
				Loose 1
				1
Junction Ontion				
⊿ Smooth		🗹 Compress		
'arameters Same With Origin	File Name			
Smooth Parameters	Compress Parameters			
		V Tower		
🖌 Wire		(		
🗹 Wire Search Radius:	0.50m	Search Radius:	0.30m	*
☑ Wire Search Radius: Smoothing Factor:	0.50m 🗘	 Search Radius: Smoothing Factor:	0.30m 0.10	•
☑ Wire Search Radius: Smoothing Factor:	0.50m		0.30m	÷
☑ Wire Search Radius: Smoothing Factor:	0.50m 🗘	 Search Radius: Smoothing Factor:	0.30m 0.10	<b>•</b>
☑ Wire Search Radius: Smoothing Factor:	0.50m 🗘	 Search Radius: Smoothing Factor:	0.30m 0.10	•
✓ Wire Search Radius: Smoothing Factor: tput Fath: C:/PR0J	0.50m 文 0.30 文 ECT/	Search Radius: Smoothing Factor:	0.30m 0.10	

🖌 wire Minimum Points Spacing: 0.03m 🌩	Minimum Points Spacing:	0.03m 韋
🗹 Other		
Minimum Points Spacing: 0.10m 🖨		

### **Parameter Settings**

- Function Options
  - Smooth (checked by default): Smooth the point cloud data to remove noise and make it more uniform.
  - Compress (checked by default): Compress the point cloud data to reduce redundancy.
- Parameters
  - Same as Source File Name (unchecked by default): If checked, the output file after smoothing/compression will use the same name as the source file. Otherwise, a suffix "-SmoothAndCompress" will be added to the file name.
  - **Process by Category (checked by default)**: If checked, only the selected categories will be processed. Otherwise, all points will be processed.
- Smoothing Parameters
  - Line (checked by default): If checked, points in the categories of conductor, ground wire, shield wire, and crossing wire will be smoothed/compressed. Otherwise, they will not be processed.
  - **Tower (checked by default)**: If checked, points in the tower category will be smoothed/compressed. Otherwise, they will not be processed.
  - Search Radius (default 0.50m for line categories, 0.3m for tower category): The distance threshold for searching neighboring points during point cloud smoothing. The larger the value, the more significant the smoothing effect, but if the value is too large, it may cause distortion.
  - **Smoothing Factor (default 0.3 for line categories, 0.1 for tower category)**: The larger the value, the more significant the smoothing effect, but if the value is too large, it may cause distortion.
- Compression Parameters
  - **Minimum Point Spacing (default 0.03m for line and tower categories, 0.10m for other categories)**: The minimum spacing between laser points during point cloud compression. The smaller the value, the weaker the compression effect; the larger the value, the stronger the compression effect.
- Number of Threads (default value is "4"): Set the number of threads for the function to run, supporting 1-32 threads. The software can record the user's current setting and automatically restore it the next time it is opened.

## **Export Danger Points**

#### Summary

Export the clearance danger points into kml file, which can be viewed in Google Earth.

#### Usage

Click Toolbox > Result Finishing > Export Danger Points

-0g			-
learance Data Type			
learance Data Type ) Based on Point Cloud	O Based on Vector Data	) Based on Simu	lation Data
learance Data Type ) Based on Point Cloud put File: [C:/PR0JECT/da	O Based on Vector Data ta/Dangers.kml	) Based on Simu	lation Data

#### Settings

- Clearance Data Type: Select the data type to be processed. The data type includes point cloud based data, vector based data, and data based on working conditions simulation. The software can record the user's current settings and automatically restore the settings when opened again.
  - **Based on Point Cloud**: Extract the power line data from the original point cloud data.
  - **Based on Vector Data**: Extract the power line data from the vector file, and other classes objects from original point cloud data.
  - **Based on Simulation Data**: Extract the power line data from the simulation file, and other classes objects from original point cloud data.
- Output File: The output path of the kml file.

### **Extract Danger Point Clouds**

#### Summary

After the clearance danger point detection, extract the points marked as "dangerous point" and generate a new point cloud file. The function interface is shown in the figure below. This function can process multiple data simultaneously. Click to add the data to be processed. Click to remove the selected data. Click is to clear the data list.

#### Usage

Click Toolbox > Result Finishing > Extract Danger Point Clouds

D:/Data/data/32-33	3(32_33).LiData	
D:/Data/data/31-32	2(31_32).LiData	
D:/Data/data/30-31	1(30_31).LiData	-tr
D:/Data/data/29-30	0(29_30).LiData	
D:/Data/data/28-29	9(28_29).LiData	
1		
		2
Output Path:	D:/Data/DangerPointCloud/	
Output Path: Dutput File Format:	D:/Data/DangerPointCloud/	

#### Settings

- Output Path: Set the output path of the result file.
- Output File Format: The output format of the result, supporting lidata and las format.

Note: The new point cloud will only be generated when the original point cloud contains danger points; otherwise, no point cloud will be generated.

### **Extract Danger Trees**

#### Summary

Based on the result of clearance danger point detection and individual tree segmentation, extract all the trees with danger points as parts of them. The function interface is shown in the figure below. This function can process multiple data simultaneously. Click to add the data to be processed. Click to remove the selected data. Click

#### Usage

Click Toolbox > Result Finishing > Extract Danger Trees

Data File Log	
D:/Data/data/32-33(32_33).LiData	
D:/Data/data/31-32(31_32).LiData	
D:/Data/data/30-31(30_31).LiData	
D:/Data/data/29-30(29_30).LiData	+
D:/Data/data/28-29(28_29).LiData	
	38
	1
	-
Dutput File: D:/Data/DangerTree.csv	
reads Num (1-32): 4	Start Exit

#### Settings

- Output Path: Set the output path of the result file.
- Threads Number (default value is "4"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.

Note: It is required to perform clearance danger point detection and individual tree segmentation before executing this function.

### **Tower Account**

#### Summary

Generate the tower account (xls file) based on the point cloud data and the tower file (LiTower file). The function interface is shown in the figure below. This function can process multiple data simultaneously. Click to add the data to be processed. Click to remove the selected data. Click to clear the data list.

#### Usage

Click Toolbox > Result Finishing > Tower Account

Tower Account		
Data File Log		
		- <del>1</del> -
		1
ower Line Name:		
Based on Unsection Data		
hannel Width: 60.00m 🗘	Extension Length: 10.00m	÷.
tput File: C:/PROJECT/test/TowerAccount.csv		][
	St. 1	30.5

#### Settings

- Power Line Name: Set the name of transmission line.
- Based on Unsection Data: Check this option if input file is unsection point cloud.
- Channel Width(Default value is "60.00m"): Width extending along both sides of the power line. The

software can record the user's current settings and automatically restore the settings when opened again.

- Extension Length(Default value is "10.00m"): Extension distance at both ends of the transmission tower.
- Output File: Set the output path of the tower account.

Note: The input point cloud must contain the point in transmission tower class. The tower file (LiTower file) corresponding to the transmission line must be in the project folder (working directory).

## **Section Map**

#### Summary

Generate the power line section map based on the point cloud data. The function interface is shown in the figure below. This function can process multiple data simultaneously. Click to add the data to be processed. Click — to remove the selected data. Click / to clear the data list.

### Usage

Click Toolbox > Result Finishing > Section Map

Section Map					
Data File Log					
					+
					1
Image Parameter					
tart Tower Index:	0		End Tower Index:	8	
op View Zoom Ratio:	1		Side View Zoom Ratio:	1	
op View Font Size:	15		Side View Font Size:	20	
wrid Row Spacing:	30	m	Grid Column Spacing:	30	
(orizontal Scale:	1/2000	*	Vertical Scale:	1/2000	•
eft Line Color:	1		Middle Line Color:		
ight Line Color:			Power Line Name:		
True Color			Generate Merged Im	age	
utput Path: C:/PROJ	ECT/			11	222
Logo File:				1	
reads Num(1-32): 4				Start	Exit



#### Settings

- **Power Line Name**: Set the name of transmission line. The software can record the user's current settings and automatically restore the settings when opened again.
- **Start Tower Index**: Towers with index numbers smaller than this value are not involved in the calculation. The default value is the minimum Index in the tower file.
- End Tower Index: Towers with index numbers larger than this value are not involved in the calculation. The default value is the maximum Index in the tower file.
- Top View Zoom Ratio (default value is "1"): Set the top view zoom ratio.
- Side View Zoom Ratio (default value is "1"): Set the side view zoom ratio.
- Top View Font Size (default value is "15"): Set the top view font size.
- Side View Font Size (default value is "20"): Set the side view font size.
- Grid Row Spacing (meters) (default value is "30"): Set the grid row spacing.
- Grid Column Spacing (meters) (default value is "30"): Set the grid column spacing.
- Horizontal Scale (default value is "1/2000"): Set the horizontal scale.
- Vertical Scale (default is "1/2000"): Set the vertical scale.
- Left Line Color: Set the color of the left line.
- Middle Line Color: Set the color of the middle line.
- Right Line Color: Set the color of the right side line.
- True Color: Whether to display in true color.
- Generate Merged Image: Whether to generate merged image.
- Output Path: Set the output path of the section maps.
- Logo File: Set the logo file path.
- Threads Number (default value is "4"): Set the number of thread (1 to 32) to run this function. The software can record the currently setting and when the user open this function again, the setting will be kept.

### **Section Report**

#### Summary

Generate a plan and section report using a plan and section drawing. The function interface is shown in the following figure. This function can process multiple data simultaneously. Click 🕂 to add data to be processed, click — to remove selected data, and click 🥖 to clear the data list.

#### Usage

Click Toolbox > Result Finishing > Section Report

Data File Log		
D:/work/workfile/da	ata/test/data/19-20(19_20).LiData	6
D:/work/workfile/da	ata/test/data/18-19(18_19).LiData	분
		-
		1
Report		
	Flectricel Trepsmission	
Assessor Company:	Electrical Transmission Bureau/Company:	
Assessor Company: Line Name:	Electrical Transmission Bureau/Company:	
Assessor Company: Line Name: Target Coordinate:	Electrical Transmission Bureau/Company:	
Assessor Company: Line Name: Target Coordinate: Report Path:	Electrical Transmission         Bureau/Company:         11         WGS 84         D:/work/workfile/data/test/AnalysisReport/	
Assessor Company: Line Name: Target Coordinate: Report Path:	Electrical Transmission Bureau/Company: 11 WGS 84 D:/work/workfile/data/test/AnalysisReport/	•••
Assessor Company: Line Name: Target Coordinate: Report Path: Shn Bila:	Electrical Transmission Bureau/Company:	•••
Assessor Company: Line Name: Target Coordinate: Report Path: Shp File:	Electrical Transmission Bureau/Company: 11 WGS 84 D:/work/workfile/data/test/AnalysisReport/	

- Report Parameters: Parameters related to report generation.
  - Assessor Company: The unit for report generation.
  - Electrical Transmission Bureau/Company: Name of power supply bureau.
  - Power Line Name: Name of power line.
  - Target Coordinate System: Coordinate system used in the report.
  - Report Path: Output path of the report.

### **Merge Tower KML Files**

### Summary

Merge tower KML files, which is the reverse operation of Split Tower KML Files. The function interface is shown below. This function can process multiple data at the same time. Click - to add data to be processed, click — to remove selected data, click  $\checkmark$  to clear the data list.

#### Usage

Click Toolbox > Result Finishing > Merge Tower KML Files

Merge Tower KML Files		
		Ę
tput File: C:/PROJECT/test/MergedTower.kml		
ps: Please add files in order.	Start	Exit

### **Parameter Settings**

• Output Files: Set the path for the merged tower KML file.

## **Batch Rename Section Data Files**

#### Summary

Rename section data files in batch based on tower files. The function interface is shown below, click to add selected data, click to remove selected data, click to clear the file list.

#### Usage

Click Toolbox > Result Finishing >Batch Rename Section Data Files

Data file		
		+
ips: Please add section data fi	les and set n	ew tower file
ath. ower File:		
<b>ath.</b> ower File: riginal Start Tower Index:	1	]
ath. ower File: riginal Start Tower Index: odified Start Tower Index:	1	] ; ;

## **Parameter Settings**

- Tower File: Select the tower information file.
- Original Starting Tower Number: The smallest tower number in the data files to be added.
- **Modified Starting Tower Number**: The number after modifying the original starting tower number, subsequent tower numbers are changed based on the difference with the original starting tower number.

## **Detection Result List**

Detection result lists include clearance danger point list, crossing analysis list, tree growth analysis list, tree growth warning analysis list, tree fall analysis list, allowable stress analysis list, drainage thread clearance analysis list, phase spacing analysis list, sag analysis list, power line and shield line distance analysis list and nearest distance analysis list. The user can choose these tools to view the results of detection and check the accuracy of the results.

- Clearance Danger Points List
- Scissors Crossing Analysis List
- Tree Growth Analysis List
- Tree Growth Warning Analysis List
- Tree Fall Analysis List
- Allowable Stress Analysis List
- Drainage Thread Clearance Analysis List
- Phase Spacing Analysis List
- Sag Analysis List
- Power Line And Shield Line Distance Analysis List
- Nearest Distance Analysis List

## **Clearance Danger Points List**

### Summary

Clearance danger points list contains the result of the clearance danger points analysis. The interface of this tool is shown as follow. Double-click the row of the danger point record to zoom to that point in the 3D scene.

Result List

Suspect Distance: 2 m				
1	28-29(28_29)	10.859	2	
2	28-29(28_29)	4.836	5	
3	29-30(29_30)	0.614	5	
4	55-56(55_56)	4.045	20	
5	55-56(55_56)	10.250	2	
6	55-56(55_56)	10.000	2	
7	55-56(55_56)	6.683	5	
8	55-56(55_56)	6.637	5	
9	55-56(55_56)	5.929	5	
10	55-56(55_56)	10.001	2	
11	55-56(55_56)	6.137	5	
12	55-56(55_56)	6.043	5	
13	55-56(55_56)	9.979	2	
14	55-56(55_56)	10.031	2	
15	55-56(55_56)	10.769	2	
16	56-57(56_57)	5.709	20	
17	56-57(56_57)	5.388	5	
18	56-57(56_57)	6.560	5	



#### Settings

• Suspected Distance (meter) (default value is "2"): Suspected danger point distance. The danger points with clearance distance less than this threshold will be marked as red in the danger points list. This parameter is used to filter out the invalid danger points which is misclassified because of the error in the classification process of the point cloud.

### Data Type



Choose the data type, and the software will list the detection result of the corresponding data type.

### Load Data



Load or renew the detection result list.

Note: Click the header of the detection result table to switch between ascending and descending display by the selected attribute values in the table.

Note: After the detection, view details in the detection result list. Double-click the row of the danger point record to zoom to that point in the 3D scene and display the distance between the danger point and the power line. And judge if the danger point is misclassified due to the error in the classification of the point

cloud. If so, user can use **Profile Tools** to modify the classification result first, then **Clear** the detection results. Finally redo the detection to correct the error.
# **Scissors Crossing Analysis List**

### Summary

Scissors crossing analysis list contains the result of the scissors crossing analysis. The interface of this tool is shown as follow. Double-click the row of the crossing point record to zoom to that point in the 3D scene.

Result List

Scissors tross	ing Analysis *	Based on Point Cloud *
Suspect Distanc	e: 2	m 🛃
Segment ID 🐣	Space Distance	Class ID



### Settings

• Suspected Distance (meter) (default value is "2"): Suspected danger point distance. The danger points with clearance distance less than this threshold will be marked as red in the danger points list. This parameter is used to filter out the invalid danger points which is misclassified because of the error in the classification process of the point cloud.

#### Load Data



Note: Click the header of the detection result table to switch between ascending and descending display by the selected attribute values in the table.

Note: After the detection, view details in the detection result list. Double-click the row of the danger point record to zoom to that point in the 3D scene and display the distance between the danger point and the power line. And judge if the danger point is misclassified due to the error in the classification of the point cloud. If so, user can use **Profile Tools** to modify the classification result first, then **Clear** the detection results. Finally redo the detection to correct the error.

## **Tree Growth Analysis List**

### Summary

Tree growth analysis list records the result of tree growth analysis, as is shown below. Each row contains the coordinates of the danger treetop point and coordinates of the point on the power line which is closest to the treetop.You can zoom to a specific danger tree in 3D viewer by double clicking the row.

Result List

S	uspect Distance:	2	m 💽
	Segment ID 🛎	Space Distance	Tree ID
	28-29(28_29)	6.659	588
2	28-29(28_29)	6.334	579
3	28-29(28_29)	6.124	561
4	28-29(28_29)	4.542	577
5	28-29(28_29)	5.037	580
6	29-30(29_30)	0.936	258



### Settings

• Suspected Distance (meter) (default value is "2"): Suspected danger point distance. The danger points with clearance distance less than this threshold will be marked as red in the danger points list. This parameter is used to filter out the invalid danger points which is misclassified because of the error in the classification process of the point cloud.

### Load Data



Load or renew the detection result list.

Note: When the option "Customize the growth rates of different tree species" is checked, tree growth analysis tool will not be applicable to those tree with unknown species information. But those trees which is tall enough to be the "danger tree" will be marked as "danger tree" anyway.

Note: Click the header of the detection result table to switch between ascending and descending display by the selected attribute values in the table.

Note: After the detection, view details in the detection result list. Double-click the row of the danger point record to zoom to that point in the 3D scene and display the distance between the danger point and the power line. And judge if the danger point is misclassified due to the error in the classification of the point cloud. If so, user can use **Profile Tools** to modify the classification result first, then **Clear** the detection results. Finally redo the detection to correct the error.

# **Tree Growth Warning Analysis List**

### Summary

Tree growth warning analysis list records the result of tree growth warning analysis, as is shown below. Each row contains the clearance distance and growth year etc. You can zoom to a specific danger tree in 3D viewer by double clicking the row.

Result List

Tr	ee Growth Warning	Analysis -	Based or	n Point Cloud
Cri	tical Time: 2			year 🚺
	Segment ID 🔶	Space Distance	Tree ID	1e Span(year-mon
1	28-29(28_29)	12.129	3	26-11
2	28-29(28_29)	14.773	6	29-9
3	28-29(28_29)	9.184	7	11-4
4	28-29(28_29)	12.969	11	27-3
5	28-29(28_29)	12.168	12	18-9
6	28-29(28_29)	10.846	13	17-8
7	28-29(28_29)	18.826	14	50-0
8	28-29(28_29)	12.468	15	20-6
9	28-29(28_29)	10.100	16	10-10
10	28-29(28_29)	19.306	18	51-6
11	28-29(28_29)	12.623	20	20-7
12	28-29(28_29)	18.263	21	42-1
13	28-29(28_29)	20.002	22	47-3
14	28-29(28_29)	10.115	23	11-1
15	28-29(28_29)	10.632	24	13-0
16	28-29(28_29)	10.493	25	13-10
17	28-29(28_29)	12.703	27	25-1
18	28-29(28_29)	14.013	28	29-3
19	28-29(28 29)	17.797	29	42-11



### Settings

• Critical Time (year) (default value is "2"): Set the critical time. When the warning time is less than the critical time, the record will be marked as red. This function is used to quickly view the distribution of danger treetops.

### Load Data



Note: Click the header of the detection result table to switch between ascending and descending display by the selected attribute values in the table.

Note: After the detection, view details in the detection result list. Double-click the row of the danger point record to zoom to that point in the 3D scene and display the distance between the danger point and the power line. And judge if the danger point is misclassified due to the error in the classification of the point cloud. If so, user can use **Profile Tools** to modify the classification result first, then **Clear** the detection results. Finally redo the detection to correct the error.

# **Tree Fall Analysis List**

### Summary

Tree fall analysis list records the result of the tree fall analysis. The interface of this tool is shown as follow. Double-click the row of the tree-fall danger point record to zoom to that point in the 3D scene.

T	ree Fall Analysis	т т В	ased on Point Cloud	
Su	spect Distance:	2	п	n 💽
	Segment ID 📤	Space Distance	Tree ID	-
1	28-29(28_29)	6.902	629	
2	28-29(28_29)	5.582	581	
3	28-29(28_29)	5.961	609	
4	28-29(28_29)	6.461	588	E
5	28-29(28_29)	6.248	579	
6	28-29(28_29)	6.535	575	
7	28-29(28_29)	5.890	561	
8	28-29(28_29)	4.671	577	
9	28-29(28_29)	4.984	580	
10	28-29(28_29)	6.469	420	
11	28-29(28_29)	2.905	405	
12	29-30(29_30)	-0.342	258	
13	29-30(29_30)	6.580	63	
14	29-30(29_30)	4.187	57	
15	29-30(29_30)	6.872	54	
16	55-56(55_56)	6.663	97	
17	55-56(55_56)	6.787	90	
18	55-56(55_56)	6.836	88	
19	55-56(55.56)	6.958	82	



### Settings

• Suspected Distance (meter) (default value is "2"): Suspected danger point distance. The danger points with clearance distance less than this threshold will be marked as red in the danger points list. This parameter is used to filter out the invalid danger points which is misclassified because of the error in the classification process of the point cloud.

#### Load Data

₽

Load or renew the detection result list.

Note: Click the header of the detection result table to switch between ascending and descending display by the selected attribute values in the table.

Note: After the detection, view details in the detection result list. Double-click the row of the danger point record to zoom to that point in the 3D scene and display the distance between the danger point and the power line. And judge if the danger point is misclassified due to the error in the classification of the point cloud. If so, user can use **Profile Tools** to modify the classification result first, then **Clear** the detection results. Finally redo the detection to correct the error.

# Allowable Stress Analysis List

### Summary

Allowable stress analysis list records the result of allowable stress analysis, as is shown below. Double-click the row to zoom to that power line in the 3D scene.

III 🔝 💽								
Segment ID Start X	Start Y	Start Z	Middle X	Middle V	Middle Z	End X	End V	End Z
47-48(47_48)	The second second				-			
47-48(47_48)								
48-49(48 49)								
48-49(48_49)								
48-49(48_49)								
49-50(49_50) 49-50(49_50)								
19-50(49_50) 19-50(49_50)								
0-51(50_51)								
50-51(50_51)								
50-51(50_51)								
1-52(51_52)								
1-52(51_52)								
53(52,53)								
3(52_53)								
8(52_53)								
(53_54)								
3_54)								
s_34) 4 55)								
(54_55)								
4_55)								
(55_56)								
5_56)								
55_56)								
56 57)								
7(56_57)								
								¥×
28	The second division of							
and the second				······································				
and a street of								
۲								and the second
and the opening and	457	Sec.				N	-	Nor II
		William Stat	Sulling.	14			in the second	
ght 201 10								
201.10								
199.71								
100.11								
108 23								

### Load Data



Load or renew the analysis result list.

# **Drainage Thread Clearance Analysis List**

### Summary

Drainage thread clearance analysis list records the result of drainage thread clearance analysis, as is shown below. Each row records the coordinates of the closest point on a single drainage line to the tower and the coordinates of the corresponding point on the tower.

Result List

Suspect Distanc	re: 2	m 💽
Tower ID 🔺	Space Distance	Class ID



#### **Settings**

• Suspected Distance (meters) (default value is "2"): Suspected danger point distance. The danger points with clearance distance less than this threshold will be marked as red in the danger points list. This parameter is used to filter out the invalid danger points which is misclassified because of the error in the classification process of the point cloud.

#### Load Data



Load or renew the detection result list.

Note: Click the header of the detection result table to switch between ascending and descending display by the selected attribute values in the table.

# Phase Spacing Analysis List

## Summary

Phase spacing analysis list records the result of phase spacing analysis, as is shown below. You can zoom to a specific place in 3D viewer by double clicking the row.

	Distance.	2	m
Segm	nent ID 🔷	Line Name	Phase Distance
1 28-2	29(28_29)	S1	18.186
2 28-2	29(28_29)	S2	9.647
3 28-2	29(28_29)	S3	10.404
4 29-3	30(29_30)	S1	11.402
5 29-3	30(29_30)	S2	11.464
6 30-3	31(30_31)	S1	11.412
7 30-3	31(30_31)	S2	11.379



### Load Data

Load or renew the detection result list.

Note: Click the header of the detection result table to switch between ascending and descending display by the selected attribute values in the table.

Note: After the detection, the details can be viewed in the phase spacing analysis list. Double-click the detection record to zoom to that phase spacing location and the phase spacing will be highlighted simultaneously.

# Sag Analysis List

### Summary

Sag analysis list records the result of sag analysis, as is shown below. Double-click the row of any record to zoom to that point in the 3D scene.





Sag Analysis File List

Result List

Ľ	Sag Analysis		<ul> <li>PowerLineSagAnalysis</li> </ul>		
S	uspect Distance:	2	FowerLineSagAnalysis		
1	Segment ID 🚔	Sag(m)	Line Length(m)		
	28-29	34.30	586.58		

Select the sag analysis file, and renew the detection result list. Sag analysis file list is loaded from the csv file in the path of the sag analysis. The default path of the sag analysis is the working directory of the sag analysis folder.

### Load Data



Load or renew the detection result list.

### Set Sag Analysis Directory

Set the directory of the sag analysis and renew the sag analysis file list.

Note: Click the header of the detection result table to switch between ascending and descending display by the selected attribute values in the table.

Note: If there is no angle of wind deflection, the angle of wind deflection records will not be displayed in the list and scene.

# **Nearest Distance Analysis List**

### Summary

The Nearest Distance Analysis List records the results of the nearest distance analysis. The interface is shown in the following figure. Double-clicking on a row will navigate to the location of the point in the 3D scene.

1	earest Distance #	Analysis		-		
Suspect Distance: 2 m						
	Segment ID 🛎	Space Distance	vrizontal Distan	/ertica		
1	0-1(#0_#1)	4.958	0.506	4		
2	0-1(#0_#1)	2.942	0.312	2		
3	1-2(#1_#2)	5.690	0.246	5		
4	1-2(#1_#2)	3.310	0.210	3		
5	2-3(#2 #3)	5.711	0.943	5		
6	2-3(#2 #3)	4.342	0.790	4		
7	3-4(#3 #4)	5.464	0.324	5		
8	3-4(#3 #4)	3.505	1.359	3		
9	4-5(#4 #5)	7.322	0.627	7		
10	4-5(#4 #5)	1.432	1.001	1		
11	5-6(#5_#6)	7.011	0.827	6		
12	5-6(#5_#6)	4.181	3.271	2		
13	6-7(#6_#7)	7.679	1.088	7		
14	6-7(#6_#7)	4.122	2.636	3		
15	6-7(#6_#7)	6.604	2.957	5		
16	6-7(#6_#7)	7.861	0.623	7		



### Settings

• Suspected Distance (meters) (default value is "2"): Suspected danger point distance. The danger points with clearance distance less than this threshold will be marked as red in the danger points list. This parameter is used to filter out the invalid danger points which is misclassified because of the error in the classification process of the point cloud.

### Load Data



Load or renew the detection result list.

Note: Click the header of the detection result table to switch between ascending and descending display by the selected attribute values in the table.

Note: When merging the records, at least two records need to be selected. The operation of merging or deleting will change the records in the corresponding danger points text file in the cache folder.

Note: After the detection, view details in the detection result list. Double-click the row of the danger point record to zoom to that point in the 3D scene and display the distance between the danger point and the powerline. And judge if the danger point is misclassified due to the error in the classification of the point cloud. If so, user can use **Profile Tool** to modify the classification result first, then **Clear** the detection results. Finally redo the detection to correct the error.

# **Tutorials**

- Realtime Working Analysis
- Early Warning Analysis

## **Realtime Working Analysis**

This tutorial introduces the standard workflow of realtime working analysis.

### Steps

The main process for using the power line module to process point cloud data, detect dangerous points, and generate dangerous point detection reports is as follows:

- 1. Click *File > Data > Add Data* to open data.
- 2. Click Power Line > Power Line Parameter Setting to set parameters of power line module.
- 3. Click *Power Line > Mark Tower* to mark position of towers and edit properties of towers.
- 4. Click Power Line > Train to generate training model for automatic classification.
- Click *Power Line > Clip and Classify* to clip and classify point cloud data into tower, power line, ground points, noise and unclassified data automatically. It is necessary to manually check the classification results after automatic classification.
- Click *Power Line > Realtime Working Analysis* to perform dangerous points detection, tree segmentation, image rendering and report generation.
- 7. Click **Power Line > Render Image** to render images based on the results of danger points detection.
- 8. Click *Power Line > Generate Report* to generate an report based on the dangerous points detection result.

### **Tutorial Videos**

1. LiPowerline Realtime Working Analysis

## **Early Warning Analysis**

This tutorial introduces the standard workflow of comprehensive working simulation.

### Steps

The main process for using the power line module to process point cloud data, detect dangerous points, and generate dangerous point detection reports is as follows:

- 1. Click File > Data > Add Data to open data.
- 2. Click Power Line > Power Line Parameter Setting to set parameters of power line module.
- 3. Click *Power Line > Mark Tower* to mark position of towers and edit properties of towers.
- 4. Click Power Line > Train to generate training model for automatic classification.
- Click *Power Line > Clip and Classify* to clip and classify point cloud data into tower, power line, ground points, noise and unclassified data automatically. It is necessary to manually check the classification results after automatic classification.
- 6. Click *Power Line > Vectorization* to semi-automatically vectorize insulators and power lines.
- Click *Power Line > Comprehensive Working Simulation* to perform dangerous points detection, tree segmentation, image rendering and report generation.
- 8. Click Power Line > Render Image to render images based on the results of danger points detection.
- 9. Click Power Line > Generate Report to generate an report based on the dangerous points detection result.

#### **Tutorial Videos**

1. LiPowerline Early Warning Analysis

## Appendix

This chapter introduces some key terms, file formats and ways of high-performance graphics mode adjustment.

- Key Terms
- File Formats
  - LiData
  - LAS
  - LiModel
  - LiTin
  - Clipping Point Cloud File Format
    - Clip by Circle File Format
    - Clip by Rectangle File Format
  - Extract by Time File Format
  - POS File
  - OUT File
  - Control Point File Format
  - Notes Elevation Points File
  - Sample Data File
  - Seed Points File
  - Tower File
  - Simulation File
  - Homologous Points File Format
  - Individual Tree Segmentation Result File
- Shortcut Keys
  - Menu Shortcut Keys
  - Viewer Shortcut Keys
  - Point Editing Shortcut Keys in Profile Window
- High-Performance Graphics Mode Adjustment

## **Key Terms**

- Workflow A sequence of steps to produce the final products.
- Clipping Extracting a subset of points from point cloud using an extent.
- Extracting Extracting a subset of points from point cloud using a specific point attribute.
- Return Number The Return Number is the pulse return number for a given output pulse. A given output laser pulse can have many returns, and they must be marked in sequence of return. The first return will have a Return Number of one, the second a Return Number of two, and so on up to five returns.
- Intensity The intensity value is the integer representation of the pulse return magnitude. This value is optional and system specific. However, it should always be included if available.
- Outlier A point or group of points isolated from other points of interest that are considered noise or extraneous objects.

## **File Formats**

This section introduces the data formats supported by LiPowerline and the specific file formats involved in various functional modules, such as POS file, control point file, seed point file and so on.

- LiData
- LAS
- LiModel
- LiTin
- Clipping Point Cloud File Format
  - Clip by Circle File Format
  - Clip by Rectangle File Format
- Extract by Time File Format
- POS File
- OUT File
- Control Point File Format
- Notes Elevation Points File
- Sample Data File
- Seed Points File
- Tower File
- Simulation File
- Homologous Points File Format

## LiData

LiData is a point cloud data file format defined by LiPowerline. It consists of a public header block, variable length records, and point data records.

This format can be exchanged with other common point cloud data format files, including LAS, LAZ, PLY, ASCII, etc.

When loading common point cloud data formats (including: LAS, LAZ, PLY, ASCII, etc.) into LiPowerline, a LiData file named after the same name will be generated, and the subsequent operations are based on LiData.

# LAS

The LAS file format is a public file format for point cloud data.

To download LAS specifications please go to:

LAS 1.1

LAS 1.2

LAS 1.3

LAS 1.4

## LiModel

LiModel file stores triangulated regular network models generated by DEM or DSM. It saves regular grid nodes and block-organized triangulated regular network models according to quadtree. DOM texture information can be superimposed on the model. LiModel could be transformed from massive data of DEM or DSM. It supports editing operations including flatten height, smooth height, noise points removal and so on. After editing, it can be exported to Tiff file for generating contours.



# LiTin

The LiTin file is generated by the irregular 2.5D triangulation model based on the point cloud. It can improve quality of contour lines by editing operations including flatten height, smooth height, vertex addition and removal, etc. It organizes data in full memory mode, which takes up large memory and causes low rendering efficiency. So it is suggested to generate LiTin file into tiles.



## **Clipping Point Cloud File Format**

#### Brief

The file is a text file that contains a list of scopes used to load multiple circles or rectangles.

### **Clip by Circle File Format**

Each circle consists of three values separated by commas: the X coordinate, the Y coordinate and the radius of the center.

The following table is an example of a circular extent file:

322610.51, 4102305.22, 50 322685.86, 4102400.5, 50 322820.45, 4102510.21, 100 322850.35, 4102655.33, 100 323000.00, 4103000.00, 60

The above values can be stored in a text file (such as "extents.txt") and loaded into the LiPowerline software.

#### **Clip by Rectangle File Format**

Each rectangle consists of four values separated by commas: X minimum, X maximum, Y minimum and Y maximum.

The following table is an example of a rectangular extent file:

```
      322601.255, 322801.255, 4102309.655, 4102409.655

      322548.966, 322600.110, 4102310.180, 4102360.180

      322539.155, 322600.255, 4102309.655, 4102359.655

      322745.950, 322780.110, 4102204.660, 4102250.180

      322875.224, 322975.224, 4102028.660, 4102128.660
```

The above values can be stored in a text file (such as "extents.txt") and loaded into the LiPowerline software.

## **Extract by Time File Format**

Each extraction range consists of two values separated by commas: starting GPS time and ending GPS time.

The following table is an example of extracting range files by GPS time:

526494.500,	527494.500
527494.500,	528494.500
527494.500,	528494.500
528494.500,	529494.500
529494.500,	530494.500

The above values can be stored in a text file (such as "extents.txt ") and loaded into the LiPowerline software.

## **Homologous Points File Format**

Homologous points file is a comma separated text file. The first row is a file header. Each row consists of 9 columns: ID, reference coordinate (X,Y,Z), reference source file, alignment coordinate(X,Y,Z) and alignment source file.

 ID
 ref\_X
 ref\_Y
 ref\_Z
 file
 align\_X
 align\_Y
 align\_Z
 file

 P01, 322500.1100, 4102499.9600, 2613.1400, E:/data/LiForest.LiData, 322500.0089, 4102499.9856, 0.0000, null

 P02, 322999.8400, 4102499.7900, 2614.3400, E:/data/LiForest.LiData, 32299.9283, 4102499.9585, 0.0000, null

 P03, 322999.8300, 4102000.3200, 2554.4100, E:/data/LiForest.LiData, 322999.8738, 410200.1457, 0.0000, null

 P04, 322500.3700, 4102000.1600, 2490.7400, E:/data/LiForest.LiData, 322500.1140, 4102000.0595, 0.0000, null

## **POS File**

The POS File contains information such as GPS time, longitude, latitude, height, roll, pitch, heading, GridX and GridY. GPS time, longitude, latitude, height, roll, pitch and heading must be necessary, while GridX and GridY are optional. If POS file doesn't include GridX and GridY, we need to set projection coordinate system when we input trajectory files. GridX and GridY can be calculated according to projection coordinate system, longitude and latitude in strip alignment module.

Data	Units	Туре
GPS time	seconds	double
longitude	degree	double
latitude	degree	double
height	meters	double
roll	degree	double
pitch	degree	double
heading	degree	double
GridX(Optional)	meters	double
GridY(Optional)	meters	double

The trajectory information stored in its file is structured as follows:

The examples the POS file is shown below. Example 1(not including GridX, GridY):

```
380954.000,112.5311950876, 26.8969520123,378.543,7.1701230000,3.0899110000,-39.4065340000380954.008,112.5311938923, 26.8969533249,378.537,7.201860000,3.0914780000,-39.4034150000380954.016,112.5311926975, 26.8969546376,378.531,7.2368710000,3.0936380000,-39.4011190000380954.024,112.5311915034, 26.8969559507,378.525,7.2683090000,3.1015050000,-39.3975470000380954.032,112.5311903098, 26.8969572641,378.518,7.3007560000,3.1115160000,-39.3929590000380954.040,112.5311891169, 26.8969585779,378.512,7.3269790000,3.117972000,-39.387826000380954.048,112.5311879247, 26.896958920,378.506,7.3525870000,3.118046000,-39.3804020000380954.056,112.5311867331, 26.896912065,378.500,7.3745730000,3.115163000,-39.3713830000
```

Example 2(including GridX, GridY):

```
383207.336,112.5421590662,26.9034172036,313.865,3.538615,2.660518,-67.848653,653147.099716932,2976670.62354689
383207.344,112.5421572108,26.9034177865,313.861,3.533299,2.659177,-67.840828,653146.914649722,2976670.68587654
383207.352,112.5421553554,26.9034183697,313.857,3.522385,2.658042,-67.828619,653146.729582108,2976670.74823943
383207.36,112.5421535001,26.9034189529,313.854,3.512757,2.659231,-67.816251,653146.544524429,2976670.81060244
383207.368,112.5421516447,26.9034195363,313.85,3.502656,2.662677,-67.807435,653146.35945655,2976670.87298749
383207.376,112.5421497892,26.9034201198,313.846,3.502243,2.664987,-67.803265,653146.174378605,2976670.9353835
383207.384,112.5421479336,26.9034207035,313.843,3.500293,2.668456,-67.80232,653145.989290462,2976670.99780155
383207.392,112.5421460783,26.903421874,313.839,3.501546,2.671267,-67.797563,653145.619183163,2976671.12268281
383207.4,112.5421442231,26.9034218713,313.835,3.496569,2.674773,-67.789195,653145.619183163,2976671.12268281
383207.408,112.542144231,26.9034224554,313.832,3.483849,2.676885,-67.774991,653145.434144147,2976671.18514579
383207.416,112.5421442519,26.9034224554,313.823,3.471533,2.676137,-67.765536,653145.24910513,2976671.24760876
383207.424,112.5421465129,26.903422657,313.824,3.47028,2.675779,-67.760612,653145.064056049,2976671.3100827
383207.432,112.5421368024,26.903424079,313.82,3.475101,2.677064,-67.761833,653144.878997039,2976671.37255652
383207.444,112.5421349471,26.9034247923,313.817,3.476053,2.681571,-67.761664,653144.69393776,2976671.43505249
```

## **OUT File**

Out file is a binary file that stores trajectory information. The following table shows the format of the POSPac SBET file provided by Applanix. For details, refer to the PosPac quick start guide.

The trajectory information stored in its file is structured as follows:

Data	Units	Туре
time	seconds	double
latitude	radians	double
longitude	radians	double
altitude	meters	double
x velocity	meters/second	double
y velocity	meters/second	double
z velocity	meters/second	double
roll	radians	double
pitch	radians	double
platform heading	radians	double
wander angle	radians	double
x body acceleration	meters/second <sup>2</sup>	double
y body acceleration	meters/second <sup>2</sup>	double
z body acceleration	meters/second <sup>2</sup>	double
x body angular rate	radians/second	double
y body angular rate	radians/second	double
z body angular rate	radians/second	double

## **Control Point File Format**

The control point file contains a list of control points in TXT format. The first row is the file header, while other rows store comma separated X, Y, Z coordinates of control points. The following table is an example of a control point file:

X, Y, Z 473575.563, 291005.332, 127.244 473576.899, 291004.245, 126.328 473576.899, 291004.243, 126.317 473576.899, 291004.245, 126.328 473576.899, 291004.243, 126.317

## **Notes Elevation Points File**

The notes elevation points file is a comma-delimited CSV file. The first row is the file header, while other rows store X, Y, Z and Label (separated by comma).

The following figure shows an example of notes elevation points file:

```
X, Y, Z, Label
322539.46, 4102000.01, 2489.21, 2489.21
322551.33, 4102009.72, 2489.55, 2489.55
322562.85, 4102000.03, 2489.74, 2489.74
322563.16, 4102019.38, 2489.98, 2489.98
322511.58, 4102056.04, 2492.86, 2492.86
```
#### Sample Data File

The sample data file is a text file (\*.txt) delimited by commas that contains a file header in the first row. The first two columns of each row are the X and Y coordinates, followed by a number of dependent variables. Multiple dependent variables can be stored, but only one is used for each regression analysis.

The dependent variable is tree height in the following example of a sample data file:

```
X,Y,Height
322859.25,4102463.86,33
322862.25,4102459.35,31.5
322864.56,4102462.49,32
322874.58,4102463.50,35
322655.52,4102192.25,21.1
```

#### **Seed Points File**

Seed points file is a comma-separated CSV file. The first row is the file header, while other rows contain a number of seed points. Each row contains four columns: tree ID, tree location X coordinate, tree location Y coordinate and tree location Z coordinate.

The following table shows an example of a seed points file:

```
TreeID,TreeLocationX,TreeLocationY,TreeLocationZ
1,322971.5,4102497.5,47.387
2,322549.5,4102496.5,49.42
3,322678.5,4102495.5,48.456
4,322716.5,4102494.5,34.366
5,322516.5,4102489.5,23.726
```

#### **Tower File**

Tower file is a customized text format file (\*.LiTower). The first row is the file header, while other rows store X, Y, Z, type, and name of each tower (separated by comma). The index is assigned automatically by the software, while the name is set the same as the index by default. Type "N" represents the tension tower, type "Z" represents the straight line tower.

Here is an example of part of tower file:

Index,X,Y,Z,Type,Name
11,740662.360000,2688164.090000,79.850000,N,1
12,740750.560000,2688525.920000,82.040000,Z,2

#### **Simulation File**

The working condition simulation file is in text format (\*.LiSim), and contains working condition information and power line coordinate information. The first line indicates the power line type, the second line indicates the detected line voltage level, and the third and fourth lines indicate power line temperature, ice thickness, and wind speed information (separated by "\t") for scanning and simulated conditions. The fifth line indicates the number of power lines, and the sixth row to the last row indicate the power line coordinate information. The coordinate information includes 17 columns (separated by "\t"), 1-3 columns indicate the X, Y, and Z coordinates of the start point of the power line , 4-6 columns indicate the X, Y, and Z coordinates of the end point of the power line , and columns 7-9 indicate the X, Y, and Z coordinates of the intersection of the start insulator and the tower body, and the columns 13-15 indicate the X, Y, and Z coordinates of the intersection of the end insulator and the tower body, 16-17 indicates whether the start and end insulators are offset under simulated conditions (0 means no offset, 1 means offset).

Here is an example of part of simulation file:

```
LGJ-240/30
500
0.0000
      0.0000
                0.0000
0.0000 0.0000 15.0000
5
666863.9100 2716344.4400 269.0700 667120.0300 2716612.3100 184.3700 666991.9700 2716478.3750
212.5901 666863.9100 2716344.4400 269.0700 667120.0300 2716612.3100 184.3700 0 0
                                 664939.7626 2712980.7251 273.4400
664593.8598 2712726.3097 200.0400
                                                                    664766.8112 2712853.5174
219.8623 664593.8598 2712726.3097
                                  200.0400 664939.1500 2712981.5597
                                                                    276.4400 0
                                                                                 1
                                  665273.5201 2713225.1898 279.0200
664939.7626 2712980.7251 273.4400
                                                                    665106.6413 2713102.9574
260.7851 664939.1500 2712981.5597 276.4400 665273.5201 2713225.1898 279.0200 1 0
665281.4701 2713230.9998 279.7300 665553.3276 2713435.1702 357.2400 665417.3988 2713333.0850
305.7610 665281.4701 2713230.9998 279.7300 665552.7100 2713436.0000 360.2400 0 1
665553.3276 2713435.1702 357.2400
                                  665680.6977 2713530.4203 382.0800
                                                                    665617.0127 2713482.7952
366.9125 665552.7100 2713436.0000
                                  360.2400 665680.0801 2713531.2501
                                                                    385,0800
                                                                             1
                                                                                  1
```

#### **CHM Segmentation Result**

The CHM segmentation result contains a comma-separated CSV table file and a polygon-type shp vector file.

The CSV table contains the attributes of tree ID, x, y coordinate position, tree height, crown diameter and crown area.

The following table shows an example of the segmentation result of CHM:

```
TreeID, TreeLocationX, TreeLocationY, TreeHeight, CrownDiameter, CrownArea
1, 322716.24, 4102494.69, 36.165, 8.982, 63.36
2, 322751.21, 4102499.9, 41.282, 4.491, 15.84
3, 322519.35, 4102499.3, 32.008, 4.708, 16.64
4, 322742.15, 4102497.7, 26.956, 8.347, 54.72
5, 322892.26, 4102499.5, 45.493, 7.792, 47.68
```

The SHP file contains the boundary range of each tree. The attribute table contains the ID, x, y coordinate position, tree height, crown diameter and crown area attributes of each tree.



	TreeID	Х	Y	TreeHeight	Diameter	Area	
1	33	322716.250	4102494.750	17.719	8.272	53,750	
2	7	322751.250	4102499.250	8.767	3.141	7.750	
3	9	322813.750	4102499.250	29.870	2.931	6.750	
4	1	322510.750	4102499.250	13.972	6.358	31.750	
5	2	322519.750	4102499.250	13.099	7.756	47.250	
6	4	322573.250	4102499.250	7.661	3.568	10.000	
7	6	322733.750	4102499.250	19.508	5.140	20.750	
8	16	322742.750	4102498.250	12.150	4.686	17.250	
9	19	322746.750	4102497.250	19.537	4.686	17.250	
10	8	322766.250	4102499.250	17.510	4.853	18.500	
11	12	322838.750	4102499.250	32.976	7.878	48.750	
12	10	322815.250	4102499.250	<mark>31.</mark> 832	3.568	10.000	
13	5	322578.250	4102499.250	11.403	6.154	29.750	
14	13	322892.250	4102499.250	32.772	7.797	47.750	

## ALS Forest results of point cloud segmentation & PCS with Seeds

The ALS Forest results of point cloud segmentation and PCS with seeds are comma-separated CSV table files containing the attributes of tree ID, x, y coordinate position, tree height, crown diameter, crown area and crown volume.

The following table shows an example of the results of the ALS individual tree segmentation:

```
TreeID, TreeLocationX, TreeLocationY, TreeHeight, CrownDiameter, CrownArea, CrownVolume
1, 322511.52, 4102089.78, 60.606, 10.85, 92.04, 3240.171
2, 322511.81, 4102015.14, 53.785, 13.15, 135.09,4358.651
3, 322537.43, 4102062.51, 46.667, 12.45, 126.76, 3272.472
4, 322529.42, 4102073.12, 45.197, 4.071, 13.019, 342.992
5, 322525.07, 4102101.07, 43.861, 3.105, 7.57, 107.672
```

### TLS Forest results of point cloud segmentation & PCS with Seeds

The TLS Forest results of point cloud segmentation and PCS with seeds are comma-separated CSV table files containing the attributes of tree ID, x, y coordinate position, tree height and DBH.

The following table shows an example of the results of the TLS individual tree segmentation:

TreeID, TreeLocationX, TreeLocationY, TreeHeight, DBH 1, 136547.147, 289995.532, 6.498, 0.081 2, 136562.037, 289985.496, 5.652, 0.112 3, 136543.853, 290001.586, 6.115, 0.078 4, 136547.766, 289997.909, 5.868, 0.081 5, 136547.127, 289980.102, 5.217, 0.097

#### **Working Condition Parameter File**

The segmented working condition parameter file is in text format and is saved by default as a segmented working condition parameter. csv file in the line information folder under the working directory, storing segmented working condition parameter information. The file is divided into six columns, separated by "," with the first column indicating the serial number; The second column represents the starting tower number; The third column represents the name of the starting tower; The fifth column represents the end tower name; The sixth to eleventh columns represent the operating conditions parameters.

The following is an example of the segmented working condition parameter file section:

 $\label{eq:linear} Index, StartTowerIndex, EndTowerIndex, StartTowerName, EndTowerName, ScanningConditionWireTemperature(°C), ScanningCondition nIceThickness(mm), ScanningConditionWindSpeed(m/s), SimulationConditionWireTemperature(°C), SimulationConditionIceThickness(mm), SimulationConditionWindSpeed(m/s)$ 

1,0,7,#0,#7,0,10,0,20,0,10

### **Shortcut Keys**

This section introduces the shortcut keys associated with menus, viewers and point editing in profile windows.

- Menu Shortcut Keys
- Viewer Shortcut Keys
- Point Editing Shortcut Keys in Profile Window

### Menu Shortcut Keys

Shortcut Key	Meaning
Ctrl+Shift+O	Open files supported by LiPowerline
Alt+F4	Exit LiPowerline
Ctrl+F3	Add New window
Ctrl+F4	Close Current Window
F11	Full Screen
F3	Orthogonal/ Perspective Projection
F1	Help

### Viewer Shortcut Keys

Shortcut Key	Meaning
А	Anticlockwise Rotation
G	Clockwise Rotation
С	Front Rotation
E	Back Rotation
Т	Tips
W	Show Model/Triangle/Points
Р	Adjust lighting (improve the display effect of LiModel, LiTin, OSGB and other model files)
1	Up
$\downarrow$	Down
$\leftarrow$	Left
$\rightarrow$	Right
+	Zoom in
-	Zoom out
Left Button	Rotation
Right Button	Pan
Middle Wheel	Zoom
Space	Default
Delete	Delete Label/Delete Seed Points

### Point Editing Shortcut Keys in Profile Window

Shortcut Key	Meaning
0-9	Modify the currently selected points to the new classification indicated by the number key pressed
L	Activate the "Line Above Selection" tool
Shift+L	Activate the "Line Below Selection" tool
Shift+R	Activate the "Rectangle Selection" too
Shift+P	Activate the "Polygon Selection" tool
Shift+C	Activate the "Circle Selection" tool
Q	Switch between different selection tools in order
R	Activate / deactivate rotation tool
Ctrl+Shift+Z	Clear Selection
Ctrl+Shift+S	Save
1	Move the cross-section/profiling area forward
$\downarrow$	Move the cross-section/profiling area backward
$\rightarrow$	Rotate the cross-section/profiling area clockwise
$\leftarrow$	Rotate the cross-section/profiling area counter-clockwise

#### **High-Performance Graphics Mode Adjustment**

Follow the procedure below to optimize graphics for LiPowerline (for NVIDIA graphic cards).

1. Right click on desktop and select NVIDIA Control Panel.

	View	
	Sort by	•
	Refresh	
	Paste	
	Paste shortcut	
	Undo Copy	Ctrl+Z
	NVIDIA Control Panel	
	Adobe Drive CS4	•
	New	•
•	nView Desktop Manager	
	Screen resolution	
	Gadgets	
	Personalize	

2. Select **Manage 3D settings > Program Settings > Add** to add LiPowerline.exe to high-performance graphics mode list.

Hect a Task     30 Settings     Adjust image settings with preview	Manage 3D Settin	igs	Restore Defaults
- Marage SD'settings - Set PhysX Configuration	You can change the global 3D settings time the specified programs are launche	and create overrides for specific programs. The overri d.	des will be used automatically each
- Change resolution Adjust desktop color settings	I would like to use the following 3D set	tings:	
- New HDCP status	Global Settings Program Settings		
Set up digital audio Adjust desktop size and position	1. Select a program to customize:		
Set up multiple displays	c: program files (x86) \ifgrest\	- Add Remove 🚾 Res	lore
Stereoscopic 3D Set up stereoscopic 3D Wew compatibility with games	Show only programs found on this con 2. Specify the settings for this program:	puter	
- Video Adjust video color settings	Feature	Setting	
Adjust video image settings	Ambient Occlusion	Not supported for this application	
Workstation Wew system topology	Anisotropic filtering	Use global setting (Application-controlled)	E
-Set up Mosaic	Antialiasing - FXAA	Use global setting (Cff)	
Manage GPU Utilization	Antalasing - Gamma correction	Use global setting (Cn)	1
	Antalasing - Mode	Use global setting (Application-controlled)	
	Antailaging - Setting	Use global secting (Application-controlled)	
	Buffer-Binging mode	Use global setting (only	
	CLIDA - GPUs	Use global secting (ABD acces)	
	Enable overlay	Use global setting (Cff)	100
	Enable overlay Describtion: This listbox contains all of the 3D features yo	Use global setting (Off)	*

Add				X
Select a program:				
	S	ort by:	Recently used	•
LiPowerline.exe			N	
				a.
Can't find the program?			Browse	]
Browse and add a program or a fold executable files inside the folder and	ler. Ad <mark>d</mark> ing a fo d subfolders.	older will	create a profile for all t	he
	Add Sele	cted Prog	ram Cance	

### FAQ

This chapter introduces the frequently asked questions and solutions in the use of LiPowerline. It contains Installation and License Activation FAQ, Platform FAQ, Strip Alignment FAQ, Terrain FAQ, Forestry FAQ and Power Line FAQ.

- Installation and License Activation FAQ
- Platform FAQ
- Power Line FAQ

# Hardware requirements and supported operating systems

- RAM: at least 8G or more.
- CPU: Intel® Core™ i5/i7; Dual-core processor.
- Display Adapter: NVIDIA graphics above GTX 970, video memory no less than 4GB.
- **Operating Systems**: Microsoft Windows 7 (64-bit), Microsoft Windows 8 (64-bit), Microsoft Windows 10 (64-bit), Microsoft Windows 11 (64-bit), Microsoft Windows Server 2012 and higher.

#### After successful installation on my computer, why does the software crash when I try to open or load data?

- Please check whether the software installation environment satisfies the recommended hardware configuration. If yes, please check the following two things. (1) Whether the graphic card is working properly. Right click on My Computer, select the device manager, find the corresponding graphic card in the Display Adapter, and view the graphic card properties status. If it shows "this device is working normally", it means that the graphic card device is running properly. (2) Update the graphic card driver to the latest version, and then use the high-performance graphic mode to run the software. For the operating procedure, see adjust the graphics mode to high performance.
- Please contact us by email info@greenvalleyintl.com to check the reason remotely if you still get an error.

#### How to activate LiPowerline?

• Send Activation Information: Run the software as administrator, click *Help > Activate License* in the menubar, or double-click the License.exe in the installation directory.

	1003	•		
	Name (*);			
	Company(*):			
T : DAD200		Select Froduct		
LIDAR200		2000 20		
- Framew	ork	Torest	Terrain	
LiGeoreference				
LiMapper				
LiPowerline				
🕅 Realtime Work:	ng Condition An	alveis 🔲 Far	ly Warning Analysis	
Real cline work.	ing condition an	u);;;; [] [] [] [] [] [] [] [] [] [] [] [] []	ry warning Analysis	
	🔘 Se	lect All 🔘 Unselect A	11	
tivation Information:				
ame:				
ODD ODT				

- Fill in Name (Mandatory);
- Fill in Company (Mandatory);
- Select the appropriate module(s);
- Click Copy;
- Send an email with the copied content to info@greenvalleyintl.com.
- Activate License:
  - Copy the license code to your local drive. Pleaser refer to the License Manager for license activation.

#### **Does LiPowerline support Windows Server System?**

- Windows Server is supported.
  - Please install and activate LiPowerline using the administrator account. The software must be installed in the folder to which all users have access.

# How to check the version information of LiPowerline software?





#### How to change the menu language?

• Click *Display > Language* in the menubar. Currently the supported language is English.

#### Why does the software exit abnormally?

 Based on our experience, the major two reasons of abnormal exits are the insufficient disk space or memory space in your computer and the existence of opened instance of screen word capturing software. If you meet any other scenarios that lead to abnormal exits, please contact us info@greenvalleyintl.com.

#### What are the supported data formats in LiPowerline?

- LiPowerline can import the following data formats:
  - Point Cloud: Proprietary LiData File(\*.LiData), LAS File(\*.las,\*.laz), ASCII File(\*.txt, \*.asc, \*.neu, \*.xyz, \*.pts, \*.csv), PLY File(\*.ply).
  - Raster: Image File(\*.tif,\*.jpg).
  - Vector: Vector File(\*.shp).
  - Table: Table File(\*.csv)
  - Model: Proprietary Model File(\*.LiModel), Proprietary TIN File\*.LiTin), OSG Model File(\*.osgb, \*.ive, \*.desc, \*.obj).
- LiPowerline can export the following data formats:

- Point Cloud: Proprietary LiData File(\*.LiData), LAS File(\*.las,\*.laz), ASCII File(\*.txt, \*.asc, \*.neu, \*.xyz, \*.pts, \*.csv), PLY File(\*.ply).
- **Raster**: Image File(\*.tif,\*.jpg).
- Vector: Vector File(\*.shp, \*.dxf)
- Table: Table File(\*.csv)
- Model: Proprietary Model File(\*.LiModel), Proprietary TIN File(\*.LiTin).

## If the color scheme of the data displayed in the viewer window is not correct, how can I correct this?

- First, right click on the desktop. Select NVIDIA Control Panel.
- Second, select manage 3D settings > program settings > add to add LiPowerline software to the list of high-performance graphics mode. Refer to adjust high-performance graphics mode.

#### How to fix drag and drop in windows 8 and windows 10?

 Go to RUN, or search "regedit.exe" then run as administrator. On Registry Editor go to: HKEY\_LOCAL\_MACHINE\SOFTWARE\Microsoft\Windows\CurrentVersion\Policies\System, double click "EnableLUA", and change the value from 1 to 0. Restart windows, and the problem will be solved. Reference.

### Why is the EDL visual effect not obvious if multiple data are added in the same window?

• It's recommended to show distant multiple data in separate windows with EDL effect. Or remove unwanted data in the current window.

#### What is the unit of point cloud data in LiPowerline?

The unit is meter. If users have point clouds with foot or other units, they can be converted by *Data Management > Point Cloud Tools > Transformation*. An example is shown in the following figure. X, Y, Z coordinates are multiplied by 0.3048 to be converted from foot to meter.

1	Select		File N	lame	
			LiDAR36	0.LiData	
rans Lir	sformation Type Linear Lear Parameters	•			
rans Lir X=	sformation Type Linear tear Parameters 0.3048	• x +	0		
rans Lir X= Y=	sformation Type Linear Near Parameters 0.3048 0.3048	• * x + * y +	0		
rans Lir X= Y= Z=	sformation Type Linear tear Parameters 0.3048 0.3048 0.3048	• x + * x + * y + * z +	0 0 0		

# Is LiPowerline capable to handle the point cloud generated by photogrammetry software?

• Yes, it is.

### How does LiPowerline perform seven parameter transformations?

- Click Data Management > Point Cloud Tools > Reproject.
- Check Use Seven Parameters.
- Input seven parameters: translations X, Y, Z; rotations Rx, Ry, Rz; and scale  $\lambda$ .
- Select target coordinate reference system. (You have to *define projection* for the point cloud if it doesn't have source coordinate reference system)

	c		
2	Select	File Name	
		LiDAR360.LiD	ata
rrent file's co	ordinate name:		
lter		A	dd Coordinate System
contly used a	aardinata rafaranga systa		
i i b f		**************************************	
oordinate Kererer	nce system	Authority ID	
Ofth_Pole_Azimu	thai_Equidistant	EPSG:102016 EDSG:4326	
/GS 84 / UTM zon	e 32N	EPSG:32632	
GS 84 / UTM zon	e 48N	EPSG:32648	
/GS <mark>8</mark> 4 / UTM zon	e 47N	EPSG:32647	
GS 84 / UTM zon	ie 50N	EPSG:32650	
GS 84 / UTM zon	ie 49N	EPSG:32649	1
<u>1</u>			
ordinate refe	erence systems of the worl	d	Hide deprecated CR
oordinate Referen	nce System	Authority ID	
Voirol 1879	(Paris)	EPSG:4821	
WGS 66		EPSG:4760	
WGS 72		EPSG:4322	
WGS 84		EP30:4324 EPSG:4326	
WGS72		IGNF:WGS72G	
Wake Island	d 1952	EPSG:4733	
		m	(F)
0GCS["WGS 84",] 378137,298.2572;	DATUM["WGS_1984", SPHEROID["WGS 23583, AUTHORITY["EPSG", "T030"] TEVISTICO" "COCC"] LETTES	: 84", ], TOWGS84[0, 0, 0, 0, 0, 0, 0], AUTHORITY["EPSG", 	"6326"]], PRIMEM["Gre OK Cancel
Bugus [ WGS 84", ] 378137, 298.2572; Reproject	DATUM["WGS_1984", SPHEROID["WGS 23583, AUTHORITY["PPSG", "7030"] TYYL <sup>®</sup> FOOL <sup>®</sup> ("COOL <sup>®</sup> ], UTTPL", " Select	: 84", ], TOWGS84[0, 0, 0, 0, 0, 0, 0], AUTHORITY["EPSG", 	"6326"]], PRIMEM["Gre OK Cancel
20GC5 ["WGS 84",] 378137,298.2572; Reproject	DATUM["WGS_1984", SPHEROID["WGS 23583, AUTHORITY["PPSG", "TO3O"] TWY ["PPGG" "COCC"] Select	: 84", ], TOWGS84[0, 0, 0, 0, 0, 0, 0], AUTHORITY["EPSG", 	"6326"]], PRIMEM["Gre OK Cancel sta
20GC5["WGS 84",] 378137,298.2572 Reproject	DATUM["WGS_1984", SPHEROID["WGS 23583, AUTHORITY["PPSG", "TO3O"] Select Vinate name:	: 84", ], TOWGS84[0, 0, 0, 0, 0, 0, 0], AUTHORITY["EPSG", 	"6326"]], PRIMEM["Gre OK Cancel
SUGES ["WGS 84",] 378137,298.2572 Reproject ] rent file's coor Use Seven Parame	DATUM["WGS_1984", SPHEROID["WGS 23583, AUTHORITY["PPSG", "7030"] Select Vinate name:	: 84", ], TOWGS84 [0, 0, 0, 0, 0, 0, 0], AUTHORITY ["EPSG", " File Name LiDAR360.LiD Seven Parameters Setting	"6326"]], PRIMEM["Gre OK Cancel sta
Reproject	DATUM["WGS_1984", SPHEROID["WGS 23583, AUTHORITY["FFSG", "TO3O"] Select dinate name: :ters	: 84", ], TOWGS84 [0, 0, 0, 0, 0, 0, 0], AUTHORITY ["EPSG", " File Name LiDAR360.LiDa Seven Parameters Setting	"6326"]], PRIMEM["Gre OK Cancel sta Add Coordinate System
Reproject Reproject Use Seven Parame Iter	DATUM ["WGS_1984", SPHEROID ["WGS 23583, AUTHORITY ["PPSG", "TO3O"] Select Vinate name: ters	: 84", ], TOWGS84 [0, 0, 0, 0, 0, 0, 0, 0], AUTHORITY ["EPSG", " File Name LiDAR360.LiD Seven Parameters Setting	"6326"]], PRIMEM["Gre OK Cancel sta Add Coordinate System
Reproject Reproject Use Seven Parame Iter cently used	DATUM ["WGS_1984", SPHEROID ["WGS 23583, AUTHORITY ["PPSG", "TO3O"] Select Vinate name: ters Seven Parameters Seven Parameters:	: 84", ], TOWGS84 [0, 0, 0, 0, 0, 0, 0], AUTHORITY ["EPSG", " File Name LiDAR360.LiD: Seven Parameters Setting	"6326"]], PRIMEM["Gre OK Cancel sta Add Coordinate System
Reproject Reproject Use Seven Parame Iter cently used orth_Pole_Azimu	DATUM ["WGS_1984", SPHEROID ["WGS 23583, AUTHORITY ["PPSG", "TO3O"] Select Vinate name: ters Seven Parameters Seven Parameters: X(m)= 0.00000000000	: 84", ], TOWGS84 [0, 0, 0, 0, 0, 0, 0], AUTHORITY ["EPSG", " File Name LiDAR360.LiD: Seven Parameters Setting	"6326"]], PRIMEM["Gre OK Cancel sta Add Coordinate System
Reproject Reproject Seven Parame Iter cently used orth_Pole_Azimu GS 84 / UTM zor	DATUM["WGS_1984", SPHEROID["WGS 23583, AUTHORITY["PPSG", "7030"]	: 84", ], TOWGS84 [0, 0, 0, 0, 0, 0, 0], AUTHORITY ["EPSG", " File Name LiDAR360.LiD: Seven Parameters Setting	"6326"]], PRIMEM["Gre OK Cancel sta Add Coordinate System
Reproject Reproject Reproject Use Seven Parame Iter cently used of cordinate Refere orth_Pole_Azimu GS 84 / UTM zon GS 84 / UTM zon	DATUM["WGS_1984", SPHEROID["WGS 23583, AUTHORITY["PESG", "7030"] Select Seven Parameters Seven Parameters	: 84", ], TOWGS84 [0, 0, 0, 0, 0, 0, 0], AUTHORITY ["EPSG", " " " " " " " " " " " " " " " " " "	"6326"]], PRIMEM["Gre OK Cancel sta Add Coordinate System
Reproject Reproject rent file's coor Use Seven Parame Iter cently used of cordinate Refere orth_Pole_Azimu GS 84 / UTM zon GS 84 / UTM zon GS 84 / UTM zon	DATUM["WGS_1984", SPHEROID["WGS           23583, AUTHORITY["PESG", "7030"]           Select           Image: Select	: 84", ], TOWGS84 [0, 0, 0, 0, 0, 0, 0], AUTHORITY ["EPSG", " " File Name LiDAR360.LiD: Seven Parameters Setting	"6326"]], PRIMEM["Gre OK Cancel sta Add Coordinate System
Reproject Reproject Reproject Use Seven Parame Liter cently used ordinate Refere orth_Pole_Azimu (GS 84 / UTM zon GS 84 / UTM zon GS 84 / UTM zon	DATUM["WGS_1984", SPHEROID["WGS           23583, AUTHORITY["PESG", "7030"]           Select           Image: Select	: 84", ], TOWGS84 [0, 0, 0, 0, 0, 0, 0], AUTHORITY ["EPSG", " " " " " " " " " " " " " " " " " "	"6326"]], PRIMEM["Gre OK Cancel sta Add Coordinate System
Reproject Reproject Reproject Seven Parame Iter cently used ordinate Refere orth_Pole_Azimu GS 84 / UTM zon GS 84 / UTM zon	DATUM["WGS_1984", SPHEROID["WGS           23583, AUTHORITY["PESG", "7030"]           Select           Image: Select	: 84", ], TOWGS84 [0, 0, 0, 0, 0, 0, 0], AUTHORITY ["EPSG", " File Name LiDAR360.LiD: Seven Parameters Setting	"6326"]], PRIMEM["Gre OK Cancel sta Add Coordinate System
Reproject Reproject Reproject Reproject Reproject	DATUM["WGS_1984", SPHEROID["WGS           23583, AUTHORITY["PESG", "7030"]           Select           Image: Select	: 84", ], TOWGS84 [0, 0, 0, 0, 0, 0, 0], AUTHORITY ["EPSG", " File Name LiDAR360.LiD: Seven Parameters Setting	"6326"]], PRIMEM["Gre OK Cancel sta Add Coordinate System
Reproject Reproject Reproject Use Seven Parame Iter cently used of condinate Refere orth_Pole_Azimu GS 84 / UTM zon GS 84 / UTM zon	DATUM["WGS_1984", SPHEROID["WGS           23583, AUTHORITY["PEPSG", "7030"]           Select           Image: Select	: 84", ], TOWGS84 [0, 0, 0, 0, 0, 0, 0], AUTHORITY ["EPSG", " File Name LiDAR360.LiDa Seven Parameters Setting	"6326"]], PRIMEM["Gre OK Cancel sta Add Coordinate System
COCCS 1 "GS 84", J Reproject Reproject rent file's coor Use Seven Parame Iter cently used cordinate Refere ordinate Refere GS 84 / UTM zon GS 84 /	DATUM["WGS_1984", SPHEROID["WGS 23583, AUTHORITY["PESG", "7030"] Select Seven Parameters	: 84", ], TOWGS84[0, 0, 0, 0, 0, 0, 0], AUTHORITY["EPSG", File Name LiDAR360.LiD: Seven Parameters Setting	"6326"]], PRIMEM["Gre OK Cancel sta Add Coordinate System
Reproject Reproject Reproject	DATUM["WGS_1984", SPHEROID["WGS 23583, AUTHORITY["PESG", "7030"] W Select Constense: Seven Parameters Seven Parameters Seven Parameters: X (m)= 0.00000000000 X (m)= 0.00000000000 Rx (")= 0.00000000000 Rx (")= 0.000000000000 Rx (")= 0.00000000000000 Rx (")= 0.000000000000 Rx (")= 0.00000000000 Rx (")= 0.000000000000 Rx (")= 0.000000000000 Rx (")= 0.000000000000 Rx (")= 0.000000000000 Rx (")= 0.000000000000 Rx (")= 0.000000000000 Rx (")= 0.000000000000 Rx (")= 0.00000000000000000 Rx (")= 0.00000000000000000000000000000000000	: 84", ], TOWGS84[0, 0, 0, 0, 0, 0, 0], AUTHORITY["EPSG", ' File Name LiDAR360.LiDa Seven Parameters Setting	"6326"]], PRIMEM["Gre OK Cancel sta Add Coordinate System Hi de deprecated CB
Reproject Reproject Reproject Reproject Reproject Reproject	DATUM["WGS_1984", SPHEROID["WGS 23583, AUTHORITY["PESG", "7030"] with the name: Select Seven Parameters Seven Parameters Seven Parameters X(m)= 0.00000000000 X(m)= 0.0000000000 Rx(")= 0.00000000000 Rx(")= 0.00000000000 Rx(")= 0.000000000000 Rx(")= 0.00000000000 Rx(")= 0.00000000000 Rx(")= 0.00000000000 Rx(")= 0.0000000000000 Rx(")= 0.00000000000 Rx(")= 0.00000000000000000000000000000000000	: 84", ], TOWGS84 [0, 0, 0, 0, 0, 0, 0], AUTHORITY ["EPSG", " File Name LiDAR360.LiD: Seven Parameters Setting OK Cancel 11	"6326"]], PRIMEM["Gre OK Cancel sta Add Coordinate System
Reproject Reproject Reproject	DATUM["WGS_1984", SPHEROID["WGS 23583, AUTHORITY["PESG", "7030"] Select	: 84", ], TOWGS84[0, 0, 0, 0, 0, 0, 0], AUTHORITY["EPSG", File Name LiDAR360.LiDa Seven Parameters Setting OK Cancel	"6326"]], PRIMEM["Gre OK Cancel sta Add Coordinate System X Hi de deprecated CB
Reproject Reproject	DATUM ["WGS_1984", SPHEROID ["WGS 23583, AUTHORITY ["PESG", "7030"] with seven Parameters Seven Parameters X(m)= 0.00000000000 X(m)= 0.00000000000 Rx(")= 0.0000000000 Rx(")= 0.0000000000 Rx(")= 0.0000000000 Rx(")= 0.0000000000 A(ppn) = 0.0000000000	: 84", ], TOWGS84 [0, 0, 0, 0, 0, 0, 0], AUTHORITY ["EPSG", ' File Name LiDAR360.LiD Seven Parameters Setting OK Cancel	"6326"]], PRIMEM["Gre OK Cancel sta Add Coordinate System X Hide deprecated CE

How to subsample the point cloud uniformly?

- LiPowerline provides subsampling methods by *Minimum Points Spacing*, *Sampling Rate*, or *Octree*. The subsampling by *Octree* is an uniform method.
- Click Data Management > Point Cloud Tools > Subsampling, then select the sampling type Octree.

# How to *Pick Rotation Center* while using the *Pick Multi-Point* tool?

• Hold the Ctrl key and pick rotation center by left-click.

# Why are point cloud transformation results incorrect in LiPowerline?

• This is because different units are used in each program. In LiPowerline degree units are used. In order to carry out a correct transformation, the units must be degrees.

# Can I modify the name of a point cloud file generated by clip?

• No, the point cloud file name is associated with the tower file.

#### After completing clip, can you edit the tower file?

• No, this may cause that the point cloud file did not match with the tower file.

### **LiPowerline Version Release Notes**

### v1.0 - 16/10/2016

First version release of LiPowerline

#### **End User License Agreement**

PLEASE READ CAREFULLY BEFORE USING THIS SOFTWARE PRODUCT: This **End-User License Agreement ("EULA")** is a contract between (a) you (either an individual or the entity you represent) and (b) **GreenValley International Inc ("GVI")** that governs your use of the software product ("Software"). This EULA does not apply if there is a separate license agreement between you and GVI or its suppliers for the Software, including a license agreement in online documentation. The term "Software" may include (i) associated media, (ii) a user guide and other printed materials, and (iii) "online" or electronic documentation (collectively "User Documentation").

RIGHTS IN THE SOFTWARE ARE OFFERED ONLY ON THE CONDITION THAT YOU AGREE TO ALL TERMS AND CONDITIONS OF THIS EULA. BY INSTALLING, COPYING, DOWNLOADING, OR OTHERWISE USING THE SOFTWARE, YOU AGREE TO BE BOUND BY THIS EULA. IF YOU DO NOT ACCEPT THIS EULA, DO NOT INSTALL, DOWNLOAD, OR OTHERWISE USE THE SOFTWARE. IF YOU PURCHASED THE SOFTWARE BUT DO NOT AGREE TO THIS EULA, PLEASE RETURN THE SOFTWARE TO YOUR PLACE OF PURCHASE WITHIN FOURTEEN DAYS FOR A REFUND OF THE PURCHASE PRICE; IF THE SOFTWARE IS INSTALLED ON OR MADE AVAILABLE WITH ANOTHER GVI PRODUCT, YOU MAY RETURN THE ENTIRE UNUSED PRODUCT.

- THIRD PARTY SOFTWARE. The Software may include, in addition to GVI proprietary software ("GVI Software"), software under licenses from third parties ("Third Party Software" and "Third Party License"). Any Third-Party Software is licensed to you subject to the terms and conditions of the corresponding Third-Party License. Generally, the Third-Party License is in a file such as "license.txt" or a "readme" file. You should contact GVI support if you cannot find a Third-Party License.
- 2. LICENSE RIGHTS. You will have the following rights provided you comply with all terms and conditions of this EULA:

a. Use. GVI grants you a license to Use one copy of the GVI Software. "Use" means installing, copying, storing, loading, executing, displaying, or otherwise using the GVI Software. You may not modify the GVI Software or disable any licensing or control feature of the GVI Software. If this Software is provided by GVI for Use with an imaging or printing product (for example, if the Software is a printer driver, firmware, or add-on), the GVI Software may only be used with such product ("GVI Product"). Additional restrictions on Use may appear in the User Documentation. You may not separate component parts of the GVI Software for Use. You do not have the right to distribute the GVI Software.

b. Copying. Your right to copy means you may make archival or back-up copies of the GVI Software, provided each copy contains all the original GVI Software's proprietary notices and is used only for back-up purposes.

- 3. UPGRADES. To Use GVI Software provided by GVI as an upgrade, update, or supplement (collectively "Upgrade"), you must first be licensed for the original GVI Software identified by GVI as eligible for the Upgrade. To the extent the Upgrade supersedes the original GVI Software, you may no longer use such GVI Software. This EULA applies to each Upgrade unless GVI provides other terms with the Upgrade. In case of a conflict between this EULA and such other terms, the other terms will prevail.
- 4. TRANSFER. You may not rent, lease or lend the GVI Software or Use the GVI Software for commercial timesharing or bureau use. You may not sublicense, assign or otherwise transfer the GVI Software except as expressly provided in this EULA.

- 5. PROPRIETARY RIGHTS. All intellectual property rights in the Software and User Documentation are owned by GVI or its suppliers and are protected by law, including applicable copyright, trade secret, patent, and trademark laws. You will not remove any product identification, copyright notice, or proprietary restriction from the Software.
- 6. LIMITATION ON REVERSE ENGINEERING. You may not reverse engineer, decompile, or disassemble the GVI Software, except and only to the extent that the right to do so is allowed under applicable law.
- 7. CONSENT TO USE OF DATA. GVI and its affiliates may collect and use technical information you provide in relation to (i) your Use of the Software or the GVI Product, or (ii) the provision of support services related to the Software or the GVI Product. All such information will be subject to GVI's privacy policy. GVI will not use such information in a form that personally identifies you except to the extent necessary to enhance your Use or provide support services.
- 8. LIMITATION OF LIABILITY. Notwithstanding any damages that you might incur, the entire liability of GVI and its suppliers under this EULA and your exclusive remedy under this EULA will be limited to the amount actually paid by you for the Product. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL GVI OR ITS SUPPLIERS BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOST PROFITS, LOST DATA, BUSINESS INTERRUPTION, PERSONAL INJURY, OR LOSS OF PRIVACY) RELATED IN ANY WAY TO THE USE OF OR INABILITY TO USE THE SOFTWARE, EVEN IF GVI OR ANY SUPPLIER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES AND EVEN IF THE ABOVE REMEDY FAILS OF ITS ESSENTIAL PURPOSE. Some states or other jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.
- 9. U.S. GOVERNMENT CUSTOMERS. Software was developed entirely at private expense. All Software is commercial computer software within the meaning of the applicable acquisition regulations. Accordingly, pursuant to US FAR 48 CFR 12.212 and DFAR 48 CFR 227.7202, use, duplication and disclosure of the Software by or for the U.S. Government or a U.S. Government subcontractor is subject solely to the terms and conditions set forth in this End User License Agreement, except for provisions which are contrary to applicable mandatory federal laws.
- 10. COMPLIANCE WITH EXPORT LAWS. You will comply with all laws, rules, and regulations (i) applicable to the export or import of the Software, or (ii) restricting the Use of the Software, including any restrictions on nuclear, chemical, or biological weapons proliferation.
- 11. RESERVATION OF RIGHTS. GVI and its suppliers reserve all rights not expressly granted to you in this EULA.